

Operating Instructions

Diesel engine
12 V 4000 M93 x
16 V 4000 M93 x

MS150047/04E



Power. Passion. Partnership.

| Engine model | kW/cyl. | Application group |
|--------------|-------------|---|
| 12V4000M93 | 195 kW/cyl. | 1DS, continuous operation, variable, low load factors |
| 12V4000M93L | 215 kW/cyl. | 1DS, continuous operation, variable, low load factors |
| 16V4000M93 | 195 kW/cyl. | 1DS, continuous operation, variable, low load factors |
| 16V4000M93L | 215 kW/cyl. | 1DS, continuous operation, variable, low load factors |

Table 1: Applicability

Printed in Germany

© 2013 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

Table of Contents

| | | | | |
|-------|--|----|-----|--|
| 1 | Safety | | | |
| 1.1 | Important provisions for all products | 5 | | |
| 1.2 | Personnel and organizational requirements | 6 | | |
| 1.3 | Safety regulations for startup and operation | 7 | | |
| 1.4 | Safety regulations for maintenance and repair work | 8 | | |
| 1.5 | Fire prevention and environmental protection, fluids and lubricants, auxiliary materials | 11 | | |
| 1.6 | Standards for safety notices in the text | 13 | | |
| 1.7 | Transport | 14 | | |
| 2 | General Information | | | |
| 2.1 | Engine layout | 15 | | |
| 2.2 | Product description | 16 | | |
| 2.3 | Engine side and cylinder designations | 25 | | |
| 2.4 | Sensors and actuators - Overview | 26 | | |
| 2.5 | Engine wiring harness - Overview | 36 | | |
| 3 | Technical Data | | | |
| 3.1 | ENGINE DATA 12V 4000M93, heat exchanger installed, EPA stage 2 | 43 | | |
| 3.2 | ENGINE DATA 12V 4000M93, heat exchanger installed, IMO | 46 | | |
| 3.3 | ENGINE DATA 12V 4000M93L, heat exchanger installed, EPA stage 2 | 49 | | |
| 3.4 | ENGINE DATA 12V 4000M93L, heat exchanger installed, IMO | 52 | | |
| 3.5 | ENGINE DATA 16V 4000M93, heat exchanger installed, EPA stage 2 | 55 | | |
| 3.6 | ENGINE DATA 16V 4000M93, heat exchanger installed, IMO | 58 | | |
| 3.7 | ENGINE DATA 16V 4000M93L, heat exchanger installed, EPA stage 2 | 61 | | |
| 3.8 | ENGINE DATA 16V 4000M93L, heat exchanger installed, IMO | 64 | | |
| 3.9 | Engine - Main dimensions | 67 | | |
| 3.10 | Firing order | 68 | | |
| 4 | Operation | | | |
| 4.1 | LOP - Controls | 69 | | |
| 4.2 | Putting the engine into operation after extended out-of-service periods (>3 months) | 71 | | |
| 4.3 | Putting the engine into operation after scheduled out-of-service-period | 72 | | |
| 4.4 | Starting the engine | 73 | | |
| 4.5 | Operational checks | 74 | | |
| 4.6 | Fuel treatment system control cabinet - Control elements | | 75 | |
| 4.7 | Tasks after extended out-of-service periods (>3 weeks) | | 76 | |
| 4.8 | Checks prior to start-up | | 77 | |
| 4.9 | Fuel treatment system - Putting into operation | | 78 | |
| 4.10 | Fuel treatment system - Switching on | | 81 | |
| 4.11 | Stopping the engine | | 82 | |
| 4.12 | Engine emergency stop at BlueLine automation system (control stand) | | 83 | |
| 4.13 | Coupling - Engaging from LOP | | 84 | |
| 4.14 | Coupling - Disengaging from LOP | | 85 | |
| 4.15 | Waterjet - Flushing from LOP (optional) | | 86 | |
| 4.16 | Stopping the engine from LOP | | 87 | |
| 4.17 | Stopping the engine at the BlueLine automation system (control stand) | | 88 | |
| 4.18 | Emergency stop from LOP | | 89 | |
| 4.19 | Emergency engine stop | | 90 | |
| 4.20 | After stopping the engine | | 91 | |
| 4.21 | Fuel treatment system - Shutdown | | 92 | |
| 4.22 | Plant - Cleaning | | 93 | |
| 5 | Maintenance | | | |
| 5.1 | Maintenance schedule task reference table [QL1] | | 94 | |
| 6 | Troubleshooting | | | |
| 6.1 | Fuel treatment system - Troubleshooting | | 96 | |
| 6.2 | Troubleshooting | | 97 | |
| 6.3 | ADEC (ECU 7) fault codes for Series 4000 engines, marine application | | 100 | |
| 6.4 | ADEC engine governor - Fault codes | | 101 | |
| 7 | Task Description | | | |
| 7.1 | Engine | | 127 | |
| 7.1.1 | Engine - Barring manually | | 127 | |
| 7.1.2 | Engine - Barring with starting system | | 128 | |
| 7.2 | Cylinder Liner | | 129 | |
| 7.2.1 | Cylinder liner - Endoscopic examination | | 129 | |
| 7.2.2 | Instructions and comments on endoscopic and visual examination of cylinder liners | | 131 | |
| 7.3 | Valve Drive | | 133 | |
| 7.3.1 | Valve gear - Lubrication | | 133 | |
| 7.3.2 | Valve clearance - Check and adjustment | | 134 | |
| 7.3.3 | Cylinder head cover - Removal and installation | | 138 | |

| | | | | | |
|--------|---|-----|---------|---|-----|
| 7.4 | Injection Pump / HP Pump | 139 | 7.15.1 | Raw water pump - Relief bore check | 183 |
| 7.4.1 | HP pump - Filling with engine oil | 139 | 7.16 | Battery-Charging Generator | 184 |
| 7.4.2 | HP pump - Relief bore check | 140 | 7.16.1 | Battery-charging generator drive - Coupling condition check | 184 |
| 7.5 | Injection Valve / Injector | 141 | 7.17 | Engine Mounting / Support | 185 |
| 7.5.1 | Injector - Replacement | 141 | 7.17.1 | Engine mounting - Check | 185 |
| 7.5.2 | Injector - Removal and installation | 142 | 7.18 | Auxiliary PTO | 186 |
| 7.6 | Fuel Filter | 147 | 7.18.1 | Bilge pump - Relief bore check | 186 |
| 7.6.1 | Fuel filter - Replacement | 147 | 7.19 | Fuel Supply System | 187 |
| 7.6.2 | Fuel prefilter - Differential pressure gauge check and adjustment | 149 | 7.19.1 | Water drain valve - Check | 187 |
| 7.6.3 | Fuel prefilter - Draining | 150 | 7.19.2 | Differential pressure gauge - Check | 188 |
| 7.6.4 | Fuel prefilter - Flushing | 151 | 7.19.3 | Water level probe (3-in-1 rod electrode) - Check | 189 |
| 7.6.5 | Fuel prefilter - Filter element replacement | 153 | 7.19.4 | Pump capacity - Check | 190 |
| 7.7 | Exhaust Turbocharger | 155 | 7.19.5 | Coalescer filter element - Replacement | 191 |
| 7.7.1 | Compressor wheel - Cleaning | 155 | 7.20 | Wiring (General) for Engine/Gearbox/Unit | 193 |
| 7.8 | Charge-Air Cooling | 157 | 7.20.1 | Engine wiring - Check | 193 |
| 7.8.1 | Intercooler - Check water drain for coolant discharge and obstruction | 157 | 7.21 | Accessories for (Electronic) Engine Governor / Control System | 194 |
| 7.9 | Air Filter | 158 | 7.21.1 | CDC parameters - Reset with DiaSys® | 194 |
| 7.9.1 | Air filter - Replacement | 158 | 7.21.2 | EMU and connectors - Cleaning | 195 |
| 7.9.2 | Air filter - Removal and installation | 159 | 7.21.3 | Limit switch for start interlock - Check | 196 |
| 7.10 | Air Intake | 160 | 7.21.4 | Engine governor and connectors - Cleaning | 197 |
| 7.10.1 | Service indicator - Signal ring position check (optional) | 160 | 7.21.5 | Engine Control Unit ECU 7 - Checking plug connections | 198 |
| 7.11 | Starting Equipment | 161 | 7.21.6 | Engine Monitoring Unit EMU 8 - Plug connections check | 199 |
| 7.11.1 | Starter - Condition check | 161 | 7.21.7 | Interface module plug connections - Check | 200 |
| 7.12 | Lube Oil System, Lube Oil Circuit | 162 | 7.21.8 | ECU 7 engine governor - Removal and installation | 201 |
| 7.12.1 | Engine oil - Level check | 162 | 7.21.9 | EMU 8 - Removal and installation | 202 |
| 7.12.2 | Engine oil - Change | 163 | 7.21.10 | Engine Interface Module EIM - Removal and installation | 203 |
| 7.12.3 | Engine oil - Sample extraction and analysis | 165 | 7.21.11 | Diagnostic features of EIM | 204 |
| 7.13 | Oil Filtration / Cooling | 166 | 7.22 | Emergency Instrumentation (Local Operating Panel) | 207 |
| 7.13.1 | Oil indicator filter - Cleaning | 166 | 7.22.1 | LOP and connectors - Cleaning | 207 |
| 7.13.2 | Automatic oil filter - Oil filter candles replacement | 168 | 8 | Appendix A | |
| 7.13.3 | Oil indicator filter - Cleaning and check | 171 | 8.1 | Abbreviations | 208 |
| 7.13.4 | Centrifugal oil filter - Cleaning and filter-sleeve replacement | 173 | 8.2 | MTU contact persons/service partners | 210 |
| 7.14 | Coolant Circuit, General, High-Temperature Circuit | 175 | 9 | Appendix B | |
| 7.14.1 | Venting points | 175 | 9.1 | Index | 211 |
| 7.14.2 | Engine coolant - Level check | 176 | 9.2 | Spare Parts | 214 |
| 7.14.3 | Engine coolant - Change | 177 | 9.3 | Consumables | 216 |
| 7.14.4 | Engine coolant draining | 178 | 9.4 | Special Tools | 219 |
| 7.14.5 | Engine coolant - Filling | 179 | | | |
| 7.14.6 | Engine coolant pump - Relief bore check | 181 | | | |
| 7.14.7 | Engine coolant - Sample extraction and analysis | 182 | | | |
| 7.15 | Raw Water Pump with Connections | 183 | | | |

1 Safety

1.1 Important provisions for all products

Nameplate

The product is identified by nameplate, model designation or serial number and must match with the information on the title page of this manual.

Nameplate, model designation or serial number can be found on the product.

General information

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Modifications or conversions
- Noncompliance with the safety instructions and warning notices

Correct use

The product is intended exclusively for the application specified in the contract or defined at the time of delivery.

This means that the equipment must be operated:

- Within the permissible operating parameters in accordance with the (→ product data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ applicable Spare Parts Catalog)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (including engine control/parameters)
- In compliance with all safety instructions and in adherence to all warning notices in this manual
- In accordance with the maintenance requirements over the entire service life of the product (→ Maintenance Schedule)
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair
- By contracting only workshops authorized by the manufacturer to carry out repair and overhaul

Any other use is considered improper use and increases the risk of personnel injury or material damage in product operation. The manufacturer will accept no liability for such damage.

Modifications or conversions

Unauthorized modifications to the product compromise safety.

The manufacturer will accept no liability or warranty claims for any damage caused by unauthorized modifications or conversions.

Spare parts

Only genuine spare parts must be used to replace components or assemblies.

The manufacturer will accept no liability or warranty claims for any damage caused by the use of other spare parts.

1.2 Personnel and organizational requirements

Organizational measures of the operator

This manual must be issued to all personnel involved in operation, maintenance, repair or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair and transport personnel at all times.

Use this manual as a basis for instructing personnel on product operation and repair, whereby the safety-relevant instructions, in particular, must be read and understood.

This is particularly important in the case of personnel who only occasionally perform work on or around the product. This personnel must be instructed repeatedly.

Personnel requirements

All work on the product shall be carried out by trained and qualified personnel only.

- Training at the Training Center of the manufacturer
- Qualified personnel specialized in mechanical and plant engineering

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair and transport.

Working clothes and personal protective equipment

Wear proper protective clothing for all work.

When working, always wear the necessary personal protective equipment (e.g. ear protectors, protective gloves, goggles, breathing protection). Observe the information on personal protective equipment in the respective activity description.

1.3 Safety regulations for startup and operation

Safety regulations for startup

Install the product correctly and carry out acceptance in accordance the manufacturer's specifications before putting the product into service.

Before the product is put into operation for the first time, all official authorizations must be available and commissioning preconditions met.

When putting the product into operation, always ensure

- that all maintenance and repair work has been completed;
- that all loose parts have been removed from rotating machine components;
- that no-one is present in the danger zone of rotating machine components.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the signaling and alarm systems work properly.

Safety regulations for equipment operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

The procedures for cases of emergency, in particular, emergency stop, must be practiced regularly.

The following steps must be taken if a malfunction of the system is recognized or reported by the system:

- Inform supervisor(s) in charge,
- Analyze the message,
- If required, carry out emergency operations e.g. emergency stop.

Operation

The following conditions must be fulfilled before starting the product:

- Wear ear protection.
- Ensure that the engine room is well ventilated.
- Do not inhale the exhaust gases of the product.
- Ensure that the exhaust system is free of leaks and that the gases are discharged to atmosphere.
- Mop up any leaked or spilt fluids and lubricants immediately or soak up with a suitable binding agent.
- Protect battery terminals, generator terminals or cables against accidental contact.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Observe the safety instructions for these devices.

1.4 Safety regulations for maintenance and repair work

Safety regulations prior to maintenance and repair work

Have maintenance or repair work carried out by qualified and authorized personnel only.

Allow the product to cool down to less than 50°C before starting maintenance work (risk of explosion of oil vapors, fluids and lubricants, risk of burning).

Before starting work, relieve pressure in systems and compressed-air lines which are to be opened. Use suitable containers of adequate capacity to catch fluids and lubricants.

When changing the oil or working on the fuel system, ensure that the engine room is adequately ventilated.

Never carry out maintenance and repair work with the product in operation.

Carry out function checks on a product in operation only if expressly permitted to do so.

Secure the product against unintentional starting, e.g. with start interlock.

Attach "Do not operate" sign in the operating area or to control equipment.

Disconnect the battery. Lock circuit breakers.

Close the main valve on the compressed-air system and vent the compressed-air line when pneumatic starters are fitted.

Disconnect the control equipment from the product.

The following additional instructions apply to starters with beryllium copper pinion:

- Breathing protection of filter class P2 must be applied during maintenance work to avoid health hazards caused by the beryllium-containing pinion. Do not blow out the interior of the flywheel housing or the starter with compressed air. Clean the flywheel housing inside with a class H dust extraction device as an additional measure.

Safety regulations during maintenance and repair work

Take special care when removing ventilation or plug screws from the product. Cover the screw or plug with a rag to prevent fluids escaping under pressure.

Take care when draining hot fluids and lubricants (risk of burning).

Use only proper and calibrated tools. Observe the specified tightening torques during assembly or disassembly.

Carry out work only on assemblies or plants which are properly secured.

Never use lines for climbing.

Keep fuel injection lines and connections clean.

Always seal connections with caps or covers if a line is removed or opened.

Take care not to damage lines, in particular fuel lines, during maintenance and repair work.

Ensure that all retainers and dampers are installed correctly.

Ensure that all fuel injection and pressurized oil lines are installed with enough clearance to prevent contact with other components. Do not place fuel or oil lines near hot components.

Do not touch elastomeric seals if they have carbonized or resinous appearance unless hands are properly protected.

Note cooling time for components which are heated for installation or removal (risk of burning).

When working high on the equipment, always use suitable ladders and work platforms. Make sure components or assemblies are placed on stable surfaces.

Ensure particular cleanliness during maintenance and repair work on the product. After completion of maintenance and repair work, make sure that no loose objects are in/on the product (e.g. cloths and cable ties)

Safety regulations after completion of maintenance and repair work

Before barring, make sure that nobody is standing in the danger zone of the product.

Check that all guards have been reinstalled and that all tools and loose parts have been removed after working on the product (in particular, the barring tool).

Welding work

Welding operations on the product or mounted units are not permitted. Cover the product when welding in its vicinity.

Before starting welding work:

- Switch off the power supply master switch.
- Disconnect the battery.
- Separate the electrical ground of electronic equipment from the ground of the unit.

No other maintenance or repair work must be carried out in the vicinity of the product while welding is going on. Risk of explosion or fire due to oil vapors and highly flammable fluids and lubricants.

Do not use product as ground terminal.

Never position the welding power supply cable adjacent to, or crossing wiring harnesses of the product. The welding current may otherwise induce an interference voltage in the wiring harnesses which could conceivably damage the electrical system.

Remove parts (e.g. exhaust pipes) which are to be welded from the product beforehand.

Hydraulic installation and removal

Check the function and safe operating condition of tools and fixtures to be used. Use only the specified devices for hydraulic removal/installation procedures.

Observe the max. permissible push-on pressure specified for the equipment.

Do not attempt to bend or apply force to lines.

Before starting work, pay attention to the following:

- Vent the hydraulic installation/removal tool, the pumps and the lines at the relevant points for the equipment to be used (e.g. open vent plugs, pump until bubble-free air emerges, close vent plugs).
- For hydraulic installation, screw on the tool with the piston retracted.
- For hydraulic removal, screw on the tool with the piston extended.

For a hydraulic installation/removal tool with central expansion pressure supply, screw spindle into shaft end until correct sealing is established.

During hydraulic installation and removal, ensure that nobody is standing in the immediate vicinity of the component to be installed/removed.

Working with batteries

Observe the safety instructions of the battery manufacturer when working with batteries.

Gases emanating from the battery are explosive. Avoid sparks and naked flames.

Do not allow electrolyte to come in contact with skin or clothing.

Wear protective clothing and protective gloves.

Never place tools on the battery.

Before connecting the cable to the battery, check the battery polarity. Battery pole reversal may lead to injury through the sudden discharge of acid or bursting of the battery body.

Working on electrical and electronic assemblies

Always obtain the permission of the person in charge before commencing maintenance and repair work or switching off any part of the electronic system required to do so.

De-energize the appropriate areas prior to working on assemblies.

Do not damage cabling during removal work. When reinstalling ensure that wiring is not damaged during operation by contact with sharp objects, by rubbing against other components or by a hot surface.

Do not secure cables on lines carrying fluids.

Do not use cable binders to secure cables.

Always use connector pliers to tighten union nuts on connectors.

Subject the device as well as the product to a function check on completion of all repair work. In particular, check the function of the engine emergency stop feature.

Store spare parts properly prior to replacement, i.e. protect them against moisture in particular. Pack defective electronic components and assemblies in a suitable manner when dispatched for repair, i.e. protected, in particular, against moisture and impact and wrapped in antistatic foil if necessary.

Working with laser equipment

When working with laser equipment, always wear special laser-protection goggles (hazard due to heavily focused radiation).

Laser equipment must be fitted with the protective devices necessary for safe operation according to type and application.

For conducting light-beam procedures and measurement work, only the following laser devices must be used:

- Laser devices of classes 1, 2 or 3A.
- Laser devices of class 3B, which have maximum output in the visible wavelength range (400 to 700 nm), a maximum output of 5 mW, and in which the beam axis and surface are designed to prevent any risk to the eyes.

1.5 Fire prevention and environmental protection, fluids and lubricants, auxiliary materials

Fire prevention

Rectify any fuel or oil leaks immediately. Oil or fuel on hot components can cause fires – therefore always keep the product in a clean condition. Do not leave cloths saturated with fluids and lubricants on the product. Do not store combustible materials near the product.

Do not carry out welding work on pipes and components carrying oil or fuel. Before welding, clean with a nonflammable fluid.

When starting the engine with an external power source, connect the ground lead last and remove it first. To avoid sparks in the vicinity of the battery, connect the ground lead from the external power source to the ground lead of the engine or to the ground terminal of the starter.

Always keep suitable firefighting equipment (fire extinguishers) at hand and familiarize yourself with their use.

Noise

Noise can lead to an increased risk of accidents if it makes it more difficult to hear audible signals, warning calls or noises indicating danger.

Wear ear defenders in work areas with a sound pressure level in excess of 85dB (A).

Environmental protection and disposal

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission control units/systems may only be maintained, exchanged or repaired if the components used for this purpose are approved by the manufacturer. Noncompliance with these guidelines will invalidate the design type approval issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emission regulations. The maintenance schedules of the manufacturer must be observed over the entire life cycle of the product.

Dispose of used consumables and filters in accordance with local regulations.

Within the EU, batteries can be returned free of charge to the manufacturer where they will be properly recycled.

Auxiliary materials, fluids and lubricants

The Fluids and Lubricants Specifications will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found on the website on the "Technical Info" tab at <http://www.mtu-online.com>.

Consumable fluids and materials may also be hazardous or toxic. When using fluids, lubricants, consumables and other chemical substances, follow the safety instructions that apply to the product. Take special care when using hot, chilled or caustic substances. When using flammable materials, prevent them coming into contact with ignition sources and do not smoke.

Used oil

Used oil contains combustion residues that are harmful to health.

Rub barrier cream into hands.

Wash hands after contact with used oil.

Lead

- Adopt suitable measures to avoid the formation of lead dust.
- Switch on extraction system.
- When working with lead or pastes that contain lead, avoid direct contact with the skin. Do not inhale lead vapors.
- Wash hands after contact with lead or lead-containing substances.

Compressed air

Observe special safety precautions when working with compressed air:

- Unauthorized use of compressed air, e.g. forcing flammable liquids (hazard class A1, A2 and B) out of containers, risks causing an explosion.
- Wear goggles when blowing dirt off components or blowing away swarf.
- Blowing compressed air into thin-walled containers (e.g. containers made of sheet metal, plastic or glass) for drying purposes or to check for leaks risks bursting them.
- Pay special attention to the pressure in the compressed air system or pressure vessel.
- Assemblies or products to be connected must either be designed for that pressure, or, if the permissible pressure is lower than the system pressure, a pressure reducing valve and safety valve (set to the permissible pressure) must be connected between the assemblies/products and the system.
- Hose couplings and connections must be securely attached.
- Provide the snout of the air nozzle with a protective disk (e.g. rubber disk).
- First shut off compressed air lines before compressed air device is disconnected from the supply line, or before device or tool is to be replaced.
- Carry out leak test in accordance with the specifications.

Paints and varnishes

- Observe the relevant safety data sheet for all materials.
- When painting in areas other than spray booths equipped with extractors, ensure good ventilation. Make sure that neighboring work areas are not adversely affected.
- There must be no naked flames in the vicinity.
- No smoking.
- Observe fire prevention regulations.
- Always wear a mask providing protection against paint and solvent vapors.





Liquid nitrogen

- Observe the relevant safety data sheet for all materials.
- Store liquid nitrogen only in small quantities and always in regulation containers (without gas-tight caps).
- Avoid body contact (eyes, hands).
- Wear protective clothing, protective gloves, closed shoes and safety goggles.
- Make sure that working area is well ventilated.
- Avoid knocking or jolting the containers, fixtures or workpieces in any way.

Acids/alkalis/urea solution (AdBlue, DEF)

- Observe the relevant safety data sheet for all materials.
- When working with acids and alkaline solutions, wear goggles or face mask, gloves and protective clothing.
- Do not inhale vapors.
- If urea solution is swallowed, rinse out mouth and drink plenty of water.
- If spilled onto clothing, remove the affected clothing immediately.
- After contact with skin, rinse affected parts of the body with plenty of water.
- Rinse eyes immediately with eyedrops or clean tap water. Seek medical attention as soon as possible.

1.6 Standards for safety notices in the text


| | |
|---|---|
| DANGER  | In the event of immediate danger. Consequences: Death, serious or permanent injury! <ul style="list-style-type: none">• Remedial action. |
| WARNING  | In the event of a situation involving potential danger. Consequences: Death, serious or permanent injury! <ul style="list-style-type: none">• Remedial action. |
| CAUTION  | In the event of a situation involving potential danger. Consequences: Minor or moderate injuries! <ul style="list-style-type: none">• Remedial action. |
| NOTICE  | In the event of a situation involving potentially adverse effects on the product. Consequences: Material damage. <ul style="list-style-type: none">• Remedial action• Additional product information |

Safety notices

- ▶ This manual with all safety instructions and safety notices must be issued to all personnel involved in operation, maintenance, repair or transportation.

1.7 Transport

Transport



Only use the lifting eyes provided to lift the engine.

The lifting eyes are designed for the transport of engine only, not for the transport of drive units (engine and transmission).

Only use transport and lifting devices approved by MTU.

The engine must only be transported in installation position, max. permissible diagonal pull 10° .

Take the engine's center of gravity into account.

In the case of special packaging with aluminum foil, suspend the engine on the lifting eyes of the transport pallet or transport with equipment for heavy loads (forklift truck).

Install the crankshaft locking device and the locking screws for the engine mounts prior to engine transportation.

Secure the engine against tilting during transport. The engine must be especially secured against slipping or tilting when going up or down inclines and ramps.

Setting the engine down after transport

Only set down engine on a firm, level surface.


Make sure that the consistency and load-bearing capacity of the ground or support surface is adequate.

Never place an engine on the oil pan, unless expressly authorized by MTU on a case-to-case basis to do so.

2 General Information

2.1 Engine layout

Also valid for 12V engines



- | | | |
|--------------------------|-----------------------|------------------------------|
| 1 Oil cooler | 7 Cylinder head | 13 Automatic oil filter |
| 2 Coolant expansion tank | 8 Charge-air pipework | 14 Fuel filter |
| 3 Crankcase breather | 9 Oil filler neck | 15 Centrifugal oil filter(s) |
| 4 Air filter | 10 Oil pan | 16 Coolant cooler |
| 5 Exhaust turbocharger | 11 Engine mounting | |
| 6 Intercooler | 12 HP fuel pump | |

Engine model designation

Key to the engine model designations 16V 4000 Mxyz

| | |
|--------|---|
| 12, 16 | Number of cylinders |
| V | Cylinder arrangement: V engine |
| 4000 | Series |
| M | Application |
| x | Application segment (1, 2) |
| y | Design index (3) |
| z | R (reduced power/speed) L (enhanced power/speed) |

2.2 Product description

Description of the engine

Engine

The engine is a liquid-cooled four-stroke diesel engine, rotating counterclockwise (seen from driving end), with direct injection, sequential turbocharging and charge-air cooling.

The engine is monitored by an engine control and monitoring system (ADEC).

Monitoring in the engine room is carried out by the engine control and monitoring unit (LOP).

Fuel system

Electronically controlled common-rail-injection system with HP pump, pressure accumulator (rail) and single injectors with integrated individual store.

The electronic control unit controls

- Start of injection
- Injection quantity
- Injection pressure

Exhaust system

The exhaust system is equipped with triple-walled, water-cooled exhaust lines.

The triple-walled design permits

- low surface temperature,
- reduced amount of heat to be dissipated by the coolant,
- absolute gas-tightness.

Turbocharging

Sequential turbocharging with internal, engine-coolant-controlled charge-air cooling. The right-hand exhaust turbocharger is cut-in and cut-out on 12V and 16V engines with electronically-controlled, hydraulically-actuated flaps.

Cooling system

Engine cooling as split-circuit cooling system with plate-core heat exchanger.

Heating of the charge air in idle and low-load operation prevents white smoke formation.

Seawater only flows through engine coolant and fuel heat exchanger as well as the raw water pump.

Service block

The service components are mounted on the auxiliary PTO end.

The arrangement facilitates easy access for maintenance operations.

Service components:

- Raw water pump, coolant pump
- Fuel duplex filter, switchable
- Automatic oil filter
- Centrifugal lube oil filter
- Coolant expansion tank

Electronic system

Electronic control and monitoring system with integrated safety and test system, providing interfaces to Remote Control System (RCS) and Monitoring and Control System (MCS).

Engine Interface Module (EIM)

The Engine Interface Module (EIM) is the central connection box on the engine. Covers the entire minimum scope of a marine engine. Has no controls or parts requiring maintenance.

Functions:

- Starter control (start repetition, tooth alignment, starter protection)
- Generator monitoring
- Open bus interface to the plant (SAE J1939)
- Emergency stop function with line break monitoring
- Redundant power supply
- Optional control of emergency air-shutoff flaps
- Key switch logic
- Interface to ECU and EMU
- MCS5 dialog interface
- Control of an MTU lube-oil priming pump (power components in separate MTU PPC Box)
- Connection facility for an MTU Local Operating Station (LOS)
- Serial RS422 interface for diagnosis

The engine interface comprises two parts. The first part is connected to the engine wiring harness via a 62-pole Tyco connector X52. The second part comprises signals at higher current levels. These signals are led out via M threaded pins and also connected to the engine wiring harness.

Functions

- ECU supply
- EMU supply
- Plant signals (ECU7 connector X1)
- Bus interface (2x MCS5 CAN)
- CAN dialog output (1xMCS5 CAN)
- ECU and EMU emergency stop
- Electric starter
- Terminal 45 of starter A/B (starter engaged)
- Pneumatic starter
- Start-air pressure valve
- Start-air pressure sensor
- Barring gear (barring gear 1 and 2)
- Generator (with excitation control)
- Optional shut-down air flaps
- Control SSK 1+2
- Feedback SSK 1+2

Electronic Engine Control Unit (ECU)

Functions:

- Engine speed control with fuel and speed limitation dependent on engine status and operating conditions;
- Control of sequential turbocharging, cylinder bank cut-out and air recirculation function.
- Data processing logistics for analog and binary signals;
- Interface for data transfer to CAN field bus for remote control and ship-side monitoring;
- RS 232 interface for connection of MTU dialog unit.

Electronic Engine Monitoring Unit (EMU), optional

Functions:

- Data processing logistics for analog and binary signals;
- Interface for data transfer to CAN field bus for remote control and ship-side monitoring.

Electronic Gear Control Unit (GCU), ship-side wall-mounting

Functions:

- Data processing logistics for gear coupling control;
- Input/output signals as well as data transfer to CAN field bus for remote control and ship-side monitoring.

Monitoring in engine room

Engine control and monitoring unit (LOP)

Functions:


- Alphanumeric, monochrome LCD display for monitoring of measured values as well as alarms when limits are violated;
- Pushbuttons for menu control and dimming unit;
- Combined control and display elements for local engine/gear control;
- Flashing light and horn for combined alarm in engine room;
- Interface to CAN field bus for connected, communicating monitoring system components.

SOLAS – Fire safety requirements


All lines with SOLAS-compliant covers for pipe connections, according to MTU standard MTN5233, are shown below.

Fuel system, fuel lines with fuel pressures exceeding 1.8 bar


1 Fuel line to fuel filter head



1 Fuel line from/to fuel filter head




1 Fuel line to HP pump



Lube oil system, oil lines with oil pressures exceeding 1.8 bar


1 Parting line ETC oil supply free end




1 Oil line on equipment carrier



1 Oil supply to HP pump




1 Oil supply to flap control free end




TIM-ID: 0000010056 - 005


1 ETC oil supply on main oil gallery




1 Switching cylinder air flap turbo-charger B1
2 T piece flap control




1 Switching cylinder exhaust flap tur-
bocharger B1




- 1 Oil line from main oil gallery
- 2 Oil line to main oil gallery



- 1 Flap control distributor



- 1 Air recirculation valve




TIM-ID: 0000010056 - 005

Special connections

The following connection types are spray-proof in case of leakage even without covers and have been confirmed as being SOLAS-compliant by GL and DNV.

Plugs and sensors, plug-in pipe connections



Plugs and sensors (a)

Screw plugs (4) are either sealed with copper sealing rings (1) as per DIN or O-rings (ISO).

The fluid must first pass the thread in case of a loose threaded union or faulty sealing ring (1).

The pressure is so greatly reduced by this and the faulty sealing ring (1) that any leakage is not under pressure.


Plug-in pipe connection (b)

Design precludes lateral spray as the point of separation is shielded by the sleeve (3).

Only seepage along the pipeline is possible whereby the pressure is greatly reduced by a faulty O-ring (2).

The union is confirmed as being SOLAS-compliant by DNV and GL.

High-pressure unions



07700104b

- | | | |
|-------------------------|---------------------|----------------------------------|
| 1 Jacketed pipe | 8 Thrust ring | 15 Union nut |
| 2 HP line | 9 Union nut | 16 Thrust ring |
| 3 O-ring | 10 Union nut | 17 Outer tube of HP fuel line |
| 4 Union nut | 11 Connecting piece | 18 Internal tube of HP fuel line |
| 5 Recess for O-ring | 12 Snap ring | 19 Ball-type seal area |
| 6 Thrust ring | 13 Thrust ring | 20 Leak fuel connection |
| 7 Leakage overflow bore | 14 Shims | |

The HP fuel line is sealed by the thrust ring (8).

If leakage in the area of the thrust ring (8) or the HP line (5) occurs, the emerging fuel is routed to the leakage chamber.

Leak fuel is allowed to escape without pressure via the leakage overflow bore (7). The leakage chamber is sealed toward the outside by the O-rings (3).

This prevents leaking fuel from escaping.


The union is confirmed as being SOLAS-compliant by DNV and GL.

2.3 Engine side and cylinder designations

Engine sides are always designated as viewed from the driving end (KS) (4).

For designation of the cylinders (to DIN ISO 1204) the letter "A" (1) is used to refer to the cylinders on the left-hand side of the engine and the letter "B" (3) to refer to the cylinders on the right-hand side. The cylinders of each bank are numbered consecutively, starting with No. 1 at the driving end.

The numbering of other engine components also starts with no. 1 at the driving end.




1 Left-hand side of engine
2 Free end

3 Right-hand side of engine
4 Driving end

00001555


2.4 Sensors and actuators - Overview

12V 4000 M top view




- | | | |
|---|---|--|
| 1 B4.A1 (exhaust temp. cyl. A1) | 8 B5.2 (lube oil pressure after filter) | 15 B4.B5 (exhaust temp. cyl. B5) |
| 2 B4.A2 (exhaust temp. cyl. A2) | 9 B34.2 (fuel pressure before filter) | 16 B4.B4 (exhaust temp. cyl. B4) |
| 3 B4.A3 (exhaust temp. cyl. A3) | 10 B34.1 (fuel pressure after filter) | 17 B4.B3 (exhaust temp. cyl. B3) |
| 4 B4.A4 (exhaust temp. cyl. A4) | 11 B5.3 (lube oil pressure before filter) | 18 B4.B2 (exhaust temp. cyl. B2) |
| 5 B4.A5 (exhaust temp. cyl. A5) | 12 B48 (fuel pressure in common rail) | 19 B4.B1 (exhaust temp. cyl. B1) |
| 6 B4.A6 (exhaust temp. cyl. A6) | 13 F33 (coolant level) | 20 B4.22 (exhaust temperature, B bank) |
| 7 B49 (charge-air temp., air recirculation valve) | 14 B4.B6 (exhaust temp. cyl. B6) | 21 B4.21 (exhaust temperature, A bank) |

12V 4000 M left side



- | | | |
|---|-------------------------------|-------------------------------|
| 1 B5.1 (lube-oil pressure after filter) | 6 B10 (charge-air pressure) | 11 B57.5 (main bearing temp.) |
| 2 B7 (lube oil temperature) | 7 B57.1 (main bearing temp.) | 12 B57.6 (main bearing temp.) |
| 3 B50 (crankcase pressure) | 8 B57.2 (main bearing temp.) | 13 B57.7 (main bearing temp.) |
| 4 B3 (intake air temperature) | 9 B57.3 (main bearing temp.) | |
| 5 B44.1 (turbocharger A speed) | 10 B57.4 (main bearing temp.) | |

12V 4000 M free end




- 1 F46 (H-Fuel leakage)
- 2 B33 (T-Fuel, rail)
- 3 B1 (N-Camshaft)

- 4 B54 (P-Oil refill pump)
- 5 B6.2 (T-Coolant)
- 6 B6 (T-Coolant)

- 7 Connector XD1 – Dialog unit


12V 4000 M right side



09600492

- | | | |
|---|---|---|
| 1 B44.2 (turbocharger B speed) | 5 B77.B5 (spray oil temp. (conrod bearing)) | 9 B77.B1 (spray oil temp. (conrod bearing)) |
| 2 B16 (coolant pressure) | 6 B77.B4 (spray oil temp. (conrod bearing)) | 10 B9 (charge-air temperature) |
| 3 B21 (raw water pressure) | 7 B77.B3 (spray oil temp. (conrod bearing)) | |
| 4 B77.B6 (spray oil temp. (conrod bearing)) | 8 B77.B2 (spray oil temp. (conrod bearing)) | |


12 V 4000 M driving end



09600489


- | | |
|--------------------------|----------------------------|
| 1 B13 (crankshaft speed) | 3 S37.1 (safety switch) |
| 2 S37.2 (safety switch) | 4 B13.2 (crankshaft speed) |

16V 4000 M top view



- | | | |
|---|---|--|
| 1 B4.A1 (exhaust temp. cyl. A1) | 10 B4.A8 (exhaust temp. cyl. A8) | 19 B4.B6 (exhaust temp. cyl. B6) |
| 2 B4.A2 (exhaust temp. cyl. A2) | 11 B5.2 (P lube oil downstream of filter) | 20 B4.B5 (exhaust temp. cyl. B5) |
| 3 B4.A3 (exhaust temp. cyl. A3) | 12 B34.2 (fuel pressure before filter) | 21 B4.B4 (exhaust temp. cyl. B4) |
| 4 B4.A4 (exhaust temp. cyl. A4) | 13 B34.1 (fuel pressure after filter) | 22 B4.B3 (exhaust temp. cyl. B3) |
| 5 B4.A5 (exhaust temp. cyl. A5) | 14 B5.3 (lube oil pressure before filter) | 23 B4.B2 (exhaust temp. cyl. B2) |
| 6 B3 (intake air temperature) | 15 B48 (fuel pressure in common rail) | 24 B4.B1 (exhaust temp. cyl. B1) |
| 7 B4.A6 (exhaust temp. cyl. A6) | 16 F33 (coolant level) | 25 B4.22 (exhaust temperature, B bank) |
| 8 B49 (charge-air temp., air recirculation valve) | 17 B4.B8 (exhaust temp. cyl. B8) | 26 B4.21 (exhaust temperature, A bank) |
| 9 B4.A7 (exhaust temp. cyl. A7) | 18 B4.B7 (exhaust temp. cyl. B7) | |


16V 4000 M left side



09600495

- | | | |
|---|-------------------------------|-------------------------------|
| 1 B5.1 (lube-oil pressure after filter) | 6 B57.1 (main bearing temp.) | 11 B57.6 (main bearing temp.) |
| 2 B7 (lube oil temperature) | 7 B57.2 (main bearing temp.) | 12 B57.7 (main bearing temp.) |
| 3 B50 (crankcase pressure) | 8 B57.3 (main bearing temp.) | 13 B57.8 (main bearing temp.) |
| 4 B44.1 (turbocharger A speed) | 9 B57.4 (main bearing temp.) | 14 B57.9 (main bearing temp.) |
| 5 B10 (charge-air pressure) | 10 B57.5 (main bearing temp.) | |

16V 4000 M free end




09600496a

- 1 F46 (H-Fuel leakage)
- 2 B33 (T-Fuel, rail)
- 3 B1 (N-Camshaft)

- 4 B54 (P-Oil refill pump)
- 5 B6.2 (T-Coolant)
- 6 B6 (T-Coolant)


- 7 Connector XD1 – Dialog unit

16V 4000 M right side



- | | | |
|---|---|--|
| 1 B44.2 (turbocharger B speed) | 5 B77.B7 (spray oil temp. (conrod bearing)) | 9 B77.B3 (spray oil temp. (conrod bearing)) |
| 2 B16 (coolant pressure) | 6 B77.B6 (spray oil temp. (conrod bearing)) | 10 B77.B2 (spray oil temp. (conrod bearing)) |
| 3 B21 (raw water pressure) | 7 B77.B5 (spray oil temp. (conrod bearing)) | 11 B77.B1 (spray oil temp. (conrod bearing)) |
| 4 B77.B8 (spray oil temp. (conrod bearing)) | 8 B77.B4 (spray oil temp. (conrod bearing)) | 12 B9 (charge-air temperature) |

16V 4000 M driving end



09600494


- 1 B13 (crankshaft speed)
- 2 S37.2 (safety switch)
- 3 S37.1 (safety switch)
- 4 B13.2 (crankshaft speed)

2.5 Engine wiring harness - Overview

| Designation | Pin assignment | |
|-------------------------------------|--------------------|---------------------------------|
| Engine wiring harness | X2 | Governor ECU-7 |
| | B1 | Camshaft speed |
| | B3 | Intake air temperature |
| | B4.21 | Exhaust temperature, A side |
| | B4.22 | Exhaust temperature, B-side |
| | B5.1 | Lube oil pressure after filter |
| | B5.2 | Lube oil pressure after filter |
| | B5.3 | Lube oil pressure before filter |
| | B6 | Coolant temperature |
| | B7 | Lube oil temperature |
| | B9 | Charge-air temperature |
| | B10 | Charge-air pressure |
| | B13 | Crankshaft speed |
| | B16 | Coolant pressure |
| | B33 | Fuel temperature |
| | B34.1 | Fuel pressure after filter |
| | B34.2 | Fuel pressure before filter |
| | B44.1 | Exhaust turbocharger A speed |
| | B44.2 | Exhaust turbocharger B speed |
| | B48 | High-pressure fuel |
| | B49 | Charge air before recirculation |
| | B50 | Crankcase pressure |
| | B54 | Refill pump pressure |
| | F33 | Coolant level |
| | M8 | Fuel pump |
| | F46 | Leak fuel level |
| | S37.1 | Start interlock limit switch A |
| | S37.2 | Start interlock limit switch B |
| | X37 | Start interlock turning |
| | Y26 | Charge-air recirculation |
| Y27 | Turbocharger valve | |
| XG03 | Generator | |
| Engine wiring harness for injectors | X4 | Governor ECU-7 |
| | E4.X | KF thermostat heating |
| | Y39A1 to Y39AX | Injectors, engine side A |
| | Y39B1 to Y39BX | Injectors, engine side B |
| Adaption | X1 | Engine Control Unit ECU |
| | X3 | Engine Control Unit ECU Power |


| Designation | Pin assignment | |
|-------------|----------------|-----------------------|
| | X11 | EMU Power |
| | X37 | Start interlock |
| | X52 | EIM engine box |
| | XB19 | Starting-air pressure |
| | XD1 | Dialog unit |
| | XY1 | Starter |

Engine wiring harness for sensors 12V




- | | | |
|---------|----------|----------|
| 1 B50 | 11 XG03 | 21 S37.2 |
| 2 B7 | 12 S37.1 | 22 B13 |
| 3 B5.1 | 13 B10 | 23 B16 |
| 4 B5.3 | 14 B4.21 | 24 B44.2 |
| 5 B34.2 | 15 M8 | 25 F33 |
| 6 B34.1 | 16 X2 | 26 B49 |
| 7 F46 | 17 X37 | 27 B44.1 |
| 8 B48 | 18 B6 | 28 Y27 |
| 9 B33 | 19 B4.22 | 29 Y26 |
| 10 B1 | 20 B9 | 30 B3 |

Engine wiring harness for sensors 16V



- | | | |
|---------|----------|----------|
| 1 B50 | 11 B1 | 21 S37.2 |
| 2 B7 | 12 S37.1 | 22 B13 |
| 3 B5.1 | 13 B10 | 23 B16 |
| 4 B5.3 | 14 B4.21 | 24 B44.2 |
| 5 B34.2 | 15 M8 | 25 Y27 |
| 6 B34.1 | 16 X2 | 26 F33 |
| 7 F46 | 17 X37 | 27 B49 |
| 8 B48 | 18 B6 | 28 B44.1 |
| 9 B33 | 19 B4.22 | 29 B3 |
| 10 XG03 | 20 B9 | 30 Y26 |

Engine wiring harness for injectors 12V




09600514

- 1 Y39A1
- 2 Y39A2
- 3 Y39A3
- 4 Y39A4
- 5 Y39A5
- 6 Y39A6

- 7 X4
- 8 E4.3
- 9 E4.4
- 10 E4.5
- 11 Y39B5
- 12 Y39B6

- 13 E4.2
- 14 E4.1
- 15 Y39B4
- 16 Y39B3
- 17 Y39B2
- 18 Y39B1

Engine wiring harness for injectors 16V




09600515

1 Y39A1
2 Y39A2
3 Y39A3
4 Y39A4
5 Y39A5
6 Y39A6
7 Y39A7
8 Y39A8

9 X4
10 E4.3
11 E4.4
12 E4.5
13 Y39B7
14 Y39B8
15 E4.2
16 E4.1

17 Y39B6
18 Y39B5
19 Y39B4
20 Y39B3
21 Y39B2
22 Y39B1

Engine wiring harness for EIM




1 XD1
2 X1
3 X3

4 X52
5 XY1
6 X11

7 XB19
8 X37

09600713

Engine wiring harness for electric starter



1 EIM terminals

2 Fuse F1

3 Starter terminals

3 Technical Data

3.1 ENGINE DATA 12V 4000M93, heat exchanger installed, EPA stage 2

Explanation:

- DL Ref. value: Continuous power
- BL Ref. value: Fuel stop power
- A Design value
- G Guaranteed value
- R Guideline value
- L Limit value, up to which the engine can be operated without changes (e.g. of power setting)
- N Not yet defined value
- Not applicable
- X Applicable

REFERENCE CONDITIONS

| Engine model | | | 12V 4000 M93 |
|-------------------------------|--|------|-----------------|
| Application group | | | 1DS |
| Intake air temperature | | °C | 25 |
| Raw water inlet temperature | | °C | 25 |
| Barometric pressure | | mbar | 1000 |
| Site altitude above sea level | | m | 100 |

POWER-RELATED DATA (power ratings are net brake power as per ISO 3046)

| Number of cylinders | | | 12 |
|--------------------------|---|-----|------|
| Rated engine speed | A | rpm | 2100 |
| Fuel stop power ISO 3046 | A | kW | 2340 |

GENERAL CONDITIONS (for maximum power)

| Number of cylinders | | | 12 |
|--------------------------------|---|------|----|
| Intake depression (new filter) | A | mbar | 15 |
| Intake depression, max. | L | mbar | 30 |

MODEL RELATED DATA (basic design)

| Number of cylinders | | | 12 |
|---------------------------------------|--|---------|-------|
| Cylinder arrangement: V angle | | Degrees | 90 |
| Bore | | mm | 170 |
| Stroke | | mm | 190 |
| Displacement per cylinder | | Liters | 4.31 |
| Displacement, total | | Liters | 51.72 |
| Number of inlet valves per cylinder | | | 2 |
| Number of exhaust valves per cylinder | | | 2 |

RAW WATER CIRCUIT (open circuit)

| | | | |
|--|---|-----|------|
| Number of cylinders | | | 12 |
| Raw water pump: Inlet pressure, min. | L | bar | -0.2 |
| Raw water pump: Inlet pressure , max. | L | bar | 0.5 |
| Pressure loss in external raw water system, max. | L | bar | 0.7 |

LUBE OIL SYSTEM

| | | | |
|--|---|-----|-----|
| Number of cylinders | | | 12 |
| Lube oil operating temperature before engine, from | R | °C | 70* |
| Lube oil operating temperature before engine, to | R | °C | 78* |
| Lube oil operating pressure before engine, from | R | bar | 6 |
| Lube oil operating pressure before engine, to | R | bar | 8 |
| Lube oil operating pressure, low idle (meas. point: before engine) | R | bar | 2.0 |

FUEL SYSTEM

| | | | |
|---|---|-----------|------|
| Number of cylinders | | | 12 |
| Fuel pressure at engine supply connection, min. (when engine is starting) | L | bar | -0.1 |
| Fuel pressure at engine supply connection, min. (when engine is running) | L | bar | -0.3 |
| Fuel pressure at engine supply connection, max. (when engine is starting) | L | bar | 1.5 |
| Fuel supply flow, max. | R | liter/min | 30 |

GENERAL OPERATING DATA

| | | | |
|---------------------|---|-----|-----|
| Number of cylinders | | | 12 |
| Firing speed, from | R | rpm | 80 |
| Firing speed, to | R | rpm | 120 |

STARTING (electric)

| | | | |
|--|---|----|----|
| Number of cylinders | | | 12 |
| Starter, rated voltage (standard design) | R | V= | 24 |

STARTING (with compressed air/hydraulic starter)

| | | | |
|--|---|-----|----|
| Number of cylinders | | | 12 |
| Starting-air pressure before starter motor, min. | R | bar | 8 |
| Starting-air pressure before starter motor, max. | R | bar | 10 |

INCLINATIONS, STANDARD OIL SYSTEM (reference: waterline)

| | | | |
|---|---|---------|------|
| Number of cylinders | | | 12 |
| Longitudinal inclination, continuous max., driving end down (option: max. operating inclinations) | L | Degrees | 15 |
| Longitudinal inclination temporary max. drive side down (design: max. operating inclinations) | L | Degrees | 22.5 |

| | | | |
|---|---|---------|-----------|
| Number of cylinders | | | 12 |
| Longitudinal inclination, continuous max., driving end up (option: max. operating inclinations) | L | Degrees | 10 |
| Transverse inclination, constant max. (option: max. operating inclinations) | L | Degrees | 22.5 |

CAPACITIES

| | | | |
|--|---|--------|-----------|
| Number of cylinders | | | 12 |
| Engine coolant, engine-side (with cooler) | R | Liters | 360 |
| Engine oil on initial filling (standard oil system) (option: max. operating inclinations) | R | Liters | 260 |
| Oil change quantity, max. (standard oil system) (option: max. operating inclinations) | R | Liters | 205 |
| Oil pan capacity at dipstick mark "min." (standard oil system) (option: max. operating inclinations) | L | Liters | 160 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (option: max. operating inclinations) | L | Liters | 200 |

WEIGHTS / MAIN DIMENSIONS

| | | | |
|--|---|----|-----------|
| Number of cylinders | | | 12 |
| Engine dry weight (with attached standard accessories, without coupling) | R | kg | 8010 |

ACOUSTICS

| | | | |
|--|---|-------|-----------|
| Number of cylinders | | | 12 |
| Exhaust noise, undamped - BL (free-field sound-pressure level Lp, 1m distance, ISO 6798, +3dB(A) tolerance) | R | dB(A) | 115 |
| Engine surface noise with attenuated intake noise (filter), BL, (free-field sound-pressure level Lp, 1m distance, ISO 6798, +2dB(A) tolerance) | R | dB(A) | 104 |

3.2 ENGINE DATA 12V 4000M93, heat exchanger installed, IMO

Explanation:

- DL Ref. value: Continuous power
- BL Ref. value: Fuel stop power
- A Design value
- G Guaranteed value
- R Guideline value
- L Limit value, up to which the engine can be operated without changes (e.g. of power setting)
- N Not yet defined value
- Not applicable
- X Applicable

REFERENCE CONDITIONS

| | | | |
|-------------------------------|--|------|-----------------|
| Engine model | | | 12V 4000 M93 |
| Application group | | | 1DS |
| Intake air temperature | | °C | 25 |
| Raw water inlet temperature | | °C | 25 |
| Barometric pressure | | mbar | 1000 |
| Site altitude above sea level | | m | 100 |

POWER-RELATED DATA (power ratings are net brake power as per ISO 3046)

| | | | |
|--------------------------|---|-----|------|
| Number of cylinders | | | 12 |
| Rated engine speed | A | rpm | 2100 |
| Fuel stop power ISO 3046 | A | kW | 2340 |

GENERAL CONDITIONS (for maximum power)

| | | | |
|--------------------------------|---|------|----|
| Number of cylinders | | | 12 |
| Intake depression (new filter) | A | mbar | 15 |
| Intake depression, max. | L | mbar | 30 |

MODEL RELATED DATA (basic design)

| | | | |
|---------------------------------------|--|---------|-------|
| Number of cylinders | | | 12 |
| Cylinder arrangement: V angle | | Degrees | 90 |
| Bore | | mm | 170 |
| Stroke | | mm | 190 |
| Displacement per cylinder | | Liters | 4.31 |
| Displacement, total | | Liters | 51.72 |
| Number of inlet valves per cylinder | | | 2 |
| Number of exhaust valves per cylinder | | | 2 |

TIM-ID: 0000010911 - 001

RAW WATER CIRCUIT (open circuit)

| | | | |
|--|---|-----|------|
| Number of cylinders | | | 12 |
| Raw water pump: Inlet pressure, min. | L | bar | -0.2 |
| Raw water pump: Inlet pressure , max. | L | bar | 0.5 |
| Pressure loss in external raw water system, max. | L | bar | 0.7 |

LUBE OIL SYSTEM

| | | | |
|--|---|-----|-----|
| Number of cylinders | | | 12 |
| Lube oil operating temperature before engine, from | R | °C | 72* |
| Lube oil operating temperature before engine, to | R | °C | 80* |
| Lube oil operating pressure before engine, from | R | bar | 6 |
| Lube oil operating pressure before engine, to | R | bar | 8 |
| Lube oil operating pressure, low idle (meas. point: before engine) | R | bar | 2.0 |

FUEL SYSTEM

| | | | |
|---|---|-----------|------|
| Number of cylinders | | | 12 |
| Fuel pressure at engine supply connection, min. (when engine is starting) | L | bar | -0.1 |
| Fuel pressure at engine supply connection, min. (when engine is running) | L | bar | -0.3 |
| Fuel pressure at engine supply connection, max. (when engine is starting) | L | bar | 1.5 |
| Fuel supply flow, max. | R | liter/min | 30 |

GENERAL OPERATING DATA

| | | | |
|---------------------|---|-----|-----|
| Number of cylinders | | | 12 |
| Firing speed, from | R | rpm | 80 |
| Firing speed, to | R | rpm | 120 |

STARTING (electric)

| | | | |
|--|---|----|----|
| Number of cylinders | | | 12 |
| Starter, rated voltage (standard design) | R | V= | 24 |

STARTING (with compressed air/hydraulic starter)

| | | | |
|--|---|-----|----|
| Number of cylinders | | | 12 |
| Starting-air pressure before starter motor, min. | R | bar | 8 |
| Starting-air pressure before starter motor, max. | R | bar | 10 |

INCLINATIONS, STANDARD OIL SYSTEM (reference: waterline)

| | | | |
|---|---|---------|------|
| Number of cylinders | | | 12 |
| Longitudinal inclination, continuous max., driving end down (option: max. operating inclinations) | L | Degrees | 15 |
| Longitudinal inclination temporary max. drive side down (design: max. operating inclinations) | L | Degrees | 22.5 |

| | | | |
|---|---|---------|------|
| Number of cylinders | | | 12 |
| Longitudinal inclination, continuous max., driving end up (option: max. operating inclinations) | L | Degrees | 10 |
| Transverse inclination, constant max. (option: max. operating inclinations) | L | Degrees | 22.5 |

CAPACITIES

| | | | |
|--|---|--------|-----|
| Number of cylinders | | | 12 |
| Engine coolant, engine-side (with cooler) | R | Liters | 360 |
| Engine oil on initial filling (standard oil system) (option: max. operating inclinations) | R | Liters | 260 |
| Oil change quantity, max. (standard oil system) (option: max. operating inclinations) | R | Liters | 205 |
| Oil pan capacity at dipstick mark "min." (standard oil system) (option: max. operating inclinations) | L | Liters | 160 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (option: max. operating inclinations) | L | Liters | 200 |

WEIGHTS / MAIN DIMENSIONS

| | | | |
|--|---|----|------|
| Number of cylinders | | | 12 |
| Engine dry weight (with attached standard accessories, without coupling) | R | kg | 8010 |

ACOUSTICS

| | | | |
|--|---|-------|-----|
| Number of cylinders | | | 12 |
| Exhaust noise, undamped - BL (free-field sound-pressure level Lp, 1m distance, ISO 6798, +3dB(A) tolerance) | R | dB(A) | 115 |
| Engine surface noise with attenuated intake noise (filter), BL, (free-field sound-pressure level Lp, 1m distance, ISO 6798, +2dB(A) tolerance) | R | dB(A) | 104 |

3.3 ENGINE DATA 12V 4000M93L, heat exchanger installed, EPA stage 2

Explanation:

- DL Ref. value: Continuous power
- BL Ref. value: Fuel stop power
- A Design value
- G Guaranteed value
- R Guideline value
- L Limit value, up to which the engine can be operated without changes (e.g. of power setting)
- N Not yet defined value
- Not applicable
- X Applicable

REFERENCE CONDITIONS

| Engine model | | | 12V 4000 M93L |
|-------------------------------|--|------|------------------|
| Application group | | | 1DS |
| Intake air temperature | | °C | 25 |
| Raw water inlet temperature | | °C | 25 |
| Barometric pressure | | mbar | 1000 |
| Site altitude above sea level | | m | 100 |

POWER-RELATED DATA (power ratings are net brake power as per ISO 3046)

| Number of cylinders | | | 12 |
|--------------------------|---|-----|------|
| Rated engine speed | A | rpm | 2100 |
| Fuel stop power ISO 3046 | A | kW | 2580 |

GENERAL CONDITIONS (for maximum power)

| Number of cylinders | | | 12 |
|--------------------------------|---|------|----|
| Intake depression (new filter) | A | mbar | 15 |
| Intake depression, max. | L | mbar | 30 |

MODEL RELATED DATA (basic design)

| Number of cylinders | | | 12 |
|---------------------------------------|--|---------|-------|
| Cylinder arrangement: V angle | | Degrees | 90 |
| Bore | | mm | 170 |
| Stroke | | mm | 190 |
| Displacement per cylinder | | Liters | 4.31 |
| Displacement, total | | Liters | 51.72 |
| Number of inlet valves per cylinder | | | 2 |
| Number of exhaust valves per cylinder | | | 2 |

TIM-ID: 0000010954 - 001

RAW WATER CIRCUIT (open circuit)

| | | | |
|--|---|-----|------|
| Number of cylinders | | | 12 |
| Raw water pump: Inlet pressure, min. | L | bar | -0.2 |
| Raw water pump: Inlet pressure , max. | L | bar | 0.5 |
| Pressure loss in external raw water system, max. | L | bar | 0.7 |

LUBE OIL SYSTEM

| | | | |
|--|---|-----|-----|
| Number of cylinders | | | 12 |
| Lube oil operating temperature before engine, from | R | °C | 72* |
| Lube oil operating temperature before engine, to | R | °C | 80* |
| Lube oil operating pressure before engine, from | R | bar | 6 |
| Lube oil operating pressure before engine, to | R | bar | 8 |
| Lube oil operating pressure, low idle (meas. point: before engine) | R | bar | 2.0 |

FUEL SYSTEM

| | | | |
|---|---|-----------|------|
| Number of cylinders | | | 12 |
| Fuel pressure at engine supply connection, min. (when engine is starting) | L | bar | -0.1 |
| Fuel pressure at engine supply connection, min. (when engine is running) | L | bar | -0.3 |
| Fuel pressure at engine supply connection, max. (when engine is starting) | L | bar | 1.5 |
| Fuel supply flow, max. | R | liter/min | 30 |

GENERAL OPERATING DATA

| | | | |
|---------------------|---|-----|-----|
| Number of cylinders | | | 12 |
| Firing speed, from | R | rpm | 80 |
| Firing speed, to | R | rpm | 120 |

STARTING (electric)

| | | | |
|--|---|----|----|
| Number of cylinders | | | 12 |
| Starter, rated voltage (standard design) | R | V= | 24 |

STARTING (with compressed air/hydraulic starter)

| | | | |
|--|---|-----|----|
| Number of cylinders | | | 12 |
| Starting-air pressure before starter motor, min. | R | bar | 8 |
| Starting-air pressure before starter motor, max. | R | bar | 10 |

INCLINATIONS, STANDARD OIL SYSTEM (reference: waterline)

| | | | |
|---|---|---------|------|
| Number of cylinders | | | 12 |
| Longitudinal inclination, continuous max., driving end down (option: max. operating inclinations) | L | Degrees | 15 |
| Longitudinal inclination temporary max. drive side down (design: max. operating inclinations) | L | Degrees | 22.5 |

| | | | |
|---|---|---------|-----------|
| Number of cylinders | | | 12 |
| Longitudinal inclination, continuous max., driving end up (option: max. operating inclinations) | L | Degrees | 10 |
| Transverse inclination, constant max. (option: max. operating inclinations) | L | Degrees | 22.5 |

CAPACITIES

| | | | |
|--|---|--------|-----------|
| Number of cylinders | | | 12 |
| Engine coolant, engine-side (with cooler) | R | Liters | 360 |
| Engine oil on initial filling (standard oil system) (option: max. operating inclinations) | R | Liters | 260 |
| Oil change quantity, max. (standard oil system) (option: max. operating inclinations) | R | Liters | 205 |
| Oil pan capacity at dipstick mark "min." (standard oil system) (option: max. operating inclinations) | L | Liters | 160 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (option: max. operating inclinations) | L | Liters | 200 |

WEIGHTS / MAIN DIMENSIONS

| | | | |
|--|---|----|-----------|
| Number of cylinders | | | 12 |
| Engine dry weight (with attached standard accessories, without coupling) | R | kg | 8010 |

ACOUSTICS

| | | | |
|--|---|-------|-----------|
| Number of cylinders | | | 12 |
| Exhaust noise, undamped - BL (free-field sound-pressure level Lp, 1m distance, ISO 6798, +3dB(A) tolerance) | R | dB(A) | 116 |
| Engine surface noise with attenuated intake noise (filter), BL, (free-field sound-pressure level Lp, 1m distance, ISO 6798, +2dB(A) tolerance) | R | dB(A) | 105 |

3.4 ENGINE DATA 12V 4000M93L, heat exchanger installed, IMO

Explanation:

- DL Ref. value: Continuous power
- BL Ref. value: Fuel stop power
- A Design value
- G Guaranteed value
- R Guideline value
- L Limit value, up to which the engine can be operated without changes (e.g. of power setting)
- N Not yet defined value
- Not applicable
- X Applicable

REFERENCE CONDITIONS

| | | | |
|-------------------------------|--|------|------------------|
| Engine model | | | 12V 4000 M93L |
| Application group | | | 1DS |
| Intake air temperature | | °C | 25 |
| Raw water inlet temperature | | °C | 25 |
| Barometric pressure | | mbar | 1000 |
| Site altitude above sea level | | m | 100 |

POWER-RELATED DATA (power ratings are net brake power as per ISO 3046)

| | | | |
|--------------------------|---|-----|------|
| Number of cylinders | | | 12 |
| Rated engine speed | A | rpm | 2100 |
| Fuel stop power ISO 3046 | A | kW | 2580 |

GENERAL CONDITIONS (for maximum power)

| | | | |
|--------------------------------|---|------|----|
| Number of cylinders | | | 12 |
| Intake depression (new filter) | A | mbar | 15 |
| Intake depression, max. | L | mbar | 30 |

MODEL RELATED DATA (basic design)

| | | | |
|---------------------------------------|--|---------|-------|
| Number of cylinders | | | 12 |
| Cylinder arrangement: V angle | | Degrees | 90 |
| Bore | | mm | 170 |
| Stroke | | mm | 190 |
| Displacement per cylinder | | Liters | 4.31 |
| Displacement, total | | Liters | 51.72 |
| Number of inlet valves per cylinder | | | 2 |
| Number of exhaust valves per cylinder | | | 2 |

TIM-ID: 0000010940 - 001

RAW WATER CIRCUIT (open circuit)

| | | | |
|--|---|-----|------|
| Number of cylinders | | | 12 |
| Raw water pump: Inlet pressure, min. | L | bar | -0.2 |
| Raw water pump: Inlet pressure , max. | L | bar | 0.5 |
| Pressure loss in external raw water system, max. | L | bar | 0.7 |

LUBE OIL SYSTEM

| | | | |
|--|---|-----|-----|
| Number of cylinders | | | 12 |
| Lube oil operating temperature before engine, from | R | °C | 72* |
| Lube oil operating temperature before engine, to | R | °C | 80* |
| Lube oil operating pressure before engine, from | R | bar | 6 |
| Lube oil operating pressure before engine, to | R | bar | 8 |
| Lube oil operating pressure, low idle (meas. point: before engine) | R | bar | 2.0 |

FUEL SYSTEM

| | | | |
|---|---|-----------|------|
| Number of cylinders | | | 12 |
| Fuel pressure at engine supply connection, min. (when engine is starting) | L | bar | -0.1 |
| Fuel pressure at engine supply connection, min. (when engine is running) | L | bar | -0.3 |
| Fuel pressure at engine supply connection, max. (when engine is starting) | L | bar | 1.5 |
| Fuel supply flow, max. | R | liter/min | 30 |

GENERAL OPERATING DATA

| | | | |
|---------------------|---|-----|-----|
| Number of cylinders | | | 12 |
| Firing speed, from | R | rpm | 80 |
| Firing speed, to | R | rpm | 120 |

STARTING (electric)

| | | | |
|--|---|----|----|
| Number of cylinders | | | 12 |
| Starter, rated voltage (standard design) | R | V= | 24 |

STARTING (with compressed air/hydraulic starter)

| | | | |
|--|---|-----|----|
| Number of cylinders | | | 12 |
| Starting-air pressure before starter motor, min. | R | bar | 8 |
| Starting-air pressure before starter motor, max. | R | bar | 10 |

INCLINATIONS, STANDARD OIL SYSTEM (reference: waterline)

| | | | |
|---|---|---------|------|
| Number of cylinders | | | 12 |
| Longitudinal inclination, continuous max., driving end down (option: max. operating inclinations) | L | Degrees | 15 |
| Longitudinal inclination temporary max. drive side down (design: max. operating inclinations) | L | Degrees | 22.5 |

| | | | |
|---|---|---------|------|
| Number of cylinders | | | 12 |
| Longitudinal inclination, continuous max., driving end up (option: max. operating inclinations) | L | Degrees | 10 |
| Transverse inclination, constant max. (option: max. operating inclinations) | L | Degrees | 22.5 |

CAPACITIES

| | | | |
|--|---|--------|-----|
| Number of cylinders | | | 12 |
| Engine coolant, engine-side (with cooler) | R | Liters | 360 |
| Engine oil on initial filling (standard oil system) (option: max. operating inclinations) | R | Liters | 260 |
| Oil change quantity, max. (standard oil system) (option: max. operating inclinations) | R | Liters | 205 |
| Oil pan capacity at dipstick mark "min." (standard oil system) (option: max. operating inclinations) | L | Liters | 160 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (option: max. operating inclinations) | L | Liters | 200 |

WEIGHTS / MAIN DIMENSIONS

| | | | |
|--|---|----|------|
| Number of cylinders | | | 12 |
| Engine dry weight (with attached standard accessories, without coupling) | R | kg | 8010 |

ACOUSTICS

| | | | |
|--|---|-------|-----|
| Number of cylinders | | | 12 |
| Exhaust noise, undamped - BL (free-field sound-pressure level Lp, 1m distance, ISO 6798, +3dB(A) tolerance) | R | dB(A) | 116 |
| Engine surface noise with attenuated intake noise (filter), BL, (free-field sound-pressure level Lp, 1m distance, ISO 6798, +2dB(A) tolerance) | R | dB(A) | 105 |

3.5 ENGINE DATA 16V 4000M93, heat exchanger installed, EPA stage 2

Explanation:

- DL Ref. value: Continuous power
- BL Ref. value: Fuel stop power
- A Design value
- G Guaranteed value
- R Guideline value
- L Limit value, up to which the engine can be operated without changes (e.g. of power setting)
- N Not yet defined value
- Not applicable
- X Applicable

REFERENCE CONDITIONS

| | | | |
|-------------------------------|--|------|-----------------|
| Engine model | | | 16V 4000 M93 |
| Application group | | | 1DS |
| Intake air temperature | | °C | 25 |
| Raw water inlet temperature | | °C | 25 |
| Barometric pressure | | mbar | 1000 |
| Site altitude above sea level | | m | 100 |

POWER-RELATED DATA (power ratings are net brake power as per ISO 3046)

| | | | |
|--------------------------|---|-----|------|
| Number of cylinders | | | 16 |
| Rated engine speed | A | rpm | 2100 |
| Fuel stop power ISO 3046 | A | kW | 3120 |

GENERAL CONDITIONS (for maximum power)

| | | | |
|--------------------------------|---|------|----|
| Number of cylinders | | | 16 |
| Intake depression (new filter) | A | mbar | 15 |
| Intake depression, max. | L | mbar | 30 |

MODEL RELATED DATA (basic design)

| | | | |
|---------------------------------------|--|---------|-------|
| Number of cylinders | | | 16 |
| Cylinder arrangement: V angle | | Degrees | 90 |
| Bore | | mm | 170 |
| Stroke | | mm | 190 |
| Displacement per cylinder | | Liters | 4.31 |
| Displacement, total | | Liters | 68.96 |
| Number of inlet valves per cylinder | | | 2 |
| Number of exhaust valves per cylinder | | | 2 |

TIM-ID: 0000010971 - 002

RAW WATER CIRCUIT (open circuit)

| | | | |
|--|---|-----|------|
| Number of cylinders | | | 16 |
| Raw water pump: Inlet pressure, min. | L | bar | -0.2 |
| Raw water pump: Inlet pressure , max. | L | bar | 0.5 |
| Pressure loss in external raw water system, max. | L | bar | 0.7 |

LUBE OIL SYSTEM

| | | | |
|--|---|-----|-----|
| Number of cylinders | | | 16 |
| Lube oil operating temperature before engine, from | R | °C | 72* |
| Lube oil operating temperature before engine, to | R | °C | 80* |
| Lube oil operating pressure before engine, from | R | bar | 6 |
| Lube oil operating pressure before engine, to | R | bar | 8 |
| Lube oil operating pressure, low idle (meas. point: before engine) | R | bar | 2.0 |

FUEL SYSTEM

| | | | |
|---|---|-----------|------|
| Number of cylinders | | | 16 |
| Fuel pressure at engine supply connection, min. (when engine is starting) | L | bar | -0.1 |
| Fuel pressure at engine supply connection, min. (when engine is running) | L | bar | -0.3 |
| Fuel pressure at engine supply connection, max. (when engine is starting) | L | bar | 1.5 |
| Fuel supply flow, max. | R | liter/min | 30 |

GENERAL OPERATING DATA

| | | | |
|---------------------|---|-----|-----|
| Number of cylinders | | | 16 |
| Firing speed, from | R | rpm | 80 |
| Firing speed, to | R | rpm | 120 |

STARTING (electric)

| | | | |
|--|---|----|----|
| Number of cylinders | | | 16 |
| Starter, rated voltage (standard design) | R | V= | 24 |

STARTING (with compressed air/hydraulic starter)

| | | | |
|--|---|-----|----|
| Number of cylinders | | | 16 |
| Starting-air pressure before starter motor, min. | R | bar | 8 |
| Starting-air pressure before starter motor, max. | R | bar | 10 |

INCLINATIONS, STANDARD OIL SYSTEM (reference: waterline)

| | | | |
|---|---|---------|------|
| Number of cylinders | | | 16 |
| Longitudinal inclination, continuous max., driving end down (option: max. operating inclinations) | L | Degrees | 15 |
| Longitudinal inclination temporary max. drive side down (design: max. operating inclinations) | L | Degrees | 22.5 |

| | | | |
|---|---|---------|-----------|
| Number of cylinders | | | 16 |
| Longitudinal inclination, continuous max., driving end up (option: max. operating inclinations) | L | Degrees | 10 |
| Transverse inclination, constant max. (option: max. operating inclinations) | L | Degrees | 22.5 |

CAPACITIES

| | | | |
|--|---|--------|-----------|
| Number of cylinders | | | 16 |
| Engine coolant, engine-side (with cooler) | R | Liters | 540 |
| Engine oil on initial filling (standard oil system) (option: max. operating inclinations) | R | Liters | 320 |
| Oil change quantity, max. (standard oil system) (option: max. operating inclinations) | R | Liters | 270 |
| Oil pan capacity at dipstick mark "min." (standard oil system) (option: max. operating inclinations) | L | Liters | 215 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (option: max. operating inclinations) | L | Liters | 260 |

WEIGHTS / MAIN DIMENSIONS

| | | | |
|--|---|----|-----------|
| Number of cylinders | | | 16 |
| Engine dry weight (with attached standard accessories, without coupling) | R | kg | 9600 |

ACOUSTICS

| | | | |
|--|---|-------|-----------|
| Number of cylinders | | | 16 |
| Exhaust noise, undamped - BL (free-field sound-pressure level Lp, 1m distance, ISO 6798, +3dB(A) tolerance) | R | dB(A) | 116 |
| Engine surface noise with attenuated intake noise (filter), BL, (free-field sound-pressure level Lp, 1m distance, ISO 6798, +2dB(A) tolerance) | R | dB(A) | 105 |

3.6 ENGINE DATA 16V 4000M93, heat exchanger installed, IMO

Explanation:

- DL Ref. value: Continuous power
- BL Ref. value: Fuel stop power
- A Design value
- G Guaranteed value
- R Guideline value
- L Limit value, up to which the engine can be operated without changes (e.g. of power setting)
- N Not yet defined value
- Not applicable
- X Applicable

REFERENCE CONDITIONS

| | | | |
|-------------------------------|--|------|-----------------|
| Engine model | | | 16V 4000 M93 |
| Application group | | | 1DS |
| Intake air temperature | | °C | 25 |
| Raw water inlet temperature | | °C | 25 |
| Barometric pressure | | mbar | 1000 |
| Site altitude above sea level | | m | 100 |

POWER-RELATED DATA (power ratings are net brake power as per ISO 3046)

| | | | |
|--------------------------|---|-----|------|
| Number of cylinders | | | 16 |
| Rated engine speed | A | rpm | 2100 |
| Fuel stop power ISO 3046 | A | kW | 3120 |

GENERAL CONDITIONS (for maximum power)

| | | | |
|--------------------------------|---|------|----|
| Number of cylinders | | | 16 |
| Intake depression (new filter) | A | mbar | 15 |
| Intake depression, max. | L | mbar | 30 |

MODEL RELATED DATA (basic design)

| | | | |
|---------------------------------------|--|---------|-------|
| Number of cylinders | | | 16 |
| Cylinder arrangement: V angle | | Degrees | 90 |
| Bore | | mm | 170 |
| Stroke | | mm | 190 |
| Displacement per cylinder | | Liters | 4.31 |
| Displacement, total | | Liters | 68.96 |
| Number of inlet valves per cylinder | | | 2 |
| Number of exhaust valves per cylinder | | | 2 |

TIM-ID: 0000010963 - 002

RAW WATER CIRCUIT (open circuit)

| | | | |
|--|---|-----|------|
| Number of cylinders | | | 16 |
| Raw water pump: Inlet pressure, min. | L | bar | -0.2 |
| Raw water pump: Inlet pressure , max. | L | bar | 0.5 |
| Pressure loss in external raw water system, max. | L | bar | 0.7 |

LUBE OIL SYSTEM

| | | | |
|--|---|-----|-----|
| Number of cylinders | | | 16 |
| Lube oil operating temperature before engine, from | R | °C | 72* |
| Lube oil operating temperature before engine, to | R | °C | 80* |
| Lube oil operating pressure before engine, from | R | bar | 6 |
| Lube oil operating pressure before engine, to | R | bar | 8 |
| Lube oil operating pressure, low idle (meas. point: before engine) | R | bar | 2.0 |

FUEL SYSTEM

| | | | |
|---|---|-----------|------|
| Number of cylinders | | | 16 |
| Fuel pressure at engine supply connection, min. (when engine is starting) | L | bar | -0.1 |
| Fuel pressure at engine supply connection, min. (when engine is running) | L | bar | -0.3 |
| Fuel pressure at engine supply connection, max. (when engine is starting) | L | bar | 1.5 |
| Fuel supply flow, max. | R | liter/min | 30 |

GENERAL OPERATING DATA

| | | | |
|---------------------|---|-----|-----|
| Number of cylinders | | | 16 |
| Firing speed, from | R | rpm | 80 |
| Firing speed, to | R | rpm | 120 |

STARTING (electric)

| | | | |
|--|---|----|----|
| Number of cylinders | | | 16 |
| Starter, rated voltage (standard design) | R | V= | 24 |

STARTING (with compressed air/hydraulic starter)

| | | | |
|--|---|-----|----|
| Number of cylinders | | | 16 |
| Starting-air pressure before starter motor, min. | R | bar | 8 |
| Starting-air pressure before starter motor, max. | R | bar | 10 |

INCLINATIONS, STANDARD OIL SYSTEM (reference: waterline)

| | | | |
|---|---|---------|------|
| Number of cylinders | | | 16 |
| Longitudinal inclination, continuous max., driving end down (option: max. operating inclinations) | L | Degrees | 15 |
| Longitudinal inclination temporary max. drive side down (design: max. operating inclinations) | L | Degrees | 22.5 |

| | | | |
|---|---|---------|------|
| Number of cylinders | | | 16 |
| Longitudinal inclination, continuous max., driving end up (option: max. operating inclinations) | L | Degrees | 10 |
| Transverse inclination, constant max. (option: max. operating inclinations) | L | Degrees | 22.5 |

CAPACITIES

| | | | |
|--|---|--------|-----|
| Number of cylinders | | | 16 |
| Engine coolant, engine-side (with cooler) | R | Liters | 540 |
| Engine oil on initial filling (standard oil system) (option: max. operating inclinations) | R | Liters | 320 |
| Oil change quantity, max. (standard oil system) (option: max. operating inclinations) | R | Liters | 270 |
| Oil pan capacity at dipstick mark "min." (standard oil system) (option: max. operating inclinations) | L | Liters | 215 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (option: max. operating inclinations) | L | Liters | 260 |

WEIGHTS / MAIN DIMENSIONS

| | | | |
|--|---|----|------|
| Number of cylinders | | | 16 |
| Engine dry weight (with attached standard accessories, without coupling) | R | kg | 9600 |

ACOUSTICS

| | | | |
|--|---|-------|-----|
| Number of cylinders | | | 16 |
| Exhaust noise, undamped - BL (free-field sound-pressure level Lp, 1m distance, ISO 6798, +3dB(A) tolerance) | R | dB(A) | 116 |
| Engine surface noise with attenuated intake noise (filter), BL, (free-field sound-pressure level Lp, 1m distance, ISO 6798, +2dB(A) tolerance) | R | dB(A) | 105 |

3.7 ENGINE DATA 16V 4000M93L, heat exchanger installed, EPA stage 2

Explanation:

- DL Ref. value: Continuous power
- BL Ref. value: Fuel stop power
- A Design value
- G Guaranteed value
- R Guideline value
- L Limit value, up to which the engine can be operated without changes (e.g. of power setting)
- N Not yet defined value
- Not applicable
- X Applicable

REFERENCE CONDITIONS

| Engine model | | | 16V 4000 M93L |
|-------------------------------|--|------|---------------|
| Application group | | | 1DS |
| Intake air temperature | | °C | 25 |
| Raw water inlet temperature | | °C | 25 |
| Barometric pressure | | mbar | 1000 |
| Site altitude above sea level | | m | 100 |

POWER-RELATED DATA (power ratings are net brake power as per ISO 3046)

| Number of cylinders | | | 16 |
|--------------------------|---|-----|------|
| Rated engine speed | A | rpm | 2100 |
| Fuel stop power ISO 3046 | A | kW | 3440 |

GENERAL CONDITIONS (for maximum power)

| Number of cylinders | | | 16 |
|--------------------------------|---|------|----|
| Intake depression (new filter) | A | mbar | 15 |
| Intake depression, max. | L | mbar | 30 |

MODEL RELATED DATA (basic design)

| Number of cylinders | | | 16 |
|---------------------------------------|--|---------|-------|
| Cylinder arrangement: V angle | | Degrees | 90 |
| Bore | | mm | 170 |
| Stroke | | mm | 190 |
| Displacement per cylinder | | Liters | 4.31 |
| Displacement, total | | Liters | 68.96 |
| Number of inlet valves per cylinder | | | 2 |
| Number of exhaust valves per cylinder | | | 2 |

TIM-ID: 0000010964 - 002

RAW WATER CIRCUIT (open circuit)

| | | | |
|--|---|-----|------|
| Number of cylinders | | | 16 |
| Raw water pump: Inlet pressure, min. | L | bar | -0.2 |
| Raw water pump: Inlet pressure , max. | L | bar | 0.5 |
| Pressure loss in external raw water system, max. | L | bar | 0.7 |

LUBE OIL SYSTEM

| | | | |
|--|---|-----|-----|
| Number of cylinders | | | 16 |
| Lube oil operating temperature before engine, from | R | °C | 72* |
| Lube oil operating temperature before engine, to | R | °C | 80* |
| Lube oil operating pressure before engine, from | R | bar | 6 |
| Lube oil operating pressure before engine, to | R | bar | 8 |
| Lube oil operating pressure, low idle (meas. point: before engine) | R | bar | 2.0 |

FUEL SYSTEM

| | | | |
|---|---|-----------|------|
| Number of cylinders | | | 16 |
| Fuel pressure at engine supply connection, min. (when engine is starting) | L | bar | -0.1 |
| Fuel pressure at engine supply connection, min. (when engine is running) | L | bar | -0.3 |
| Fuel pressure at engine supply connection, max. (when engine is starting) | L | bar | 1.5 |
| Fuel supply flow, max. | R | liter/min | 30 |

GENERAL OPERATING DATA

| | | | |
|---------------------|---|-----|-----|
| Number of cylinders | | | 16 |
| Firing speed, from | R | rpm | 80 |
| Firing speed, to | R | rpm | 120 |

STARTING (electric)

| | | | |
|--|---|----|----|
| Number of cylinders | | | 16 |
| Starter, rated voltage (standard design) | R | V= | 24 |

STARTING (with compressed air/hydraulic starter)

| | | | |
|--|---|-----|----|
| Number of cylinders | | | 16 |
| Starting-air pressure before starter motor, min. | R | bar | 8 |
| Starting-air pressure before starter motor, max. | R | bar | 10 |

INCLINATIONS, STANDARD OIL SYSTEM (reference: waterline)

| | | | |
|---|---|---------|------|
| Number of cylinders | | | 16 |
| Longitudinal inclination, continuous max., driving end down (option: max. operating inclinations) | L | Degrees | 15 |
| Longitudinal inclination temporary max. drive side down (design: max. operating inclinations) | L | Degrees | 22.5 |

| | | | |
|---|---|---------|-----------|
| Number of cylinders | | | 16 |
| Longitudinal inclination, continuous max., driving end up (option: max. operating inclinations) | L | Degrees | 10 |
| Transverse inclination, constant max. (option: max. operating inclinations) | L | Degrees | 22.5 |

CAPACITIES

| | | | |
|--|---|--------|-----------|
| Number of cylinders | | | 16 |
| Engine coolant, engine-side (with cooler) | R | Liters | 540 |
| Engine oil on initial filling (standard oil system) (option: max. operating inclinations) | R | Liters | 320 |
| Oil change quantity, max. (standard oil system) (option: max. operating inclinations) | R | Liters | 270 |
| Oil pan capacity at dipstick mark "min." (standard oil system) (option: max. operating inclinations) | L | Liters | 215 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (option: max. operating inclinations) | L | Liters | 260 |

WEIGHTS / MAIN DIMENSIONS

| | | | |
|--|---|----|-----------|
| Number of cylinders | | | 16 |
| Engine dry weight (with attached standard accessories, without coupling) | R | kg | 9600 |

ACOUSTICS

| | | | |
|--|---|-------|-----------|
| Number of cylinders | | | 16 |
| Exhaust noise, undamped - BL (free-field sound-pressure level Lp, 1m distance, ISO 6798, +3dB(A) tolerance) | R | dB(A) | 117 |
| Engine surface noise with attenuated intake noise (filter), BL, (free-field sound-pressure level Lp, 1m distance, ISO 6798, +2dB(A) tolerance) | R | dB(A) | 106 |

3.8 ENGINE DATA 16V 4000M93L, heat exchanger installed, IMO

Explanation:

- DL Ref. value: Continuous power
- BL Ref. value: Fuel stop power
- A Design value
- G Guaranteed value
- R Guideline value
- L Limit value, up to which the engine can be operated without changes (e.g. of power setting)
- N Not yet defined value
- Not applicable
- X Applicable

REFERENCE CONDITIONS

| | | | |
|-------------------------------|--|------|------------------|
| Engine model | | | 16V 4000 M93L |
| Application group | | | 1DS |
| Intake air temperature | | °C | 25 |
| Raw water inlet temperature | | °C | 25 |
| Barometric pressure | | mbar | 1000 |
| Site altitude above sea level | | m | 100 |

POWER-RELATED DATA (power ratings are net brake power as per ISO 3046)

| | | | |
|--------------------------|---|-----|------|
| Number of cylinders | | | 16 |
| Rated engine speed | A | rpm | 2100 |
| Fuel stop power ISO 3046 | A | kW | 3440 |

GENERAL CONDITIONS (for maximum power)

| | | | |
|--------------------------------|---|------|----|
| Number of cylinders | | | 16 |
| Intake depression (new filter) | A | mbar | 15 |
| Intake depression, max. | L | mbar | 30 |

MODEL RELATED DATA (basic design)

| | | | |
|---------------------------------------|--|---------|-------|
| Number of cylinders | | | 16 |
| Cylinder arrangement: V angle | | Degrees | 90 |
| Bore | | mm | 170 |
| Stroke | | mm | 190 |
| Displacement per cylinder | | Liters | 4.31 |
| Displacement, total | | Liters | 68.96 |
| Number of inlet valves per cylinder | | | 2 |
| Number of exhaust valves per cylinder | | | 2 |

TIM-ID: 0000010978 - 002

RAW WATER CIRCUIT (open circuit)

| | | | |
|--|---|-----|------|
| Number of cylinders | | | 16 |
| Raw water pump: Inlet pressure, min. | L | bar | -0.2 |
| Raw water pump: Inlet pressure , max. | L | bar | 0.5 |
| Pressure loss in external raw water system, max. | L | bar | 0.7 |

LUBE OIL SYSTEM

| | | | |
|--|---|-----|-----|
| Number of cylinders | | | 16 |
| Lube oil operating temperature before engine, from | R | °C | 72* |
| Lube oil operating temperature before engine, to | R | °C | 80* |
| Lube oil operating pressure before engine, from | R | bar | 6 |
| Lube oil operating pressure before engine, to | R | bar | 8 |
| Lube oil operating pressure, low idle (meas. point: before engine) | R | bar | 2.0 |

FUEL SYSTEM

| | | | |
|---|---|-----------|------|
| Number of cylinders | | | 16 |
| Fuel pressure at engine supply connection, min. (when engine is starting) | L | bar | -0.1 |
| Fuel pressure at engine supply connection, min. (when engine is running) | L | bar | -0.3 |
| Fuel pressure at engine supply connection, max. (when engine is starting) | L | bar | 1.5 |
| Fuel supply flow, max. | R | liter/min | 30 |

GENERAL OPERATING DATA

| | | | |
|---------------------|---|-----|-----|
| Number of cylinders | | | 16 |
| Firing speed, from | R | rpm | 80 |
| Firing speed, to | R | rpm | 120 |

STARTING (electric)

| | | | |
|--|---|----|----|
| Number of cylinders | | | 16 |
| Starter, rated voltage (standard design) | R | V= | 24 |

STARTING (with compressed air/hydraulic starter)

| | | | |
|--|---|-----|----|
| Number of cylinders | | | 16 |
| Starting-air pressure before starter motor, min. | R | bar | 8 |
| Starting-air pressure before starter motor, max. | R | bar | 10 |

INCLINATIONS, STANDARD OIL SYSTEM (reference: waterline)

| | | | |
|---|---|---------|------|
| Number of cylinders | | | 16 |
| Longitudinal inclination, continuous max., driving end down (option: max. operating inclinations) | L | Degrees | 15 |
| Longitudinal inclination temporary max. drive side down (design: max. operating inclinations) | L | Degrees | 22.5 |

| | | | |
|---|---|---------|------|
| Number of cylinders | | | 16 |
| Longitudinal inclination, continuous max., driving end up (option: max. operating inclinations) | L | Degrees | 10 |
| Transverse inclination, constant max. (option: max. operating inclinations) | L | Degrees | 22.5 |

CAPACITIES

| | | | |
|--|---|--------|-----|
| Number of cylinders | | | 16 |
| Engine coolant, engine-side (with cooler) | R | Liters | 540 |
| Engine oil on initial filling (standard oil system) (option: max. operating inclinations) | R | Liters | 320 |
| Oil change quantity, max. (standard oil system) (option: max. operating inclinations) | R | Liters | 270 |
| Oil pan capacity at dipstick mark "min." (standard oil system) (option: max. operating inclinations) | L | Liters | 215 |
| Oil pan capacity at dipstick mark "max." (standard oil system) (option: max. operating inclinations) | L | Liters | 260 |

WEIGHTS / MAIN DIMENSIONS


| | | | |
|--|---|----|------|
| Number of cylinders | | | 16 |
| Engine dry weight (with attached standard accessories, without coupling) | R | kg | 9600 |

ACOUSTICS

| | | | |
|--|---|-------|-----|
| Number of cylinders | | | 16 |
| Exhaust noise, undamped - BL (free-field sound-pressure level Lp, 1m distance, ISO 6798, +3dB(A) tolerance) | R | dB(A) | 117 |
| Engine surface noise with attenuated intake noise (filter), BL, (free-field sound-pressure level Lp, 1m distance, ISO 6798, +2dB(A) tolerance) | R | dB(A) | 106 |

3.9 Engine - Main dimensions

Engine - Main dimensions



| Engine model | Length (A) | Width (B) | Height (C) |
|----------------------|-----------------|-----------------|-----------------|
| 12 V 4000 M73/93 (L) | approx. 2991 mm | approx. 1463 mm | approx. 2368 mm |
| 16 V 4000 M73/93 (L) | approx. 3583 mm | approx. 1463 mm | approx. 2368 mm |
| 20 V 4000 M73/93 (L) | approx. 4192 mm | approx. 1484 mm | approx. 2368 mm |

3.10 Firing order


Firing order

| Number of cylinders | Firing order |
|---------------------|---|
| 8V | A1-B4-A4-A2-B3-A3-B2-B1 |
| 12V | A1-B5-A5-B3-A3-B6-A6-B2-A2-B4-A4-B1 |
| 16 V | A1-A7-B4-B6-A4-B8-A2-A8-B3-B5-A3-A5-B2-A6-B1-B7 |
| 20 V | A1-B5-A8-B7-A5-B2-A7-B10-A2-B3-A10-B6-A3-B4-A6-B9-A4-B1-A9-B8 |

4 Operation

4.1 LOP - Controls

LOP - Controls



| Item | Color | Inscription | Meaning / Function |
|------|-------|---------------|---|
| 1 | White | F1 | Function keys to control the man-machine interface. Functions vary and are displayed on the LCD screen. |
| 2 | White | F2 | |
| 3 | White | F3 | |
| 4 | White | F4 | |
| 5 | White | F5 | |
| 6 | White | ALARM ACKNOWL | Pressing the button the first time stops alarm signalization. Pressing the button a second time acknowledges an active alarm. LED (spot) lights up when an alarm is active. |
| 7 | White | DIM ↑ | Holding down the button increases LCD background illumination. |
| 8 | White | DIM ↓ | Holding down the button decreases LCD background illumination. |

TIM-ID: 000-000861 - 002

| Item | Color | Inscription | Meaning / Function |
|------|-------|---|---|
| 9 | White | LAMP TEST | Pressing the button initiates lamp test. |
| 10 | Red | TEST OVERSPEED | Pressing the button initiates overspeed test. LED (spot) lights up as long as the overspeed test is running. |
| 11 | Green | (depending on type of gearbox and propulsion) | FPP: Pressing the button engages gear ahead. CPP, WJ, VS: Pressing the button engages clutch. LED (spot) lights up when GCU feedback is active. |
| 12 | Green | | FPP, CPP, WJ, VS: Pressing the button disengages clutch. LED (spot) lights up when GCU feedback is active. |
| 13 | Green | | FPP: Pressing the button engages gear astern. CPP, VS: No function assigned. WJ: Holding down the button provides flushing of water jet intake channel (water-jet reverse) . LED (spot) lights up when GCU feedback is active. |
| 14 | White | ENGINE SPEED INCREASE | Engine speed is increased as long as the button is held down. |
| 15 | White | ENGINE SPEED DECREASE | Engine speed is decreased as long as the button is held down. |
| 16 | Green | READY FOR OPERATION | Pressing the button switches between "Not ready for operation" and "Ready for operation". LED (spot) is illuminated when the button is in the "Ready for operation" position. |
| 17 | Green | LOCAL CONTROL | Pressing the button switches between local operation and remote control. LED (spot) lights up when local mode is active. |
| 18 | White | START | Pressing the button initiates the automatic engine start sequence. LED (spot) lights up as long as the starting procedure is running. |
| 19 | White | STOP | Pressing the button initiates automatic engine stopping procedure. LED (spot) lights up as long as the STOP signal is available (also if transmitted from RCS). |
| 20 | Red | EMERGENCY STOP | Pressing the button initiates an immediate emergency engine stop. LED (spot) flashes once the emergency stop has been tripped and until the alarm has been acknowledged. |

4.2 Putting the engine into operation after extended out-of-service periods (>3 months)

Preconditions

- ☑ Engine is stopped and starting disabled.
- ☑ MTU Fluids and Lubricants Specifications (A001061/..) are available.

Putting into operation after extended out-of-service periods (>3 months)

| Item | Action |
|---|---|
| Engine | Depreserve (→ MTU Fluids and Lubricants Specifications A001061/..). |
| Lube oil system | Check engine oil level (→ Page 162); Preheat engine oil if required. Lubricate valve gear (→ Page 133). |
| Raw water pump (if located above waterline) | Fill with water (approx. 3 – 4 liters). |
| Coolant circuit | If engine is out of service for more than one year, change coolant (→ Page 177). |
| Coolant circuit | Check coolant level (→ Page 176). |
| Coolant circuit | Heat coolant with coolant preheating unit. |
| HP fuel pump | Only for engines without oil priming pump Fill HP fuel pump with new engine oil (→ Page 139). |
| Engine control system | Switch master switch to ON; Press illuminated pushbutton READY FOR OPERATION (→ Page 69). |
| Engine Control Unit ECU | Check plug connections (→ Page 198). |
| EIM | Check plug connections (→ Page 200). |
| EMU 8 | Check plug connections (→ Page 199). |
| LOP | Press illuminated pushbutton LAMP TEST (→ Page 69). |

4.3 Putting the engine into operation after scheduled out-of-service-period

Preconditions

- Engine is stopped and starting disabled.



Putting into operation

| Item | Action |
|-----------------------|--|
| Lube oil system | Check engine oil level (→ Page 162); Preheat engine oil if required. |
| Coolant circuit | Check coolant level (→ Page 176). |
| Coolant circuit | Heat coolant with coolant preheating unit. |
| Engine control system | Switch master switch to ON; Press illuminated pushbutton READY FOR OPERATION (→ Page 69). |
| LOP | Press illuminated pushbutton LAMP TEST (→ Page 69). |
| ECU | Check plug connections (→ Page 198). |
| EIM | Check plug connections (→ Page 200). |
| EMU 8 | Check plug connections (→ Page 199). |

4.4 Starting the engine

Preconditions

- External start interlock is not active.
- Emergency air shut-off flaps (if fitted) are open.

| | |
|---|---|
| DANGER  | Rotating and moving engine parts. Risk of crushing, danger of parts of the body being caught or pulled in! <ul style="list-style-type: none">• Before cranking the engine with starter system, make sure that there are no persons in the engine's danger zone. |
| WARNING  | High level of engine noise when the engine is running. Risk of damage to hearing! <ul style="list-style-type: none">• Wear ear protectors. |

The engine can be started from the following points

| Item | Action |
|-----------------------------|--|
| Control stand | (→ Operating instructions for electronic system) |
| Local Operating Panel LOP | (→ Operating instructions for electronic system) |
| Local Operation Station LOS | (→ Operating instructions for electronic system) |
| CCU | (→ Operating instructions for electronic system) |


4.5 Operational checks

| | |
|---------|--|
| DANGER | <p>Rotating and moving engine parts.</p> <p>Risk of crushing, danger of parts of the body being caught or pulled in!</p> <ul style="list-style-type: none"> • Only run the engine at low power. Keep away from the engine's danger zone. |
| WARNING | <p>High level of engine noise when the engine is running.</p> <p>Risk of damage to hearing!</p> <ul style="list-style-type: none"> • Wear ear protectors. |

Operational checks

| Item | Action |
|--|--|
| Engine oil | Check engine oil level (→ Page 162). |
| Engine under load, engine at nominal speed | Visually inspect engine for leaks and general condition; Check speed, pressures and temperatures; Check engine and external lines for leaks; Check for abnormal running noises and vibration; Check exhaust color (→ Page 97). |
| Air filter | Check signal ring position of service indicator (→ Page 160); Replace air filter (→ Page 158) if the signal ring is completely visible in the service indicator observation window. |
| Intercooler | Check condensate drain(s) for water discharge and obstruction (→ Page 157). |
| Exhaust gas system | Check condensate drain for obstructions. |
| Fuel prefilter(s) | Drain water and contamination from fuel prefilter (if fitted) (→ Page 150). Check pointer position of differential pressure gage at fuel prefilter (if applicable). |
| HT coolant pump | Check relief bore for oil and coolant discharge and contamination (→ Page 181). |
| Raw water pump | Check relief bore for oil and water discharge and contamination (→ Page 183). |

4.6 Fuel treatment system control cabinet - Control elements



| No. | Color | Caption | Meaning/Function |
|-----|--------|--------------------|---|
| 1 | Green | Signal lamp | Indicates „Pump running“ |
| 2 | Red | Signal lamp | Indicates „Pump fault“ |
| 3 | Yellow | Illuminated button | Indicates „Water drain“ / Press to drain water manually. |
| 4 | Red | Illuminated button | Indicates „Water alarm“ / Press to acknowledge. |
| 5 | Yellow | Signal lamp | Indicates „Filter warning“ due to increased differential pressure. |
| 6 | Red | Illuminated button | Indicates „Replace filter element“ / Press to acknowledge. |
| 7 | | Switch | Pump operating mode “Remote- 0 - Manual” <ul style="list-style-type: none"> • Switch position “Remote”: Pump is controlled at LOP • Switch position “0”: Pump is switched OFF • Switch position “Manual”: Pump is started manually |
| 8 | White | Signal lamp | Indicates „Control voltage present“. |
| 9 | | Hour meter | Indicates runtime of pump. |
| 10 | | Master switch | |

4.7 Tasks after extended out-of-service periods (>3 weeks)

Tasks after extended out-of-service periods (>3 weeks)

Note: Operate fuel treatment system for at least 5 minutes.

1. Start up fuel treatment system (→ Page 78).
2. Shut down fuel treatment system (→ Page 92).


4.8 Checks prior to start-up

Checks prior to start-up

1. Check tank and the entire pipework for cleanness. If microorganisms are detected:
 - a) Clean affected components.
 - b) Disinfect affected components with biocides (→ MTU Fluids and Lubricants Specifications A001061/..).
 2. Close drain valves on housing.
 3. Open all supply and discharge valves.
 4. Switch on fuel treatment system (→ Page 81).
 5. Check direction of rotation of pump.
 6. Vent bypass and fuel lines of the system.
 - a) Open ball valve for pressure tank.
 - b) Open ball valve for overflow tank.
 - c) Close ball valve at the inlet to the fuel treatment system.
- Result: Bypass line is vented via the overflow tank.
7. Check the fuel treatment system for leaks.
- Result: The fuel treatment system is ready for operation.

4.9 Fuel treatment system - Putting into operation

Overview of fuel treatment system



- | | | |
|----------------------------------|---------------------------------|---|
| 1 Pressure-free overflow | 9 Ball valve, outlet | 17 Automatic water drain |
| 2 Bypass 1 | 10 Check valve 700 mbar | 18 Water level electrode |
| 3 Bypass 2 | 11 Check valve 5 mbar | 19 Ball valve, sample extraction, inlet |
| 4 Safety valve, 3 bar | 12 Return to overflow container | 20 Switchgear cabinet |
| 5 Ball valve, inlet | 13 Engine | 21 Pump |
| 6 Pressure gage | 14 Overflow container | 22 Coarse filter |
| 7 Ventilation, sample extraction | 15 Water separator filter | 23 Fuel supply from tank |
| 8 Differential pressure gage | 16 Ball valve, drain | 24 Tank |

Switching on fuel treatment system

1. Switch on fuel treatment system (→ Page 81).
2. Check differential pressure at differential pressure gage (8). Differential pressure in a new system: 0.1 bar to 0.3 bar.

Result: If no differential pressure is measured, the coalescer filter element is probably being bypassed.

1. Remove coalescer filter element (→ Page 191).
2. Check sealing surfaces on coalescer filter element and in the pressure tank.

Initial operation: HAT

1. Replace fuel filter on engine (→ Page 147).

Note: Determine the suction pressure upstream of the engine-mounted fuel delivery pump.

2. Install pressure gage in fuel supply line from Yard fuel system to engine.
3. Switch on fuel treatment system and operate it for some minutes (→ Page 81).

Result: The fuel is drawn from tank (24), cleaned by the water separator filter (15) and then routed via overflow tank (14) back to tank (24). Water that collects in the tank is separated.

4. Start engine (→ Page 73).
5. Run engine at idling speed.
6. Check suction pressure (see technical data of the engine) at the engine-mounted fuel delivery pump.

Note: If the suction pressure is within the permissible limits and engine operation is satisfactory.

7. Increase engine speed to 1000 rpm and monitor suction pressure.
8. Check suction pressure at the engine-mounted fuel delivery pump.

Result: If the values are within the limits specified by the manufacturer, the system is ready to start filter replacement simulation with the engine running as part of the Harbor Acceptance Tests.

Simulation of filter replacement with the engine running: HAT

1. Switch on fuel treatment system (→ Page 81).
2. Start engine (→ Page 73).
3. Run engine at idling speed.
4. Close ball valve (5) at inlet to fuel treatment system.

Result: The pressure upstream of the fuel treatment system increases until the overflow valve at the pump unit opens and fuel flows through bypass (3) and bypass (2).

5. Open ball valve (19) .

Result: Fuel emerges. If no fuel emerges:

- Open ball valve (5) at inlet to fuel treatment system.
- No function of bypasses (2) and (3); carry out functional test of bypasses (2) and (3) .

6. Check suction pressure (see technical data of the engine) at the fuel delivery pump.

Note: If the suction pressure is within the permissible limits and engine operation is satisfactory.

7. Increase engine speed to 1000 rpm and monitor suction pressure.

Result: If all engine operating values are within the specified limits, open ball valve (5) at inlet to fuel treatment system.

Simulation of power failure (emergency): HAT

1. Switch on fuel treatment system (→ Page 81).
2. Start engine (→ Page 73).
3. Run engine at idling speed.
4. Switch off pump (21) at switchgear cabinet (20).

Result: The engine-mounted fuel delivery pump draws fuel via bypass (2) directly from tank (24).

5. Check suction pressure at the engine-mounted fuel delivery pump.

Note: If the suction pressure is within the permissible limits and engine operation is satisfactory.

6. Increase engine speed to 1000 rpm and monitor suction pressure.

Result: If the suction pressure is within the specified limits, simulation was successful.

Simulation of power failure (emergency): SAT

1. Switch on fuel treatment system (→ Page 81).
2. Start engine (→ Page 73).
3. Run engine at idling speed.
4. Switch off pump (21) at switchgear cabinet (20).

Result: The engine-mounted fuel delivery pump draws fuel via bypass (2) directly from tank (24).

5. Check suction pressure at the engine-mounted fuel delivery pump.

Note: If the suction pressure is within the permissible limits and engine operation is satisfactory.

6. Operate engine at full load and monitor suction pressure.

Result: If the suction pressure is within the specified limits, simulation was successful.

4.10 Fuel treatment system – Switching on

Preconditions

- The on-board power supply is switched on.

NOTICE



Risk of damage to engine/system.

Risk of severe damage to property!

- Before switching on, ensure that the engine/system is ready for operation.
- Before switching on, ensure that all housings are closed.
- Before switching on, ensure that no work is in progress anywhere on the entire system.

Fuel treatment system – Switching on

1. Carry out checks prior to start-up (→ Page 77).
2. Switch on master switch on switchgear cabinet.
Result: Signal lamp “Control voltage present” lights up.
3. Switch on switch for pump.
Result: Signal lamp “Pump running” lights up.

4.11 Stopping the engine

Stopping the engine via the automation system

Refer to automation system operating instructions

4.12 Engine emergency stop at BlueLine automation system (control stand)

NOTICE



An emergency stop causes extreme stress to the engine plant.

Risk of overheating, damage to components!

- Initiate emergency stop only in emergency situations.


Engine emergency stop at BlueLine automation system

| Item | Measure |
|--------|---|
| Engine | Emergency stop at BlueLine automation system (→ Operating Instructions for BlueLine). |

4.13 Coupling - Engaging from LOP

Preconditions

- LOCAL OPERATION illuminated pushbutton lights up brightly (local operating mode is active).
- Engine speed in engagement window.
- No external engagement interlock active.

| | |
|--------|---|
| DANGER |  <p>Vessel is sailing blind. In Local Operation mode, the propulsion plant is controlled from the engine room.</p> <p>Risk of accidents!</p> <ul style="list-style-type: none"> • Only execute vessel movements on the instructions of a person who has visual contact with the area outside the vessel. |
|--------|---|

Engaging coupling without reversing gearbox (CPP, WJ, VS)

| Item | Measure |
|------|---|
| LOP | Press COUPLING IN illuminated pushbutton (→ Page 69). <ul style="list-style-type: none"> • COUPLING IN button flashes. • Coupling is engaged. • After receiving the feedback signal from coupling, the COUPLING IN button is illuminated brightly. |

Engaging coupling in ahead direction with reversing gearbox (FPP, WJ)

| Item | Measure |
|------|--|
| LOP | Press COUPLING AHEAD illuminated pushbutton (→ Page 69). <ul style="list-style-type: none"> • COUPLING AHEAD button flashes. • Gearbox is engaged in AHEAD direction. • After receiving the feedback signal from coupling, the COUPLING AHEAD button is illuminated brightly. |

Engaging coupling in astern direction with reversing gearbox (FPP)

| Item | Measure |
|------|---|
| LOP | Press COUPLING ASTERN illuminated pushbutton (→ Page 69). <ul style="list-style-type: none"> • COUPLING ASTERN button flashes. • Gearbox is engaged astern. • After receiving the feedback signal from coupling, the COUPLING ASTERN button is illuminated brightly. |

4.14 Coupling - Disengaging from LOP

Preconditions

- LOCAL OPERATION illuminated pushbutton lights up brightly (local operating mode is active).
- Engine speed in disengagement window.

Disengaging coupling without reversing gearbox (CPP, WJ, VS)

| Item | Measure |
|------|---|
| LOP | Press COUPLING OUT illuminated pushbutton (→ Page 69). <ul style="list-style-type: none">• COUPLING OUT button flashes.• Coupling is disengaged.• After receiving the feedback signal from coupling, the COUPLING OUT button is illuminated brightly. |

Disengaging coupling with reversing gearbox (FPP, WJ)

| Item | Measure |
|------|---|
| LOP | Press COUPLING NEUTRAL illuminated pushbutton (→ Page 69). <ul style="list-style-type: none">• COUPLING NEUTRAL button flashes.• Gearbox is disengaged (neutral position).• After receiving the feedback signal from coupling, the COUPLING NEUTRAL button is illuminated brightly. |

4.15 Waterjet – Flushing from LOP (optional)

Preconditions

- LOCAL OPERATION illuminated pushbutton is lit brightly (local operating mode is active).
- Vessel is at a standstill and waterjet bucket is below the waterline.
- Engine speed is in engagement window.
- No external engagement interlock is active.

NOTICE



Waterjet flushing puts excessive strain on the bearings.

Bearing damage!

- Do not flush waterjet for too long.
- Follow instructions of the waterjet manufacturer.

Flushing with reversing gearbox and flushing mode

| Item | Measure |
|------|--|
| LOP | Press FLUSH illuminated pushbutton and keep pressed (→ Page 69). <ul style="list-style-type: none">• FLUSH pushbutton flashes.• Gearbox is engaged astern.• After receiving the feedback signal from coupling, the FLUSH pushbutton is illuminated brightly. |
| LOP | Release FLUSH illuminated pushbutton. <ul style="list-style-type: none">• FLUSH pushbutton flashes.• Gearbox is disengaged (neutral position).• Illumination of FLUSH pushbutton is switched off as soon as the feedback signal from coupling is received. |

4.16 Stopping the engine from LOP

Preconditions

- Engine is running in local mode.

NOTICE



Stopping the engine when it is running at full load causes extreme stress to the engine.

Risk of overheating, damage to components!

- Before shutting down, disengage gear and run the engine at idle speed for at least 10 minutes until engine temperatures have dropped and constant values are displayed.

Stopping the engine from LOP

| Item | Measure |
|-------------------------|--|
| LOP | Disengage gearbox (→ Page 69). |
| LOP | Operate engine at idle speed (→ Page 69). |
| Temperature indications | Wait until engine temperatures do not fall any further. |
| LOP | Press STOP illuminated pushbutton (→ Page 69). <ul style="list-style-type: none">• STOP button is illuminated.• Engine at a standstill. |

4.17 Stopping the engine at the BlueLine automation system (control stand)

NOTICE



Stopping the engine when it is running at full load causes extreme stress to the engine.

Risk of overheating, damage to components!

- Before shutting down, disengage gear and run the engine at idle speed for at least 10 minutes until engine temperatures have dropped and constant values are displayed.

Stopping the engine at the BlueLine automation system (control stand)

| Item | Measure |
|--------|---|
| Engine | Stop the engine at the BlueLine automation system (control stand) (→ Blue-Line Operating Instructions). |

4.18 Emergency stop from LOP

NOTICE



An emergency stop causes extreme stress to the engine plant.

Risk of overheating, damage to components!

- Initiate emergency stop only in emergency situations.

Emergency stop from LOP

| Item | Measure |
|------|---|
| LOP | Open cap of illuminated EMERGENCY STOP pushbutton (→ Page 69). |
| LOP | Press EMERGENCY STOP illuminated pushbutton. <ul style="list-style-type: none">• Engine is stopped by disconnecting the power supply to the ECU.• On engines with emergency-air shutoff flaps: flaps close;• EMERGENCY STOP illuminated pushbutton flashes. Horn, flashing lamp etc. are tripped. |

After emergency stop from LOP

| Item | Measure |
|--------|---|
| LOP | Press ALARM ACKNOWLEDGE illuminated pushbutton (→ Page 69). <ul style="list-style-type: none">• Audible and visual signalization stops. |
| LOP | Press ALARM ACKNOWLEDGE button again. <ul style="list-style-type: none">• Power supply to ECU is provided;• Alarm has been acknowledged. |
| Engine | On engines with emergency-air shutoff flaps: open flaps. <ul style="list-style-type: none">• Engine is ready for starting. |

4.19 Emergency engine stop

NOTICE



An emergency stop causes extreme stress to the engine plant.

Risk of overheating, damage to components!

- Initiate emergency stop only in emergency situations.

Emergency stop

1. Refer to automation system operating instructions.
2. Follow instructions.

4.20 After stopping the engine

Preconditions

- ☑ MTU Fluids and Lubricants Specifications (A001061/..) are available.

After stopping the engine

| Item | Action |
|-------------------------------|---|
| Coolant circuit | Drain coolant (→ Page 178) if: <ul style="list-style-type: none">• freezing temperatures are expected and the engine is to remain out of service for an extended period, but engine coolant has no antifreeze additive;• the engine room is not heated;• the coolant is not kept at a suitable temperature;• the antifreeze concentration is insufficient for the engine-room temperature;• antifreeze concentration is 50 % and engine-room temperature is below -40 °C. |
| Raw water | Drain <ul style="list-style-type: none">• If freezing temperatures are to be expected and the engine is to remain out of service for an extended period. |
| Engine control system | Switch off. |
| Air intake and exhaust system | Out-of-service-period > 1 week <ul style="list-style-type: none">• Seal engine's air and exhaust sides. |
| Engine | Out-of-service-period > 1 month <ul style="list-style-type: none">• Preserve engine (→ MTU Fluids and Lubricants Specifications A001061/..) |

4.21 Fuel treatment system - Shutdown

Shutting down fuel treatment system

1. Press the illuminated pushbutton "Water drain" on the switch cabinet until water discharge from the outlet stops.
2. Switch off fuel treatment system.
3. Close ball valve at the inlet to the fuel treatment system.
4. Close ball valve at the outlet of the fuel treatment system.
5. Open drain valve until pressure has escaped from fuel treatment system.





4.22 Plant – Cleaning

Preconditions

- Engine stopped and starting disabled.
- Operating voltage is not present.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-----------------------|----------|------|
| Steam jet cleaner | - | 1 |
| Cleaner (Hakupur 312) | 30390 | 1 |

| | |
|---|---|
| WARNING  | Compressed air gun ejects a jet of pressurized air. Risk of injury to eyes and damage to hearing, risk of rupturing internal organs! <ul style="list-style-type: none"> • Never direct air jet at people. • Always wear safety goggles/face mask and ear defenders. |
| WARNING  | Steam jet cleaner ejects jet of pressurized water. Risk of injury to eyes and scalding! <ul style="list-style-type: none"> • Never direct water jet at people. • Wear protective clothing, protective gloves and safety goggles/face mask. |
| NOTICE  | Cleaning agents should not be left to take effect for too long. Damage to components is possible! <ul style="list-style-type: none"> • Observe manufacturer's instructions. |
| NOTICE  | Blowing down product with compressed air. Entry of dirt and damage to components is possible! <ul style="list-style-type: none"> • Do not aim compressed air gun directly at seals or electronic components such as connectors or ECUs. |

Plant – Cleaning

1. Carry out plant cleaning only in areas where an appropriate oil separator is provided (environmental protection).
2. Prior to putting the cleaning unit into operation, read the Operating Instructions of the water/steam jet unit carefully and observe the safety precautions.
3. For external cleaning of the plant with water or steam-jet cleaners:
 - The pressure of the high-pressure jet (cleaning jet) must not exceed 50 bar.
 - A minimum distance between spray nozzle and plant of 1 m must be observed.
 - The temperature of the cleaning medium must not exceed 80 °C.
4. For external cleaning with high-pressure jet, use a flat-mouth nozzle only.
5. Carry out external cleaning as follows:
 - a) Seal all openings in a suitable fashion.
 - b) Remove coarse dirt.
 - c) Spray on cleaner sparingly and leave it for 1 to 5 minutes.
 - d) Use the high-pressure jet to remove the loosened dirt.

Note: Never aim compressed air directly at electronic components.
e) Dry engine.

5 Maintenance

5.1 Maintenance schedule task reference table [QL1]

The maintenance tasks and intervals for this product are defined in the Maintenance Schedule. The Maintenance Schedule is a stand-alone publication.

The task numbers in this table provide reference to the maintenance tasks specified in the Maintenance Schedule.

| Task | Option | Maintenance tasks | |
|-------|--------|---|----------------------|
| W0500 | | Check engine oil level. | (→ Page 162) |
| W0501 | | Visually inspect engine for leaks and general condition. | (→ Page 74) |
| W0502 | X | Check intercooler condensate drain. | (→ Page 74) |
| W0503 | | Check service indicator of air filter. | (→ Page 160) |
| W0504 | | Check relief bores of HP fuel pump. | (→ Page 140) |
| W0505 | | Check relief bores of water pump(s). | (→ Page 181) |
| W0506 | | Check engine for abnormal running noises, exhaust color and vibrations. | (→ Page 74) |
| W0507 | X | Drain water and contaminants from fuel pre-filter. | (→ Page 74) |
| W0508 | X | Check reading on differential pressure gauge of fuel prefilter. | (→ Page 149) |
| W1001 | | Replace fuel filter or fuel filter element | (→ Page 147) |
| W1005 | | Replace air filter. | (→ Page 158) |
| W1006 | | Replace fuel injection valves/injectors. | (→ Page 141) |
| W1008 | | Replace engine oil filter when changing engine oil, or when the interval (years) is reached, at the latest. | (→ Page 168) |
| W1009 | X | Check layer thickness of oil residues, clean and replace filter sleeve at each oil change, at the latest. | (→ Page 173) |
| W1011 | | Perform endoscopic examination. | (→ Page 129) |
| W1016 | | Generator: Check condition of coupling. | (→ Page 184) |
| W1036 | X | Replace coolant filter. | No longer installed. |
| W1047 | | Check and clean oil indicator filter. | (→ Page 171) |
| W1076 | | Exhaust turbocharger: Clean compressor wheel (MTU-ZR turbocharger). | (→ Page 155) |
| W1207 | | Check and adjust valve clearance. ATTENTION! First adjustment after 1,000 operating hours. | (→ Page 134) |
| W1244 | X | Check function of rod electrode. | (→ Page 189) |
| W1245 | X | Check alarm function of differential pressure gauge. | (→ Page 188) |
| W1246 | X | Check pump capacity. | (→ Page 190) |

TIM-ID: 000.0035260 - 002

| Task | Option | Maintenance tasks | |
|-------|--------|---|--------------|
| W1463 | | Check general condition of engine mounting (visual inspection). | (→ Page 185) |
| W1713 | | Injector: Reset drift correction (CDC) parameters. | (→ Page 194) |

Table 2: Maintenance schedule task reference table [QL 1]

6 Troubleshooting

6.1 Fuel treatment system – Troubleshooting

Illuminated pushbutton “Water alarm” is lit.

| Cause | Corrective action |
|--|---|
| When the maximum water level is reached, the water level electrode opens the water drain valve and water is discharged. If the opening period of the valve exceeds a preset limit (4 minutes), the pump will switch off and an alarm is initiated. | <ol style="list-style-type: none">1. Press illuminated pushbutton “Water alarm” to acknowledge.2. In addition to the automatic water drain function, water can also be drained manually. To do so, press the illuminated pushbutton “Water drain” to open the drain valve. |

Signal lamp “Pump fault” is lit.

| Cause | Corrective action |
|---|---------------------------------|
| The drive motor is equipped with an overload protection. If the maximum permissible current consumption is exceeded, e.g. in case of a blockage or dry-running, the motor protection relay triggers and the pump is switched off. | ▶ Reset motor protection relay. |

Signal lamp “Warning filter” is lit.

| Cause | Corrective action |
|---|--|
| The differential pressure exceeded 1.3 bar. | ▶ Replace coalescer filter element (→ Page 191). |

Illuminated pushbutton “Replace filter element” is lit.

| Cause | Corrective action |
|--|--|
| The max. permissible differential pressure of 1.5 bar was exceeded. If the coalescer filter element is not replaced, pressure will increase further and the safety valve will open. Fuel will be led via the bypass directly into the overflow tank. | <ol style="list-style-type: none">1. Replace coalescer filter element (→ Page 191).2. Press illuminated pushbutton “Replace filter element” to acknowledge. |

6.2 Troubleshooting

Engine does not turn when starter is actuated

| Cause | Corrective action |
|--|---|
| Battery low or faulty | ▶ Charge or replace (see special documentation). |
| Battery: Cable connections faulty | ▶ Check if cable connections are properly secured (see special documentation). |
| Engine cabling or starter faulty | ▶ Check if cable connections are properly secured, contact Service. |
| Engine wiring defective | ▶ Check (→ Page 193). |
| Assemblies or connectors on LOP possibly loose | ▶ Inspect visually. |
| Plug-in connections on Engine Control Unit possibly loose | ▶ Check plug connections (→ Page 198). |
| Plug-in connections on Engine Interface Module (EIM) possibly loose | ▶ Check plug connections (→ Page 200). |
| Fuse F1 (→ Page 36) in engine wiring harness faulty (fuse lamp on EIM flashes with relevant flashing code) | ▶ Check fuse (replace if required) and re-start the system by actuating the key switch. |
| Running gear blocked (engine cannot be barred manually) | ▶ Contact Service. |

Engine turns but does not fire

| Cause | Corrective action |
|---|--|
| Poor rotation by starter: Battery low or faulty | ▶ Charge or replace battery (see special documentation). |
| Engine wiring defective | ▶ Check (→ Page 193). |
| Engine Control Unit defective | ▶ Contact Service. |

Engine fires unevenly

| Cause | Corrective action |
|-------------------------------|-------------------------|
| Injector faulty | ▶ Replace (→ Page 141). |
| Engine wiring defective | ▶ Check (→ Page 193). |
| Engine Control Unit defective | ▶ Contact Service. |

Engine does not reach rated speed

| Cause | Corrective action |
|---------------------------------|---|
| Easy-change fuel filter clogged | ▶ Replace (→ Page 147). |
| Air supply: Air filter clogged | ▶ Check signal ring position of service indicator (→ Page 160). |
| Fuel injection: Injector faulty | ▶ Replace (→ Page 141). |
| Engine wiring defective | ▶ Check (→ Page 193). |
| Engine: Overloaded | ▶ Contact Service. |

Engine speed not steady

| Cause | Corrective action |
|---------------------------------|-------------------------|
| Fuel injection: Injector faulty | ▶ Replace (→ Page 141). |
| Speed transmitter defective | ▶ Contact Service. |
| Engine Control Unit defective | ▶ Contact Service. |

Charge air temperature too high

| Cause | Corrective action |
|--|--|
| Engine coolant treatment incorrect | ▶ Check (MTU test kit). |
| Intercooler clogged | ▶ Contact Service. |
| Engine room: Air-intake temperature too high | ▶ Check fans and air supply / ventilation ducts. |

Charge-air pressure too low

| Cause | Corrective action |
|--------------------------------|---|
| Air supply: Air filter clogged | ▶ Check signal ring position of service indicator (→ Page 160). |
| Intercooler clogged | ▶ Contact Service. |
| Exhaust turbocharger defective | ▶ Contact Service. |

Coolant leaks at intercooler

| Cause | Corrective action |
|--|--------------------|
| Intercooler leaky, major coolant discharge | ▶ Contact Service. |

Black exhaust gas

| Cause | Corrective action |
|---------------------------------|---|
| Air supply: Air filter clogged | ▶ Check signal ring position of service indicator (→ Page 160). |
| Fuel injection: Injector faulty | ▶ Replace (→ Page 141). |
| Engine: Overloaded | ▶ Contact Service. |

Blue exhaust gas


| Cause | Corrective action |
|---|----------------------------------|
| Too much oil in engine | ▶ Drain engine oil (→ Page 163). |
| Oil separator or oil-preseparator of crankcase breather clogged | ▶ Replace. |
| Exhaust turbocharger, cylinder head, piston rings, cylinder liner defective | ▶ Contact Service. |

White exhaust gas

| Cause | Corrective action |
|--|--|
| Engine is not at operating temperature | ▶ Run engine to reach operating temperature. |
| Intercooler leaky | ▶ Contact Service. |

6.3 ADEC (ECU 7) fault codes for Series 4000 engines, marine application

The fault code numbers are generated by the engine governor and transmitted to the display below (if fitted).



The fault code (1) comprises 3 digits.

Fault messages may also be caused by faulty sensors/actuators. Contact Service to have sensors/actuators tested and replaced as necessary if troubleshooting as described in the table (→ Page 101) proves unsuccessful.

For explanations of alarm configuration parameters, refer to PR 2.8008.100.

Fault code list (→ Page 101).

6.4 ADEC engine governor – Fault codes

29 – HI ETC Idle Speed too High

ZKP-Number: 18.004.206

| Cause | Corrective action |
|---|--------------------|
| Idle speed of one of the secondary turbochargers is too high. | ▶ Contact Service. |

38 – AL ETC Speed Deviation

ZKP-Number: 18.004.205

| Cause | Corrective action |
|--|---|
| Speeds of one of the secondary turbochargers deviates from primary turbocharger speed. | 1. Reduce power. 2. Contact Service. |

39 – AL ETC2 CutIn Failure

ZKP-Number: 18.004.204

| Cause | Corrective action |
|---------------------------|---|
| ETC2 could not be cut in. | 1. Reduce power. 2. Contact Service. |

81 – AL Rail Leakage

ZKP-Number: 18.004.046

| Cause | Corrective action |
|---|--------------------|
| Pressure gradient in rail is too low during starting or too high during stopping (HP system leaky or air in the system) | ▶ Contact Service. |

102 – AL Cons. Counter Defect

ZKP-Number: 18.004.624

| Cause | Corrective action |
|---------------------------|--------------------|
| Consumption meter faulty. | ▶ Contact Service. |

104 – AL Eng Hours Counter Defect

ZKP-Number: 18.004.623

| Cause | Corrective action |
|-------------------|--------------------|
| Hourmeter faulty. | ▶ Contact Service. |

141 – AL Power too high

ZKP-Number: 11.088.007

| Cause | Corrective action |
|--|-------------------|
| This alarm occurs if the average value of power over the last 24 hours exceeded the maximum value specified in PR1.1088.001. | ▶ Reduce power. |

142 – AL MCR exceeded 1 hour

ZKP-Number: 11.088.006

| Cause | Corrective action |
|--|-------------------|
| This alarm occurs if the MCR was exceeded for more than 1 hour within the last 12 hours. | ▶ Reduce power. |

201 – SD T-Coolant

ZKP-Number: 18.004.570

| Cause | Corrective action |
|--|---|
| Coolant temperature sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B6), replace as necessary.2. Error cleared after restarting the engine. |

202 – SD T-Fuel

ZKP-Number: 18.004.572

| Cause | Corrective action |
|--|--|
| Coolant temperature sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B33), replace as necessary.2. Error cleared after restarting the engine. |

203 – SD T-Charge Air

ZKP-Number: 18.004.571

| Cause | Corrective action |
|---|---|
| Charge-air temperature sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B9), replace as necessary.2. Error cleared after restarting the engine. |

204 – SD Level Lube Oil

ZKP-Number: 18.004.602

| Cause | Corrective action |
|---|---|
| lube oil level sensor faulty; Short circuit or wire break | ▶ Check sensor and cabling, replace as necessary. |

205 – SD T-Coolant Intercooler

ZKP-Number: 18.004.574

| Cause | Corrective action |
|--|---|
| Intercooler coolant temperature sensor faulty; Short circuit or wire break | ▶ Check sensor and cabling (B26), replace as necessary. |

206 – SD T-Exhaust A

ZKP-Number: 18.004.576

| Cause | Corrective action |
|--|---|
| Exhaust temperature sensor on A-side faulty; Short circuit or wire break | ▶ Check sensor and cabling (B4.21), replace as necessary. |

207 – SD T-Exhaust B

ZKP-Number: 18.004.577

| Cause | Corrective action |
|--|---|
| Exhaust temperature sensor on B-side faulty; Short circuit or wire break | ▶ Check sensor and cabling (B4.22), replace as necessary. |

208 – SD P-Charge Air

ZKP-Number: 18.004.566

| Cause | Corrective action |
|--|--|
| Charge-air pressure sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B10), replace as necessary.2. Error cleared after restarting the engine. |

211 – SD P-Lube Oil

ZKP-Number: 18.004.563

| Cause | Corrective action |
|--|---|
| Lube oil pressure sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B5), replace as necessary.2. Error cleared after restarting the engine. |

212 – SD P-Coolant

ZKP-Number: 18.004.564

| Cause | Corrective action |
|---|--|
| Coolant pressure sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B16), replace as necessary.2. Error cleared after restarting the engine. |

213 – SD P-Coolant Intercooler

ZKP-Number: 18.004.569

| Cause | Corrective action |
|---|--|
| Intercooler coolant pressure sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B43), replace as necessary.2. Error cleared after restarting the engine. |

214 – SD P-CrankCase

ZKP-Number: 18.004.568

| Cause | Corrective action |
|---|--|
| Crankcase pressure sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B50), replace as necessary.2. Error cleared after restarting the engine. |

215 – SD P-HD

ZKP-Number: 18.004.567

| Cause | Corrective action |
|--|--|
| Rail pressure sensor faulty; high-pressure regulator emergency mode; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B48), replace as necessary.2. Error cleared after restarting the engine. |

216 – SD T-Lube Oil

ZKP-Number: 18.004.575

| Cause | Corrective action |
|---|---|
| Lube oil temperature sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B7), replace as necessary.2. Error cleared after restarting the engine. |

219 – SD T-Intake Air

ZKP-Number: 18.004.573

| Cause | Corrective action |
|---|---|
| Intake air temperature sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B3), replace as necessary.2. Error cleared after restarting the engine. |

220 – SD Level Coolant Water

ZKP-Number: 18.004.584

| Cause | Corrective action |
|--|--|
| Coolant level sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (F33), replace as necessary.2. Error cleared after restarting the engine. |

221 – SD P-Diff-Lube Oil

ZKP-Number: 18.004.585

| Cause | Corrective action |
|---|--|
| Lube oil differential pressure sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (F25), replace as necessary.2. Error cleared after restarting the engine. |

222 – SD Level Leakage Fuel

ZKP-Number: 18.004.582

| Cause | Corrective action |
|--|--|
| Leak-off fuel level sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (F46), replace as necessary.2. Error cleared after restarting the engine. |

223 – SD Level Coolant Intercooler

ZKP-Number: 18.004.583

| Cause | Corrective action |
|---|--|
| Coolant level sensor of intercooler faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (F57), replace as necessary.2. Error cleared after restarting the engine. |

227 – SD P-Lube Oil before Filter

ZKP-Number: 18.004.620

| Cause | Corrective action |
|--|---|
| Sensor for lube oil pressure before filter faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B5.3), replace as necessary.2. Error cleared after restarting the engine. |

228 – SD P-Fuel before Filter

ZKP-Number: 18.004.595

| Cause | Corrective action |
|--|---|
| Fuel pressure sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B5.3), replace as necessary.2. Error cleared after restarting the engine. |

229 – AL Stop Camshaft Sensor Defect

ZKP-Number: 18.004.562

| Cause | Corrective action |
|---|--|
| Engine shutdown due to camshaft sensor fault (and a prior crankshaft sensor fault in the same operating cycle). | <ol style="list-style-type: none">1. Check connector and cabling to sensor B1, replace as necessary.2. Error cleared after restarting the engine. |

230 – SD Crankshaft Speed

ZKP-Number: 18.004.498

| Cause | Corrective action |
|---|--|
| Crankshaft sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B13), replace as necessary.2. Error cleared after restarting the engine. |

231 – SD Camshaft Speed

ZKP-Number: 18.004.499

| Cause | Corrective action |
|---|---|
| Camshaft sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B1), replace as necessary.2. Error cleared after restarting the engine. |

232 – SD Charger 1 Speed

ZKP-Number: 13.011.128

| Cause | Corrective action |
|--|--|
| Speed sensor of primary turbocharger faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B44.1), replace as necessary.2. Error cleared after restarting the engine. |

233 – SD Charger 2 Speed

ZKP-Number: 13.011.129

| Cause | Corrective action |
|--|--|
| Speed sensor of secondary turbocharger faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B44.2), replace as necessary.2. Error cleared after restarting the engine. |

239 – SD P-Diff Fuel

ZKP-Number: 18.004.598

| Cause | Corrective action |
|--|--|
| Fuel differential pressure sensor faulty; occurs only in combination with alarm "SD P-Fuel before Filter" or "SD P-Fuel after Filter". | ► Note further fault messages. Pressure sensor before or after filter is faulty. |

240 – SD P-Fuel

ZKP-Number: 18.004.565

| Cause | Corrective action |
|--|--|
| Fuel pressure sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B34), replace as necessary.2. Error cleared after restarting the engine. |

241 – SD T-Umlasen

ZKP-Number: 18.004.581

| Cause | Corrective action |
|--|--|
| Recirculation temperature sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling (B49), replace as necessary.2. Error cleared after restarting the engine. |

242 – SD T-Coolant (R)

ZKP-Number: 18.004.622

| Cause | Corrective action |
|--|--|
| Redundant coolant temperature sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling, replace as necessary.2. Error cleared after restarting the engine. |

244 – SD P-Lube Oil (R)

ZKP-Number: 18.004.621

| Cause | Corrective action |
|--|--|
| Redundant lube oil pressure sensor faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check sensor and cabling, replace as necessary.2. Error cleared after restarting the engine. |

301 – AL Timing Cylinder A1

ZKP-Number: 18.004.500

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector in cylinder A1: Time-of flight measured value extremely low or extremely high. | <ul style="list-style-type: none">▶ If alarm occurs frequently, replace solenoid valve of injector |

302 – AL Timing Cylinder A2

ZKP-Number: 18.004.501

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector in cylinder A2: Time-of flight measured value extremely low or extremely high. | <ul style="list-style-type: none">▶ If alarm occurs frequently, replace solenoid valve of injector |

303 – AL Timing Cylinder A3

ZKP-Number: 18.004.502

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector in cylinder A3: Time-of-flight measured value extremely low or extremely high. | ► If alarm occurs frequently, replace solenoid valve of injector |

304 – AL Timing Cylinder A4

ZKP-Number: 18.004.503

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector in cylinder A4: Time-of-flight measured value extremely low or extremely high. | ► If alarm occurs frequently, replace solenoid valve of injector |

305 – AL Timing Cylinder A5

ZKP-Number: 18.004.504

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector in cylinder A5: Time-of-flight measured value extremely low or extremely high. | ► If alarm occurs frequently, replace solenoid valve of injector |

306 – AL Timing Cylinder A6

ZKP-Number: 18.004.505

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector in cylinder A6: Time-of-flight measured value extremely low or extremely high. | ► If alarm occurs frequently, replace solenoid valve of injector |

307 – AL Timing Cylinder A7

ZKP-Number: 18.004.506

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector in cylinder A7: Time-of-flight measured value extremely low or extremely high. | ► If alarm occurs frequently, replace solenoid valve of injector |

308 – AL Timing Cylinder A8

ZKP-Number: 18.004.507

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector in cylinder A8: Time-of flight measured value extremely low or extremely high. | ▶ If alarm occurs frequently, replace solenoid valve of injector |

309 – AL Timing Cylinder A9

ZKP-Number: 18.004.508

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector in cylinder A9: Time-of flight measured value extremely low or extremely high. | ▶ If alarm occurs frequently, replace solenoid valve of injector |

310 – AL Timing Cylinder A10

ZKP-Number: 18.004.509

| Cause | Corrective action |
|--|--|
| Time-of-flight measuring fault of injector in cylinder A10: Time-of flight measured value extremely low or extremely high. | ▶ If alarm occurs frequently, replace solenoid valve of injector |

311 – AL Timing Cylinder B1

ZKP-Number: 18.004.510

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector B1: Time-of flight measured value extremely low or extremely high. | ▶ If alarm occurs frequently, replace solenoid valve of injector |

312 – AL Timing Cylinder B2

ZKP-Number: 18.004.511

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector B2: Time-of flight measured value extremely low or extremely high. | ▶ If alarm occurs frequently, replace solenoid valve of injector |

313 – AL Timing Cylinder B3

ZKP-Number: 18.004.512

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector B3: Time-of flight measured value extremely low or extremely high. | ▶ If alarm occurs frequently, replace solenoid valve of injector |

314 – AL Timing Cylinder B4

ZKP-Number: 18.004.513

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector B4: Time-of flight measured value extremely low or extremely high. | ▶ If alarm occurs frequently, replace solenoid valve of injector |

315 – AL Timing Cylinder B5

ZKP-Number: 18.004.514

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector B5: Time-of flight measured value extremely low or extremely high. | ▶ If alarm occurs frequently, replace solenoid valve of injector |

316 – AL Timing Cylinder B6

ZKP-Number: 18.004.515

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector B6: Time-of flight measured value extremely low or extremely high. | ▶ If alarm occurs frequently, replace solenoid valve of injector |

317 – AL Timing Cylinder B7

ZKP-Number: 18.004.516

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector B7: Time-of flight measured value extremely low or extremely high. | ▶ If alarm occurs frequently, replace solenoid valve of injector |

318 – AL Timing Cylinder B8

ZKP-Number: 18.004.517

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector B8: Time-of flight measured value extremely low or extremely high. | ▶ If alarm occurs frequently, replace solenoid valve of injector |

319 – AL Timing Cylinder B9

ZKP-Number: 18.004.518

| Cause | Corrective action |
|---|--|
| Time-of-flight measuring fault of injector B9: Time-of flight measured value extremely low or extremely high. | ▶ If alarm occurs frequently, replace solenoid valve of injector |

320 – AL Timing Cylinder B10

ZKP-Number: 18.004.519

| Cause | Corrective action |
|--|--|
| Time-of-flight measuring fault of injector B10: Time-of flight measured value extremely low or extremely high. | ▶ If alarm occurs frequently, replace solenoid valve of injector |

321 – AL Wiring Cylinder A1

ZKP-Number: 18.004.520

| Cause | Corrective action |
|---|---|
| Short-circuit in injector cabling to cylinder A1. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

322 – AL Wiring Cylinder A2

ZKP-Number: 18.004.521

| Cause | Corrective action |
|---|---|
| Short-circuit in injector cabling to cylinder A2. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

323 – AL Wiring Cylinder A3

ZKP-Number: 18.004.522

| Cause | Corrective action |
|---|---|
| Short-circuit in injector cabling to cylinder A3. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

324 – AL Wiring Cylinder A4

ZKP-Number: 18.004.523

| Cause | Corrective action |
|---|---|
| Short-circuit in injector cabling to cylinder A4. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

325 – AL Wiring Cylinder A5

ZKP-Number: 18.004.524

| Cause | Corrective action |
|---|---|
| Short-circuit in injector cabling to cylinder A5. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

326 – AL Wiring Cylinder A6

ZKP-Number: 18.004.525

| Cause | Corrective action |
|---|---|
| Short-circuit in injector cabling to cylinder A6. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

327 – AL Wiring Cylinder A7

ZKP-Number: 18.004.526

| Cause | Corrective action |
|---|---|
| Short-circuit in injector cabling to cylinder A7. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

328 – AL Wiring Cylinder A8

ZKP-Number: 18.004.527

| Cause | Corrective action |
|---|---|
| Short-circuit in injector cabling to cylinder A8. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

329 – AL Wiring Cylinder A9

ZKP-Number: 18.004.528

| Cause | Corrective action |
|---|---|
| Short-circuit in injector cabling to cylinder A9. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

330 – AL Wiring Cylinder A10

ZKP-Number: 18.004.529

| Cause | Corrective action |
|--|---|
| Short-circuit in injector cabling to cylinder A10. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

331 – AL Wiring Cylinder B1

ZKP-Number: 18.004.530

| Cause | Corrective action |
|---|---|
| Cabling fault in injector cabling to cylinder B1. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

332 – AL Wiring Cylinder B2

ZKP-Number: 18.004.531

| Cause | Corrective action |
|---|---|
| Cabling fault in injector cabling to cylinder B2. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

333 – AL Wiring Cylinder B3

ZKP-Number: 18.004.532

| Cause | Corrective action |
|---|---|
| Cabling fault in injector cabling to cylinder B3. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

334 – AL Wiring Cylinder B4

ZKP-Number: 18.004.533

| Cause | Corrective action |
|---|---|
| Cabling fault in injector cabling to cylinder B4. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

335 – AL Wiring Cylinder B5

ZKP-Number: 18.004.534

| Cause | Corrective action |
|---|---|
| Cabling fault in injector cabling to cylinder B5. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

336 – AL Wiring Cylinder B6

ZKP-Number: 18.004.535

| Cause | Corrective action |
|---|---|
| Cabling fault in injector cabling to cylinder B6. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

337 – AL Wiring Cylinder B7

ZKP-Number: 18.004.536

| Cause | Corrective action |
|---|---|
| Cabling fault in injector cabling to cylinder B7. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

338 – AL Wiring Cylinder B8

ZKP-Number: 18.004.537

| Cause | Corrective action |
|---|---|
| Cabling fault in injector cabling to cylinder B8. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

339 – AL Wiring Cylinder B9

ZKP-Number: 18.004.538

| Cause | Corrective action |
|---|---|
| Cabling fault in injector cabling to cylinder B9. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

340 – AL Wiring Cylinder B10

ZKP-Number: 18.004.539

| Cause | Corrective action |
|--|---|
| Cabling fault in injector cabling to cylinder B10. Result: Misfiring | <ol style="list-style-type: none">1. Rectify short circuit in injector solenoid valve circuit (positive to negative) (e.g. by injector replacement)2. Error cleared after restarting the engine. |

341 – AL Open Load Cylinder A1

ZKP-Number: 18.004.540

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder A1. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

342 – AL Open Load Cylinder A2

ZKP-Number: 18.004.541

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder A2. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

343 – AL Open Load Cylinder A3

ZKP-Number: 18.004.542

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder A3. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

344 – AL Open Load Cylinder A4

ZKP-Number: 18.004.543

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder A4. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

345 – AL Open Load Cylinder A5

ZKP-Number: 18.004.544

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder A5. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

346 – AL Open Load Cylinder A6

ZKP-Number: 18.004.545

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder A6. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

347 – AL Open Load Cylinder A7

ZKP-Number: 18.004.546

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder A7. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

348 – AL Open Load Cylinder A8

ZKP-Number: 18.004.547

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder A8. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

349 – AL Open Load Cylinder A9

ZKP-Number: 18.004.548

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder A9. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

350 – AL Open Load Cylinder A10

ZKP-Number: 18.004.549

| Cause | Corrective action |
|---|---|
| Disruption fault in injector cabling to cylinder A10. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

351 – AL Open Load Cylinder B1

ZKP-Number: 18.004.550

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder B1. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

352 – AL Open Load Cylinder B2

ZKP-Number: 18.004.551

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder B2. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

353 – AL Open Load Cylinder B3

ZKP-Number: 18.004.552

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder B3. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

354 – AL Open Load Cylinder B4

ZKP-Number: 18.004.553

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder B4. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

355 – AL Open Load Cylinder B5

ZKP-Number: 18.004.554

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder B5. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

356 – AL Open Load Cylinder B6

ZKP-Number: 18.004.555

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder B6. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

357 – AL Open Load Cylinder B7

ZKP-Number: 18.004.556

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder B7. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

358 – AL Open Load Cylinder B8

ZKP-Number: 18.004.557

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder B8. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

359 – AL Open Load Cylinder B9

ZKP-Number: 18.004.558

| Cause | Corrective action |
|--|---|
| Disruption fault in injector cabling to cylinder B9. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

360 – AL Open Load Cylinder B10

ZKP-Number: 18.004.559

| Cause | Corrective action |
|---|---|
| Disruption fault in injector cabling to cylinder B10. Result: Misfiring | <ol style="list-style-type: none">1. Check continuity of injector cabling or exclude open load in solenoid valve circuit (e.g. by injector replacement)2. Error clearance: After each working cycle. |

361 – AL Power Stage Low

ZKP-Number: 18.004.496

| Cause | Corrective action |
|---|--|
| Internal electronic fault (electronics possibly faulty). If bit "1.1020.021" (Power Stage Failure: Stop Engine) is set, engine will be shut down as additional measure. | <ul style="list-style-type: none">▶ Start ITS. If the ITS diagnosis result is "electronics OK", note further fault messages (e.g. cabling faults). |

362 – AL Power Stage High

ZKP-Number: 18.004.497

| Cause | Corrective action |
|---|--|
| Internal electronic fault (electronics possibly faulty). If bit "1.1020.021" (Power Stage Failure: Stop Engine) is set, engine will be shut down as additional measure. | <ul style="list-style-type: none">▶ Start ITS. If the ITS diagnosis result is "electronics OK", note further fault messages (e.g. cabling faults). |

363 – AL Stop Power Stage

ZKP-Number: 18.004.560

| Cause | Corrective action |
|---|--|
| Internal electronic fault (electronics possibly faulty). If bit "1.1020.021" (Power Stage Failure: Stop Engine) is set, engine will be shut down as additional measure. | <ul style="list-style-type: none">▶ Start ITS. If the ITS diagnosis result is "electronics OK", note further fault messages (e.g. cabling faults). |

TIM-ID: 000.0018389 - 003

365 – AL Stop MV-Wiring Ground

ZKP-Number: 18.004.561

| Cause | Corrective action |
|---|--|
| Injector cabling fault. If bit "1.1020.021" (Power Stage Failure: Stop Engine) is set, engine will be shut down as additional measure. Possible causes: 1. Short circuit of positive connection of one or more injectors to ground 2. Short circuit of negative connection of one or more injectors to ground | ▶ Check wiring, replace wiring harness as necessary. |

371 – AL Wiring TO 1

ZKP-Number: 18.004.634

| Cause | Corrective action |
|--|--|
| Short circuit or wire break on transistor output 1 (TO 1). | 1. Check charger valve/cabling, repair as necessary. 2. Replace engine governor |

372 – AL Wiring TO 2

ZKP-Number: 18.004.635

| Cause | Corrective action |
|--|---|
| Short circuit or wire break on transistor output 2 (TO 2). | 1. Check air recirculation valve/cabling, repair as necessary 2. Replace engine governor |

373 – AL Wiring TO 3

ZKP-Number: 18.004.636

| Cause | Corrective action |
|--|---|
| Short circuit or wire break on transistor output 3 (TO 3). | ▶ Check wiring of charger valve 2 (marine engine) |

374 – AL Wiring TO 4

ZKP-Number: 18.004.637

| Cause | Corrective action |
|--|---|
| Short circuit or wire break on transistor output 4 (TO 4). | ▶ Check wiring of charger valve 3 (marine engine) |

390 – AL MCR exceeded

ZKP-Number: 11.085.009

| Cause | Corrective action |
|--|---|
| DBR/MCR feature: MCR (maximum continuous rating) was exceeded. | <ol style="list-style-type: none">1. If the alarm occurs temporarily, no action required.2. If the alarm is permanently active, contact Service. |

396 – TD T-Coolant Sensor Deviation

ZKP-Number: 10.480.193

| Cause | Corrective action |
|--|--|
| Maximum deviation of coolant temperature values from sensors | <ol style="list-style-type: none">1. Check sensor and cabling, replace as necessary.2. Contact Service. |

397 – TD P-Oil Sensor Deviation

ZKP-Number: 10.480.293

| Cause | Corrective action |
|--|--|
| Maximum deviation of lube oil pressure values from sensors | <ol style="list-style-type: none">1. Check sensor and cabling, replace as necessary.2. Contact Service. |

417 – SD Level Water Fuel Prefilter

ZKP-Number: 18.004.594

| Cause | Corrective action |
|--|---|
| Water level sensor in fuel prefilter faulty; Short circuit or wire break | ▶ Check sensor and cabling, replace as necessary. |

419 – SD T-Coolant b.Engine

ZKP-Number: 18.004.604

| Cause | Corrective action |
|--|--|
| Coolant inlet temperature sensor faulty; Short circuit or wire break | ▶ Check sensor and cabling (B3), replace as necessary. |

444 – SD U-PDU

ZKP-Number: 18.004.578

| Cause | Corrective action |
|--|-------------------|
| Injector power stage sensor defect; Internal fault in ECU 7. | ▶ Replace ECU 7. |

TIM-ID: 0000018389 - 003

445 – SD P-Ambient Air

ZKP-Number: 18.004.580

| Cause | Corrective action |
|-------------------------------------|---|
| Ambient air pressure sensor faulty. | <ol style="list-style-type: none">1. Check pressure sensor and cabling, replace as necessary.2. Replace engine governor. |

464 – SD P-AUX 1

ZKP-Number: 18.004.589

| Cause | Corrective action |
|--|--|
| Analog input signal for Aux 1 pressure faulty; Short circuit or wire break | ▶ Check pressure sensor and cabling, replace as necessary. |

468 – SD T-AUX 1

ZKP-Number: 18.004.579

| Cause | Corrective action |
|---|--|
| Analog input signal for Aux 1 temperature faulty; | <ol style="list-style-type: none">1. Check signal transmitter and cabling, replace as necessary.2. Replace engine governor. |

469 – SD AUX 1

ZKP-Number: 18.004.590

| Cause | Corrective action |
|---|---|
| Analog input signal for Aux 1 faulty; Short circuit or wire break | ▶ Check signal transmitter and cabling, replace as necessary. |

470 – SD T-ECU

ZKP-Number: 18.004.587

| Cause | Corrective action |
|--|---|
| Temperature sensor for ECU faulty; Short circuit or wire break | ▶ Check sensor and cabling, replace as necessary. |

471 – SD Coil Current

ZKP-Number: 18.004.592

| Cause | Corrective action |
|--|---|
| Control of HP fuel control block faulty; Short circuit or wire break | ▶ Check sensor and cabling, replace as necessary. |

473 – AL Wiring PWM_CM2

ZKP-Number: 18.004.593

| Cause | Corrective action |
|--|--|
| Cable break or short circuit on channel PWM_CM2. | 1. Check cabling. 2. Contact Service. |

475 – AL CR Trigger Engine Stop

ZKP-Number: 18.010.009

| Cause | Corrective action |
|--|---|
| Activated if the crash recorder was triggered due to an engine stop. | 1. Determine cause of trigger/engine stop and rectify. 2. Contact Service. |

476 – AL Crash Rec. Init. Error

ZKP-Number: 18.010.007

| Cause | Corrective action |
|--------------------------------------|--|
| Crash recorder initialization error. | 1. Check setting with DiaSys. 2. Contact Service. |

482 – SD T-Exhaust C

ZKP-Number: 18.004.596

| Cause | Corrective action |
|--|---|
| Exhaust temperature sensor on A-side faulty; Short circuit or wire break | ▶ Check sensor and cabling (B4.23), replace as necessary. |

483 – SD T-Exhaust D

ZKP-Number: 18.004.597

| Cause | Corrective action |
|--|---|
| Exhaust temperature sensor on A-side faulty; Short circuit or wire break | ▶ Check sensor and cabling (B4.24), replace as necessary. |

492 – AL ETC4 CutIn Failure

ZKP-Number: 18.004.202

| Cause | Corrective action |
|---------------------------|---------------------------------|
| ETC4 could not be cut in. | ▶ Check control valve on ETC 4. |

493 – AL ETC3 CutIn Failure

ZKP-Number: 18.004.203

| Cause | Corrective action |
|---------------------------|---------------------------------|
| ETC3 could not be cut in. | ▶ Check control valve on ETC 3. |

500 – AL Wiring POM Starter 1

ZKP-Number: 14.500.900

| Cause | Corrective action |
|--|---|
| A wiring fault was detected in the connection between starter 1 and POM. This may be a missing consumer, a wire break, or a short circuit. | ▶ Check connection between POM and starter. |

501 – AL Wiring POM Starter 2

ZKP-Number: 14.500.901

| Cause | Corrective action |
|--|---|
| A wiring fault was detected in the connection between starter 2 and POM. This may be a missing consumer, a wire break, or a short circuit. | ▶ Check connection between POM and starter. |

502 – AL Open Load POM Alternator

ZKP-Number: 14.500.902

| Cause | Corrective action |
|--|---|
| Open load was detected at the connection of the battery-charging generator on the POM. | ▶ Check connection between POM and starter. |

503 – AL Battery Not Charging

ZKP-Number: 14.500.903

| Cause | Corrective action |
|---|---|
| The battery-charging generator does not charge the battery. | ▶ Check battery-charging generator and cabling. |

504 – AL CAN POM Node Lost

ZKP-Number: 14.500.904

| Cause | Corrective action |
|-------------------------|--|
| POM missing on CAN bus. | ▶ Check connection and POM. If alarm occurs in combination with alarm 508, the resistor in the POM cabling is missing. |

506 – AL Low Starter Voltage

ZKP-Number: 14.500.906

| Cause | Corrective action |
|--|---|
| battery voltage is too low to accomplish a starting procedure. | ▶ Check battery-charging generator and cabling. |

507 – AL POM Error

ZKP-Number: 14.500.907

| Cause | Corrective action |
|-------------------------------|-------------------|
| A general POM error occurred. | ▶ Replace POM. |

508 – AL Wrong POM-ID

ZKP-Number: 14.500.908

| Cause | Corrective action |
|---|-----------------------------|
| POM transmits an unexpected ID number. If alarm occurs in combination with alarm 504, the resistor in the POM cabling is missing. | ▶ Check POM wiring harness. |

519 – Oillevel Calibration Error

ZKP-Number: 10.158.921

| Cause | Corrective action |
|--|--|
| Error when writing the calibration value into the Flash or SD memory of the level sensor; associated PV: AL Group 6 Mot Bit 11 | <ol style="list-style-type: none">1. Check sensor and cabling, replace as necessary.2. Contact Service. |

525 – SD P-Lube Oil (R2)

ZKP-Number: 18.004.638

| Cause | Corrective action |
|--|---|
| Redundant lube oil pressure sensor faulty; Short circuit or wire break | ▶ Check sensor and cabling, replace as necessary. |

526 – SD T-Coolant (R2)

ZKP-Number: 18.004.639

| Cause | Corrective action |
|--|---|
| Redundant coolant temperature sensor faulty; Short circuit or wire break | ▶ Check sensor and cabling, replace as necessary. |

527 – TD EngineSpd. Sensor Deviation

ZKP-Number: 10.480.093

| Cause | Corrective action |
|------------------------------------|--|
| Maximum deviation of speed sensors | 1. Check cabling of speed sensors. Observe additional messages. 2. Contact Service. |

528 – SD Engine Speed 3rd Sensor

ZKP-Number: 12.500.102

| Cause | Corrective action |
|---|---|
| Redundant crankshaft sensor faulty; Short circuit or wire break | ▶ Check sensor and cabling, replace as necessary. |

576 – AL ESCM Override

ZKP-Number: 11.075.083

| Cause | Corrective action |
|---|-------------------|
| Violation of corrected MCR or DBR/MCR curve. Engine overload! | ▶ Reduce power. |

577 – SD T-Lube Oil Pan

ZKP-Number: 10.137.900

| Cause | Corrective action |
|--|---|
| Temperature sensor in oil pan defective; Short circuit or wire break | ▶ Check sensor and cabling, replace as necessary. |

582 – AL Emergency Stop Failed

ZKP-Number: 11.005.006

| Cause | Corrective action |
|--|---|
| This alarm occurs if the engine fails to come to a standstill within a specified (by parametrization) a period of time after the emergency stop signal was output. | ▶ The delay between the emergency stop signal and this alarm signal is set in parameter 1.1005.4. |

588 – SD P-Oil Refill Pump

ZKP-Number: 10.159.910

| Cause | Corrective action |
|---|---|
| Pressure sensor faulty; Short circuit or wire break | ▶ Check sensor and cabling, replace as necessary. |

596 – AL Develop PR Set

ZKP-Number: 18.004.645

| Cause | Corrective action |
|---|---|
| The parameter set used is a test parameter set. | ▶ The alarm remains active until a series-production parameter set was installed. |

600 – SD T-Exhaust A+B

ZKP-Number: 18.004.646

| Cause | Corrective action |
|--------------------------------|---|
| SD T-Exhaust A and T-Exhaust B | ▶ Check sensor and cabling, replace as necessary. |

601 – SD ETC1+ETC2

ZKP-Number: 13.011.227

| Cause | Corrective action |
|------------------|---|
| SD ETC1 and ETC2 | ▶ Check sensor and cabling, replace as necessary. |

625 – SD P-Fuel before Prefilter

ZKP-Number: 18.004.600

| Cause | Corrective action |
|---|---|
| Analog input signal for pressure before prefilter faulty; Short circuit or wire break | <ol style="list-style-type: none">1. Check pressure sensor and cabling, replace as necessary.2. Error cleared after restarting the engine. |

7 Task Description

7.1 Engine

7.1.1 Engine - Barring manually

Preconditions

- ☑ Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-----------------------------|-----------|------|
| Barring device | F6555766 | 1 |
| Ratchet head with extension | F30006212 | 1 |

DANGER




Rotating and moving engine parts.

Risk of crushing, danger of parts of the body being caught or pulled in!

- Before cranking the engine, make sure that there are no persons in the engine's danger zone.
- After finishing work on the engine, make sure that all safety devices are put back in place and all tools removed from the engine.

Engine – Barring manually

1. Remove guard plate.
Result: Safety switch preventing engine starting is activated.
2. Engage barring device (2) in ring gear (3) and install on flywheel housing.
3. Apply ratchet (1) to barring device (2).
4. Rotate crankshaft in engine direction of rotation. Apart from the normal compression resistance, there should be no resistance.
5. For barring device removal, follow reverse sequence of working steps.



7.1.2 Engine - Barring with starting system

Barring using the automation system

Refer to automation system operating instructions

7.2 Cylinder Liner

7.2.1 Cylinder liner – Endoscopic examination

Preconditions

- Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|-----------|------|
| Rigid endoscope | Y20097353 | 1 |

Preparatory steps

1. Remove cylinder head cover (→ Page 138).
2. Remove injector (→ Page 142).

Positioning crankshaft at BDC

1. Using barring gear, turn crankshaft until crankshaft journal of the cylinder to be inspected has reached BDC.
2. Insert endoscope into cylinder liner through injector seat.

Cylinder liner – Endoscopic examination

| Findings | Action |
|---|---|
| <ul style="list-style-type: none">• Thin carbon coating on circumference of carbon scraper ring• Slight localized additive deposits at top edge• Singular smooth areas at lower edge• Carbon deposits on circumference in clearance between top piston ring and bottom edge of carbon scraper ring• First signs of marks left by top piston ring• Bright mark on entire circumference• Consistent honing pattern without objections• First signs of marks left by lower cooling bores• Running pattern seems darker | No action required |
| <ul style="list-style-type: none">• Dark areas with even or varying degrees of discoloration• Beginning and end of the discoloration are not sharply defined and do not cover the entire stroke area• Dark areas in the upper section of the cooling bore, remaining circumference without objections• Piston rings without objections | Further endoscopic examination required as part of maintenance work |
| <ul style="list-style-type: none">• On the entire circumference, apart from light areas of discoloration (that do not impair operation) clearly darker stripes that start at the top piston ring• Heat discoloration in the direction of stroke and honing pattern damage• Heat discoloration of piston rings | Cylinder liner must be replaced; Service must be contacted |

1. Compile endoscopy report using the table.
2. Use technical terms for description of the liner surface (→ Page 131).
3. Depending on findings:
 - do not take any action or
 - carry out a further endoscopic examination as part of maintenance work or
 - contact Service; cylinder liner must be replaced.

Final steps

1. Install injector (→ Page 142).
2. Install cylinder head cover (→ Page 138).

7.2.2 Instructions and comments on endoscopic and visual examination of cylinder liners

Terms used for endoscopic examination

Use the terms listed below to describe the condition of the cylinder-liner surface in the endoscopic examination report.

| Findings | Explanations/Action |
|--------------------------|---|
| Minor dirt scores | Minor dirt scores can occur during the assembly of a new engine (honing products, particles, broken-off burrs). Removed cylinders clearly show such scoring on the running surface under endoscope magnification. Cannot be felt with the fingernail. Findings not critical. |
| Single scores | Clearly visible scores caused by hard particles. They usually start in the TDC area and cross through the hone pattern in the direction of stroke. Findings not critical. |
| Scored area | These areas consist of scores of different length and depth next to one another. In most cases, they are found at the 6-o'clock and 12-o'clock positions (inlet/exhaust) along the transverse engine axis. Findings not critical. |
| Smoothened area | Smoothened areas are on the running surface but almost the whole honing pattern is still visible. Smoothened areas appear brighter and more brilliant than the surrounding running surface. Findings not critical. |
| Bright area | Bright areas are on the running surface and show local removal of the honing pattern. Grooves from honing process are not visible any more. |
| Discoloration | This is caused by oxidation (surface discoloration through oil or fuel) and temperature differences around the liner. It appears rather darker within the honed structure in contrast to the bright metallic running surface. The honing pattern is undisturbed. Discolorations extend in stroke direction and may be interrupted. Findings not critical. |
| Corrosion fields / spots | Corrosion fields / spots result from water (condensed water) with the valves in the overlap (open) position. They are clearly visible due to the dark color of the honing groove bottom. This corrosion is not critical unless there is corrosion pitting. |
| Black lines | Black lines are a step towards heat discoloration. They are visible as a clear discoloration from TDC to BDC in the running surface and the start of localized damage to the honing pattern. Cylinder liners with a large number of black lines around the running surface have limited service life and should be replaced. |
| Burn mark | This is caused by a malfunction in the liner / ring tribosystem. Usually they run over the whole ring-travel area (TDC/BDC), starting at the first TDC-ring and becoming more visible from the second TDC-ring 2 onwards and less pronounced from TDC-ring 1. The honing pattern is usually no longer visible and displays a clearly defined (straight) edge to the undisturbed surface. The damaged surface is usually discolored. The circumferential length varies. Liners with burn marks, or heat discoloration, starting in TDC-ring 1 have to be replaced. |
| Seizure marks, scuffing | Irregular circumference lengths and depths. Can be caused either by the piston skirt or the piston crown. Material deposits on the liner (smear), heavy discoloration. Severe, visible scoring. Replace liner. |

Evaluation of findings and further measures

The findings in the start phase of oxidation discoloration and heat discoloration are similar. A thorough investigation and compliance with the above evaluation criteria allow an unambiguous evaluation. To avoid unnecessary disassembly work, it is recommended that another inspection be carried out after further operation of the engine.

7.3 Valve Drive

7.3.1 Valve gear - Lubrication

Preconditions


- Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Engine oil | | |

Valve gear - Lubrication

1. Remove cylinder head covers (→ Page 138).
2. Fill oil chambers of valve bridges with oil.
3. Fill oil chambers of rocker arms and adjusting screws with oil.
4. Install cylinder head covers (→ Page 138).



7.3.2 Valve clearance – Check and adjustment

Preconditions


- Engine shut down and starting disabled.
- Engine coolant temperature is max. 40 °C.
- Valves are closed.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|--------------------------|-----------|------|
| Feeler gauge | Y20098771 | 1 |
| Torque wrench, 60-320 Nm | F30452768 | 1 |
| Box wrench socket, 24 mm | F30039526 | 1 |
| Engine oil | | |

Preparatory steps

1. Remove cylinder head cover (→ Page 138).
2. Install barring device (→ Page 127).
3. The OT (TDC) marking (1) (if fitted) on the flywheel must not be used for reference.



- Rotate crankshaft with barring device in direction of engine rotation until the "OT-A1" marking and pointer are aligned.




Diagram for 8V engines (two crankshaft positions)




Diagram for 12V engines (two crankshaft positions)




Diagram for 16V engines (two crankshaft positions)





Diagram for 20V engines (two crankshaft positions)




Checking valve clearance at two crankshaft positions

- Check TDC position of piston in cylinder A1:
 - If the rocker arms are unloaded on cylinder A1, the piston is in firing TDC.
 - If the rocker arms are under load on cylinder A1, the piston is in overlap TDC.
- Check valve clearance with cold engine:
 - Inlet (long rocker arm) = 0.2 mm \pm 0.05 mm
 - Exhaust (short rocker arm) = 0.5 mm \pm 0.05 mm
- Check all valve clearances in two crankshaft positions (firing TDC and overlap TDC of cylinder A1) as per diagram.
 - Cylinder A1 is in firing TDC
 - Cylinder A1 is in overlap TDC
 - Inlet valve
 - Exhaust valve
- Use feeler gauge to determine the distance between valve bridge and rocker arm.
- If the deviation from the set value exceeds 0.1 mm, adjust valve clearance.

Adjusting valve clearance

1. Release locknut (1).
2. Insert feeler gauge (3) between valve bridge and rocker arm.
3. Use Allen key to set adjusting screw (2) so that the specified valve clearance is established.
4. Feeler gauge (3) must just pass through gap.



5. Tighten locknut (1) with torque wrench to the specified tightening torque, holding the adjusting screw (2) to prevent it from turning.

| Name | Size | Type | Lubricant | Value/Standard |
|---------|-----------|-------------------|--------------|----------------|
| Locknut | M16 x 1.5 | Tightening torque | (Engine oil) | 90 Nm +9 Nm |

6. Replace or rectify adjusting screws and/or locknuts which do not move freely.
7. Check valve clearance.

Final steps

1. Remove barring device (→ Page 127).
2. Install cylinder head cover (→ Page 138).

7.3.3 Cylinder head cover - Removal and installation

Preconditions


- Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|-------------------------|------|
| Gasket | (→ Spare Parts Catalog) | |

Removing cylinder head cover

1. Clean very dirty cylinder head covers prior to removal.
2. Remove screws.
3. Remove cylinder head cover with gasket from cylinder head.



Installing cylinder head cover

1. Clean mating face.
2. Check condition of gasket, replace if necessary.
3. Place gasket and cylinder head cover on cylinder head.
4. Install cylinder head cover.

7.4 Injection Pump / HP Pump

7.4.1 HP pump - Filling with engine oil

Preconditions

- Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Engine oil | | |

WARNING



Fuels are combustible.

Risk of fire and explosion!

- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

WARNING



Oils/oil vapors are combustible/explosive.

Risk of fire and explosion!

- Avoid open flames, electric sparks and ignition sources.
- Do not smoke.

NOTICE




HP fuel pump not filled with engine oil.

Damage to components, major material damage!

- Ensure that th HP fuel pump is filled with engine oil before it is installed or put into operation.

Filling HP pump

1. Remove plug screw (1).
2. Use pump oiler to fill HP pump with engine oil until engine oil emerges.
3. Install plug screw (1).



07300740a

7.4.2 HP pump - Relief bore check

DANGER



Rotating and moving engine parts.

Risk of crushing, danger of parts of the body being caught or pulled in!

- Only run the engine at low power. Keep away from the engine's danger zone.

WARNING




High level of engine noise when the engine is running.

Risk of damage to hearing!

- Wear ear protectors.

HP pump - Relief bore check

1. Visually inspect relief bore (1) for fuel discharge.
2. For jacketed HP lines, leakage is indicated by the yellow combined alarm.
3. If fuel discharge is found or indicated, contact Service.



7.5 Injection Valve / Injector

7.5.1 Injector - Replacement

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|-------------------------|------|
| Injector | (→ Spare Parts Catalog) | |

Replacing injector

- ▶ Remove injector and install new injector (→ Page 142).

7.5.2 Injector - Removal and installation

Preconditions

- Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|---|-------------------------|------|
| Installation/removal tool | F6789889 | 1 |
| Milling cutter | F30452739 | 1 |
| Torque wrench, 0.5-5 Nm | 0015384230 | 1 |
| Torque wrench, 10-60 Nm | F30452769 | 1 |
| Ratchet | F30027340 | 1 |
| Torque wrench, 60-320 Nm | F30452768 | 1 |
| Ratchet | F30027341 | 1 |
| Assembly paste (Optimoly Paste White T) | 40477 | 1 |
| Grease (Kluthe Hakuform 30-10/Emulgier) | X00029933 | 1 |
| Engine oil | | |
| O-ring | (→ Spare Parts Catalog) | |

WARNING



Fuels are combustible.

Risk of fire and explosion!


- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

Preparatory steps

1. Shut off fuel supply to engine.
2. Remove cylinder head cover (→ Page 138).

Removing injector

1. Disconnect connectors on injector.




TIM-ID: 0000000925 - 009


2. Remove HP fuel line (4).
3. Remove return line (5).

Note: While the adapter is removed, the injector is drained.


4. Remove adapter (3).
5. Remove screw (2) and take off hold-down clamp (1).



6. Install installation/removal tool on cylinder head.
7. Remove injector with installation/removal tool.
8. Remove installation/removal tool.






9. Remove sealing ring (4) from injector or use a self-made hook to take it out of the cylinder head.
10. Remove O-rings (3), O-ring (2) and damper ring (1) from injector.
11. Clean all mating and sealing surfaces.
12. Cover all connections and bores, or seal with suitable plugs.




Installing injector

1. Remove plug before installing the injector. (Do not remove the plug from the HP line before installing the adapter.)
2. Coat injector with assembly paste at the seat of the nozzle retaining nut.
3. Fit new sealing ring (included in the scope of supply of the injector) with grease on injector, observe installation position of sealing ring.
4. Fit new O-rings (3) (included in the scope of supply of the injector), O-ring (2) and damping ring (1) onto the injector and coat with grease.
5. Remove oil carbon from sealing face on cylinder head and protective sleeve with milling cutter.
6. Insert injector into cylinder head, ensuring that the HP line adapter is correctly aligned.
7. Press in injector with installation/removal tool.
8. Remove installation/removal tool.



9. Coat screw head mating face (2) and thread with engine oil.



10. Fit hold-down clamp (1) in the correct position and use torque wrench to tighten screw (2) to the specified initial tightening torque.

| Name | Size | Type | Lubricant | Value/Standard |
|-------|------|----------------|--------------|----------------|
| Screw | M12 | Preload torque | (Engine oil) | 5 Nm to 10 Nm |

Note: Ensure special cleanness.

11. Coat thread and sealing cone of adapter (3) with engine oil.
 12. Install adapter (3) and use torque wrench to tighten to the specified initial tightening torque.

| Name | Size | Type | Lubricant | Value/Standard |
|---------|------|----------------|--------------|----------------|
| Adapter | | Preload torque | (Engine oil) | 5 Nm to 10 Nm |

13. Tighten screw (2) with torque wrench to the specified tightening torque.

| Name | Size | Type | Lubricant | Value/Standard |
|-------|------|-------------------|-----------|----------------|
| Screw | M12 | Tightening torque | | 100 Nm + 10 Nm |

14. Tighten adapter (3) with torque wrench to the specified tightening torque.

| Name | Size | Type | Lubricant | Value/Standard |
|---------|------|-------------------|-----------|----------------|
| Adapter | | Tightening torque | | 100 Nm + 10 Nm |

15. Install return line (7).

Note: Ensure special cleanness.

16. Coat thread and sealing cone of HP line (5) with engine oil.

Note: Two HP line versions (single- and double-walled) with different torques as described below.

17. Mount single-walled HP line (5) and use torque wrench to tighten to the specified torque. Tightening sequence:
 1 Rail (6)
 2 Adapter (4)

| Name | Size | Type | Lubricant | Value/Standard |
|--------------------------|------|-------------------|-----------|----------------|
| Union nut / thrust screw | | Tightening torque | | 30 Nm + 5 Nm |


18. Mount double-walled HP line (5) and use torque wrench to tighten to the specified torque. Tightening sequence:
 - 1 Adapter (4)
 - 2 Rail (6)

| Name | Size | Type | Lubricant | Value/Standard |
|--------------------------|------|-------------------|-----------|----------------|
| Union nut / thrust screw | | Tightening torque | | 40 Nm + 5 Nm |

19. Fit connectors on injector.

Note: Failure to reset drift compensation (CDC) will void the emissions certification.

20. Reset drift compensation (CDC) with DiaSys® (→ E531920/...). If DiaSys® is not available, contact Service.



Final steps

1. Install cylinder head cover (→ Page 138).
2. Open fuel supply to engine.

7.6 Fuel Filter

7.6.1 Fuel filter - Replacement

Preconditions

- Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|--------------------|-------------------------|------|
| Oil filter wrench | F30379104 | 1 |
| Diesel fuel | | |
| Easy-change filter | (→ Spare Parts Catalog) | |
| Synthetic ring | (→ Spare Parts Catalog) | |

DANGER



Rotating and moving engine parts.

Risk of crushing, danger of parts of the body being caught or pulled in!

- Only run the engine at low power. Keep away from the engine's danger zone.

WARNING



Fuels are combustible.

Risk of fire and explosion!

- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

WARNING



High level of engine noise when the engine is running.

Risk of damage to hearing!

- Wear ear protectors.

NOTICE




Damage to component!

Severe material damage!

- For filter replacement with the engine running, operate the engine at low engine load.
- The filter which is to be replaced must be cut out for a brief period only.

Fuel filter replacement with the engine stopped


- A Both filters cut in
- B Left filter cut out
- C Right filter cut out
- 1 Fuel vent
- 2 Fuel filter



1. Cut out the filter to be replaced.
2. Unscrew switched off easy-change filter with oil filter wrench.
3. Clean sealing surface on filter head.
4. Check seal on new easy-change filter and moisten with fuel.
5. Fit SOLAS shield (→ Page 16).
6. Screw on easy-change filter and tighten by hand.
7. Set three-way cock to operating position (both filters cut in).
8. Replace further fuel filters in the same way.
9. Vent fuel system (1).

Fuel filter replacement with the engine running

1. Cut out the filter to be replaced.
2. Unscrew switched off easy-change filter with oil filter wrench.
3. Clean sealing surface on filter head.
4. Check seal on new easy-change filter and moisten with fuel.
5. Fit SOLAS shield (→ Page 16).
6. Screw on easy-change filter and tighten by hand.
7. Set three-way cock to operating position (both filters cut in).
8. Replace further fuel filters in the same way.



7.6.2 Fuel prefilter – Differential pressure gauge check and adjustment

DANGER



Rotating and moving engine parts.

Risk of crushing, danger of parts of the body being caught or pulled in!

- Only run the engine at low power. Keep away from the engine's danger zone.

WARNING




High level of engine noise when the engine is running.

Risk of damage to hearing!

- Wear ear protectors.

Adjusting differential pressure gauge

1. When installing the new filter element: align adjustable pointer (2) with pressure-indicating pointer (3) of pressure gauge (1).
2. Check differential pressure.



Checking differential pressure of fuel prefilter

1. With the engine running at full load or rated power, read off pressure at gauge (1).
2. If differential pressure as indicated between position of adjustable pointer (2) and pressure-indicating pointer (3) of pressure gauge is ≥ 0.3 bar, flush filter element of the cut-in filter (→ Page 151).

7.6.3 Fuel prefilter – Draining

Preconditions

- ☑ Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|-------------------------|------|
| Diesel fuel | | |
| Gasket | (→ Spare Parts Catalog) | |

WARNING





Fuels are combustible.

Risk of fire and explosion!

- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

Fuel prefilter – Draining

1. Cut out filter to be drained.
 - 1 Left filter cut in
 - 2 Right filter cut in
2. Open threaded vent plug (5) of filter to be drained.
3. Unlock drain valve (6) by pressing toggle and open it.
4. Drain water and contaminants from filter until pure fuel emerges.
5. Close drain valve (6).
6. Remove screws for cover and take off cover (2).
7. Fill filter housing with clean fuel.
8. Place new gasket in cover (2).
9. Fit cover with gasket and secure it with screws.
10. Cut in the cut-out filter again.
11. Close threaded vent plug (5) when fuel emerges.



7.6.4 Fuel prefilter – Flushing

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|-------------------------|------|
| Fuel | | |
| Seal | (→ Spare Parts Catalog) | |

DANGER



Rotating and moving engine parts.

Risk of crushing, danger of parts of the body being caught or pulled in!

- Only run the engine at low power. Keep away from the engine's danger zone.

WARNING



Fuels are combustible.

Risk of fire and explosion!

- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

WARNING




High level of engine noise when the engine is running.

Risk of damage to hearing!

- Wear ear protectors.

Fuel prefilter – Flushing


1. Cut out the contaminated filter.
 - 1 Left filter cut in
 - 2 Right filter cut in



2. Open vent plug (5) of the filter to be flushed.
3. Unlock drain cock (6) by pressing toggle, open it and drain fuel.

Result: Fuel flows from filtered side back to the unfiltered side, flushing the filter deposits downwards out of the filter.

4. Close vent plug (5) and drain cock (6).



Fuel prefilter – Filling with fuel

1. Stop engine (→ Page 82) and disable engine start.
2. Remove screws securing the cover and take off cover (2).
3. Fill filter housing with clean fuel.
4. Place new gasket in cover (2).
5. Fit cover with gasket and secure it with screws.
6. Check differential pressure (→ Page 149).

Result: If flushing did not lead to an improvement of the differential pressure, replace filter element of fuel prefilter (→ Page 153).

7.6.5 Fuel prefilter – Filter element replacement

Preconditions

- ☑ Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|-------------------------|------|
| Diesel fuel | | |
| Filter element | (→ Spare Parts Catalog) | |
| Gasket | (→ Spare Parts Catalog) | |

WARNING




Fuels are combustible.

Risk of fire and explosion!


- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

Replacing filter element

1. Cut out filter to be drained.
 - I Left filter cut in
 - II Right filter cut in



2. Open threaded vent plug (5) of contaminated filter.
3. Unlock drain valve (6) by pressing toggle and open it.
4. Drain water and dirt from filter.
5. Close drain valve (6).
6. Remove screws securing the cover and take off cover (2).
7. Remove spring housing (4) and filter element (3).
8. Insert new filter element (3) and spring housing (4).
9. Fill filter housing with clean fuel.
10. Place new gasket in cover (2).
11. Fit cover with gasket and secure it with screws.
12. Cut in the cut-out filter again.
13. Close threaded vent plug (5) when fuel emerges.
14. Adjust the differential pressure gauge (→ Page 149).



7.7 Exhaust Turbocharger

7.7.1 Compressor wheel - Cleaning

Preconditions

- Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|-----------|------|
| Cold cleaner | X00056750 | 1 |

WARNING



Compressed air gun ejects a jet of pressurized air.

Risk of injury to eyes and damage to hearing, risk of rupturing internal organs!

- Never direct air jet at people.
- Always wear safety goggles/face mask and ear defenders.

WARNING



Chemical substances.

Risk of irritation and chemical burns!

- Observe the instructions of the cleaning agent manufacturer.

NOTICE



Incorrect installation of electric lines .

Damage to component!

- Note down line assignment to connections before removal.

NOTICE



Inappropriate cleaning tool.

Risk of damage to component!

- Observe manufacturer's instructions.
- Use appropriate cleaning tool.

Preparatory steps

1. Drain engine coolant (→ Page 178).
2. Remove air filter (→ Page 159).
3. Remove exhaust system after exhaust turbocharger.
4. Remove exhaust flap with actuators.
5. Remove air intake.

Compressor wheel - Cleaning

Note: Do not use wire brush, scraper or similar tools for cleaning!

1. Clean compressor housing with paint brush or smooth brush.
2. Clean compressor wheel and bearing housing with cold cleaner.
3. Thoroughly blow out all parts with compressed air to remove cold cleaner.

Final steps

1. Install air intake.
2. Install exhaust flap with actuators.
3. Install exhaust system after exhaust turbocharger.
4. Install air filter (→ Page 159).
5. Fill with engine coolant (→ Page 179).

7.8 Charge-Air Cooling

7.8.1 Intercooler - Check water drain for coolant discharge and obstruction

DANGER



Rotating and moving engine parts.

Risk of crushing, danger of parts of the body being caught or pulled in!

- Only run the engine at low power. Keep away from the engine's danger zone.

WARNING



High level of engine noise when the engine is running.

Risk of damage to hearing!

- Wear ear protectors.

WARNING




Compressed air gun ejects a jet of pressurized air.

Risk of injury to eyes and damage to hearing, risk of rupturing internal organs!

- Never direct air jet at people.
- Always wear safety goggles/face mask and ear defenders.

Checking intercooler water drain for coolant discharge and obstruction

1. With the engine running check the drain bore(s) on the right and left of the engine for emerging air (at driving end). If no air emerges:
2. Clean drain bore(s) and blow out with compressed air.
3. Significant coolant discharge indicates a leaking intercooler. Contact Service.



Emergency measures prior to engine start with a leaking intercooler

1. Remove injectors (→ Page 142).
2. Bar engine manually (→ Page 127).
3. Bar engine with starting system to blow out cylinder chambers (→ Page 127).
4. Install injectors (→ Page 142).

7.9 Air Filter

7.9.1 Air filter - Replacement

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|-------------------------|------|
| Air filter | (→ Spare Parts Catalog) | |

Replacing the air filter

1. Remove old air filter and install new air filter (→ Page 159).
2. Reset signal ring of contamination indicator (→ Page 160).

7.9.2 Air filter - Removal and installation

Preconditions


- Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|------------------------|-----------|------|
| Torque wrench, 4-20 Nm | F30044239 | 1 |

Air filter – Removal and installation

1. Release clamp (2).
2. Remove air filter (1) and clamp (2) from connecting flange of intake housing (3).
3. Verify that there are no objects in the connecting flange of the intake housing (3) and clean it.
4. Place new air filter (1) with clamp (2) onto intake housing (3).



5. Tighten screw on clamp (2) with torque wrench to the specified tightening torque.

| Name | Size | Type | Lubricant | Value/Standard |
|-------|------|-------------------|-----------|----------------|
| Screw | - | Tightening torque | | 5 Nm |

7.10 Air Intake

7.10.1 Service indicator – Signal ring position check (optional)


Preconditions

- Engine is stopped and starting disabled.

Checking signal ring position

1. If the signal ring is completely visible in the control window (2), replace air filter (→ Page 158).
2. After installation of new filter, press reset button (1).

Result: Engaged piston with signal ring moves back to initial position.



7.11 Starting Equipment

7.11.1 Starter - Condition check

Preconditions

- Engine is stopped and starting disabled.

Checking starter condition

1. Check securing screws of starter for secure seating and tighten if required.
2. Check wiring (→ Page 193).

7.12 Lube Oil System, Lube Oil Circuit

7.12.1 Engine oil - Level check


Preconditions

- Engine is stopped and starting disabled.

Oil level check prior to engine start

1. Withdraw dipstick from guide tube and wipe it.
2. Insert dipstick into guide tube to stop, withdraw after approx. 10 seconds and check oil level.

- Note: After extended standstill, the oil level may exceed the mark (1) by up to 2 cm. This can be caused by oil flowing from e.g. oil filter or heat exchanger back to the oil pan.
3. The oil level must reach mark (1) or exceed mark (1) by up to 2 cm.
 4. Top up with oil to mark (1) as necessary (→ Page 163).
 5. Insert dipstick into guide tube up to the stop.



Oil level check after the engine is stopped

1. 5 minutes after stopping the engine, remove oil dipstick from the guide tube and wipe it.
2. Insert dipstick into guide tube to stop, withdraw after approx. 10 seconds and check oil level.
3. Oil level must be between marks (1) and (2).
4. Top up with oil to mark (1) as necessary (→ Page 163).
5. Insert dipstick into guide tube up to the stop.

7.12.2 Engine oil – Change

Preconditions

- ☑ Engine is stopped and starting disabled.
- ☑ Engine is at operating temperature.
- ☑ MTU Fluids and Lubricants Specifications (A001061/..) are available.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|-------------------------|------|
| Torque wrench | F30027337 | 1 |
| Ratchet | F30027341 | 1 |
| Engine oil | | |
| Sealing ring | (→ Spare Parts Catalog) | |

WARNING



- Hot oil.
Oil can contain combustion residues which are harmful to health.
Risk of injury and poisoning!
- Wear protective clothing, gloves, and goggles / safety mask.
 - Avoid contact with skin.
 - Do not inhale oil vapor.

Oil change without semirotary hand pump: Draining oil via drain plug(s) on oil pan


1. Provide a suitable container to collect the oil.
2. Remove drain plug(s) and drain oil.
3. Install drain plug(s) with new sealing ring.

Oil change using semirotary hand pump: Oil extraction

1. Provide a suitable container to collect the oil.
2. Extract all oil from oil pan using the semirotary hand pump.

Draining residual oil at equipment carrier

1. Provide a suitable container to collect the oil.
2. Remove drain plugs (1) and (2) and drain oil:
 - Approx. 12 liters at (1)
 - Approx. 5 liters at (2)
3. Check oil indicator filter (→ Page 171).
4. Install drain plug(s) with new sealing ring.




5. Tighten drain plugs (1) and (2) with torque wrench to the specified torque:

| Name | Size | Type | Lubricant | Value/Standard |
|-------|-----------|-------------------|-----------|----------------|
| Screw | M26 x 1.5 | Tightening torque | | 100 Nm+10Nm |

Filling with new oil

1. Open cover (1) on filler neck.
2. Pour oil in at filler neck up to "max." mark at oil dipstick.
3. Close cover (1) on filler neck.
4. Check engine oil level (→ Page 162).
5. After oil change, bar engine with starting system (→ Page 128).






7.12.3 Engine oil – Sample extraction and analysis

Preconditions

- ☑ MTU Fluids and Lubricants Specifications (A001061/..) are available.


Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|---------------|------|
| MTU test kit | 5605892099/00 | 1 |

| | |
|---|---|
| DANGER  | Rotating and moving engine parts. Risk of crushing, danger of parts of the body being caught or pulled in! <ul style="list-style-type: none">• Only run the engine at low power. Keep away from the engine's danger zone. |
| WARNING  | Hot oil. Oil can contain combustion residues which are harmful to health. Risk of injury and poisoning! <ul style="list-style-type: none">• Wear protective clothing, gloves, and goggles / safety mask.• Avoid contact with skin.• Do not inhale oil vapor. |
| WARNING  | High level of engine noise when the engine is running. Risk of damage to hearing! <ul style="list-style-type: none">• Wear ear protectors. |

Engine oil sample extraction and analysis

1. With the engine running at operating temperature, open screw on automatic oil filter by 1 to 2 turns.
2. Drain approx. 2 liters engine oil to flush out the oil sludge.
3. Drain approx. 1 liter engine oil into a clean container.
4. Close screw.
5. Using the equipment and chemicals in the MTU test kit, analyze the engine oil for:
 - Dispersion capability (spot test);
 - Water content;
 - Dilution by fuel.



7.13 Oil Filtration / Cooling

7.13.1 Oil indicator filter - Cleaning

Preconditions

- Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|---------------------------|-------------------------|------|
| Cleaner (Snow-White 11-0) | X00054118 | 1 |
| Cleaner (Hakupur 312) | 30390 | 1 |
| Engine oil | | |
| O-ring | (→ Spare Parts Catalog) | 1 |
| O-ring | (→ Spare Parts Catalog) | 1 |
| Strainer | (→ Spare Parts Catalog) | 1 |

WARNING



- Hot oil.
Oil can contain combustion residues which are harmful to health.
Risk of injury and poisoning!
- Wear protective clothing, gloves, and goggles / safety mask.
 - Avoid contact with skin.
 - Do not inhale oil vapor.


WARNING



- Compressed air gun ejects a jet of pressurized air.
Risk of injury to eyes and damage to hearing, risk of rupturing internal organs!
- Never direct air jet at people.
 - Always wear safety goggles/face mask and ear defenders.

Removing strainer

1. Remove cover (1).
2. Remove strainer from housing and allow oil to drip into container.



TIM-ID: 0000014187 - 004

Cleaning strainer

1. Shake coarse contamination out of strainer.
2. Clean all metallic parts with cleaner (Snow-White 11-0), then rinse with cleaner (Hakupur 312).
3. Use a soft brush to remove stubborn deposits from strainer if required. Ensure that the mesh is not damaged.
4. Carefully blow out strainer with compressed air from outside to inside.

Checking strainer

1. Check strainer for damage.
2. Fit new strainer if damaged or severely contaminated.

Installing strainer

1. Insert strainer with new O-ring into housing.
2. Fill housing with new engine oil.
3. Install cover (1) with new O-ring.

7.13.2 Automatic oil filter – Oil filter candles replacement

Preconditions

- Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|---|-------------------------|------|
| Grease (Kluthe Hakuform 30-10/Emulgier) | X00029933 | 1 |
| Engine oil | | |
| O-ring | (→ Spare Parts Catalog) | |
| Oil filter candles | (→ Spare Parts Catalog) | |

WARNING



- Hot oil.
Oil can contain combustion residues which are harmful to health.
Risk of injury and poisoning!
- Wear protective clothing, gloves, and goggles / safety mask.
 - Avoid contact with skin.
 - Do not inhale oil vapor.


NOTICE




- Contamination of components.
Damage to component!
- Observe manufacturer's instructions.
 - Check components for special cleanliness.

Removing oil filter candles

1. Remove nuts (2) from oil filter cover (1).
2. Remove oil filter cover (1).




3. Withdraw oil filter element (1).
4. Remove O-ring.



5. Remove screw (2).
6. Withdraw plastic spinner (1) with spring.
7. Remove nut (3).
8. Take off spring washer and washer.
9. Remove screw (4).
10. Remove flushing arm (5) from screen plate (6).



11. Turn filter element by 180° and use appropriate tool to push out filter candles (1).
12. Turn filter insert by 180° and insert new filter candles (1) with chamfer facing downwards.



Installing oil filter candles

1. For installation follow reverse sequence of working steps.
2. Additionally, the following instructions are to be observed:
 - Replace all sealing elements.
 - Coat O-rings with grease.
 - Insert O-rings in grooves.
 - Observe position of cylinder screw to elongated hole on shaft.

7.13.3 Oil indicator filter – Cleaning and check

Preconditions

- ☑ Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|---------------------------|-------------------------|------|
| Cleaner (Snow-White 11-0) | 40460 | 1 |
| Cleaner (Hakupur 312) | 30390 | 1 |
| Engine oil | | |
| Strainer | (→ Spare Parts Catalog) | |
| Square-section ring | (→ Spare Parts Catalog) | |
| O-ring | (→ Spare Parts Catalog) | |

WARNING



- Hot oil.
Oil can contain combustion residues which are harmful to health.
Risk of injury and poisoning!
- Wear protective clothing, gloves, and goggles / safety mask.
 - Avoid contact with skin.
 - Do not inhale oil vapor.

WARNING



- Compressed air gun ejects a jet of pressurized air.
Risk of injury to eyes and damage to hearing, risk of rupturing internal organs!
- Never direct air jet at people.
 - Always wear safety goggles/face mask and ear defenders.


NOTICE



- Inappropriate cleaning tool.
Risk of damage to component!
- Observe manufacturer's instructions.
 - Use appropriate cleaning tool.

Removing strainer

1. Clean oil indicator filter before disassembling it.
2. Remove screws (1).
3. Take off cover (2) with O-ring (3).
4. Take strainer (5) from filter housing.



18300256b

Checking strainer

| Item | Findings | Measure |
|---------------------|-------------------|---|
| Strainer | Metallic residues | <ul style="list-style-type: none">• Clean• Monitor engine operation• Check strainer daily• Contact Service |
| Strainer | Damaged | Fit new part |
| Square-section ring | Damaged | Fit new part |
| O-ring | Damaged | Fit new part |

Cleaning strainer

1. Wash strainer (5) with cleaner.
2. Remove stubborn deposits with soft brush.
3. Blow out strainer (5) with compressed air from inside.

Installing strainer

1. Coat square-section ring (4) on strainer (5) with engine oil and install strainer (5).
2. Coat O-ring (3) with engine oil and fit in filter housing.
3. Fit cover (2) and secure with screws (1) and washers.

7.13.4 Centrifugal oil filter – Cleaning and filter-sleeve replacement

Preconditions

- Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|---------------------------|-------------------------|------|
| Torque wrench, 6-50 Nm | F30027336 | 1 |
| Cold cleaner (Hakutex 60) | X00056750 | 1 |
| Filter sleeve | (→ Spare Parts Catalog) | |
| Sealing ring | (→ Spare Parts Catalog) | |

WARNING



- Hot oil.
Oil can contain combustion residues which are harmful to health.
Risk of injury and poisoning!
- Wear protective clothing, gloves, and goggles / safety mask.
 - Avoid contact with skin.
 - Do not inhale oil vapor.

WARNING



- Compressed air gun ejects a jet of pressurized air.
Risk of injury to eyes and damage to hearing, risk of rupturing internal organs!
- Never direct air jet at people.
 - Always wear safety goggles/face mask and ear defenders.

Centrifugal oil filter – Cleaning and filter-sleeve replacement

1. Remove clamp (14).
2. Release cover screw (2) and take off cover (1).
3. Carefully lift rotor (11), allow oil to drain and remove from housing.
4. Holding the rotor (11) firmly, release rotor cover nut (3).
5. Take off rotor cover (4).
6. Remove filter sleeve (6).
7. Measure thickness of oil residues on filter sleeve (6).

Result: If the thickness of the oil residue layer exceeds the maximum value of 45 mm, shorten the maintenance interval.

8. Disassemble rotor tube (7), conical disk (8) and rotor base (10).
9. Wash rotor cover (4), rotor tube (7), conical disk (8) and rotor base (10) with cold cleaner.
10. Blow out with compressed air.
11. Check sealing ring (9), fit new one if necessary.
12. Assemble rotor tube (7), conical disk (8) and rotor base (10) with sealing ring (9).
13. Insert new filter sleeve (6) in rotor tube (7) with the smooth paper surface facing the wall.
14. Check sealing ring (5), fit new one if necessary.
15. Mount rotor cover (4) with sealing ring (5).
16. Tighten rotor cover nut (3) with torque wrench to the specified torque.


| Name | Size | Type | Lubricant | Value/Standard |
|------|------|-------------------|-----------|----------------|
| Nut | | Tightening torque | | 35 Nm to 45 Nm |

17. Place rotor (11) in housing (12) and check for ease of movement.
18. Check sealing ring (13), fit new one if necessary.
19. Fit sealing ring (13) on housing (12).
20. Fit cover (1).
21. Tighten cover screw (2) by hand.
22. Install clamp (14) and tighten with torque wrench to the specified torque.

| Name | Size | Type | Lubricant | Value/Standard |
|-------|------|-------------------|-----------|----------------|
| Clamp | | Tightening torque | | 8 Nm to 10 Nm |

23. Tighten cover screw (2) with torque wrench to the specified torque.

| Name | Size | Type | Lubricant | Value/Standard |
|-------|------|-------------------|-----------|----------------|
| Screw | | Tightening torque | | 5 Nm to 7 Nm |




7.14 Coolant Circuit, General, High-Temperature Circuit

7.14.1 Venting points


Coolant lines on ETC

1 Venting point



Vent line – Cross-distribution expansion tank

1 Venting point



7.14.2 Engine coolant – Level check

Preconditions

- ☑ Engine is stopped and starting disabled.
- ☑ MTU Fluids and Lubricants Specifications (A001061/..) are available.

WARNING



Coolant is hot and under pressure.

Risk of injury and scalding!


- Let the engine cool down.
- Wear protective clothing, gloves, and goggles / safety mask.

Checking engine coolant level at filler neck:

1. Turn breather valve on coolant expansion tank counterclockwise to the first stop and allow pressure to escape.
2. Continue to turn breather valve counterclockwise and remove.
3. Check engine coolant level (coolant must be visible at the bottom edge of the filler neck's cast eye).

Checking engine coolant level at remote cooler:

1. Check engine coolant level (coolant must be visible at marker plate).
2. Top up engine coolant if necessary (→ Page 179).
3. Check and clean breather valve.
4. Place breather valve on filler neck and close.



Checking engine coolant level via level sensor:

1. Switch on engine control system and check readings on the display.
2. Top up engine coolant if necessary (→ Page 179).

7.14.3 Engine coolant - Change

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Coolant | | |

Engine coolant change

1. Drain engine coolant (→ Page 178).
2. Fill with engine coolant (→ Page 179).

7.14.4 Engine coolant draining

Preconditions

- Engine is stopped and starting disabled.

WARNING



Coolant is hot and under pressure.

Risk of injury and scalding!


- Let the engine cool down.
- Wear protective clothing, gloves, and goggles / safety mask.

Preparatory steps

1. Provide an appropriate container to drain the coolant into.
2. Switch off preheating unit.

Engine coolant draining

1. Turn breather valve of filler neck on expansion tank counterclockwise to first stop and allow pressure to escape.
2. Continue to turn breather valve counterclockwise and remove.
3. Draw off precipitated corrosion inhibitor oil from the expansion tank through filler neck.
4. Open drain valves and drain plugs and drain coolant at the following points:
 - Preheating unit
 - Elbow of HT coolant pump (2)
 - Crankcase, left and right side (3)
 - T piece (5) on engine driving end;
 - Intercooler
 - Carrier housing (1)



Final steps

1. Seal all open drain points
2. Place breather valve onto filler neck and close it.

7.14.5 Engine coolant - Filling

Preconditions

- ☑ Engine is stopped and starting disabled.
- ☑ MTU Fluids and Lubricants Specifications (A001061/..) are available.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Engine coolant | | |

WARNING



Coolant is hot and under pressure.

Risk of injury and scalding!

- Let the engine cool down.
- Wear protective clothing, gloves, and goggles / safety mask.

NOTICE




Cold coolant in hot engine can cause thermal stress.

Possible formation of cracks in the engine!

- Fill / top up coolant only into cold engine.


Preparatory steps

1. Turn breather valve on filler neck of expansion tank counterclockwise to first stop and allow pressure to escape.
2. Continue to turn breather valve counterclockwise and remove.



Filling coolant through filler neck

1. Open vent points on distributor, oil heat exchanger and exhaust turbochargers (arrowed).
2. Fill in coolant in expansion tank via filler neck until coolant level at top edge of filler neck remains constant.
3. When coolant emerges from the vent points, close vent points one by one, proceeding from the lowest point upwards.
4. Check satisfactory condition of breather valve and clean sealing surfaces if required.
5. Place breather valve on filler neck and close until it engages (first lock).
6. Start engine (→ Page 73).
7. After 10 seconds of engine operation without load, shut down the engine (→ Page 82).
8. Turn breather valve counterclockwise and remove.
9. Check coolant level (→ Page 176) and top up engine coolant as required:
 - a) Repeat the steps from “Start engine” (→ Step 6) until coolant no longer needs topping up.
 - b) Check satisfactory condition of breather valve and clean sealing surfaces if required.
 - c) Place breather valve on filler neck and close.



Final steps

1. Start engine and run without load for some minutes.
2. Check coolant level (→ Page 176) and top up coolant as required.

7.14.6 Engine coolant pump – Relief bore check

DANGER



Rotating and moving engine parts.

Risk of crushing, danger of parts of the body being caught or pulled in!

- Only run the engine at low power. Keep away from the engine's danger zone.

WARNING




High level of engine noise when the engine is running.

Risk of damage to hearing!

- Wear ear protectors.

Engine coolant pump – Relief bore check

1. Check relief bore for oil and coolant discharge.
2. Stop engine (→ Page 73) and disable engine start, observe general safety instructions on maintenance and repair.
3. Clean the relief bore with a wire if it is dirty.
 - Permissible coolant discharge: up to 10 drops per hour;
 - Permissible oil discharge: up to 5 drops per hour.
4. If discharge exceeds the specified limits: Contact Service.






7.14.7 Engine coolant – Sample extraction and analysis

Preconditions

- MTU Fluids and Lubricants Specifications (A001061/..) are available.


Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|---------------|------|
| MTU test kit | 5605892099/00 | 1 |

| | |
|---|---|
| DANGER  | Rotating and moving engine parts. Risk of crushing, danger of parts of the body being caught or pulled in! <ul style="list-style-type: none">• Only run the engine at low power. Keep away from the engine's danger zone. |
| WARNING  | Coolant is hot and under pressure. Risk of injury and scalding! <ul style="list-style-type: none">• Let the engine cool down.• Wear protective clothing, gloves, and goggles / safety mask. |
| WARNING  | High level of engine noise when the engine is running. Risk of damage to hearing! <ul style="list-style-type: none">• Wear ear protectors. |

Engine coolant – Sample extraction and analysis

1. With the engine running, open drain valve (1).
2. Flush sampling point by draining approx. 1 liter coolant.
3. Drain approx. 1 liter of engine coolant into a clean container.
4. Close drain valve (1).
5. Use the equipment and chemicals of the MTU test kit to check the coolant for:
 - Antifreeze concentration
 - Corrosion inhibitor concentration
 - pH value
6. Engine coolant change intervals (→ MTU Fluids and Lubricants Specifications).



TIM-ID: 0000014608 - 006

7.15 Raw Water Pump with Connections

7.15.1 Raw water pump - Relief bore check

DANGER



Rotating and moving engine parts.

Risk of crushing, danger of parts of the body being caught or pulled in!

- Only run the engine at low power. Keep away from the engine's danger zone.

WARNING




High level of engine noise when the engine is running.

Risk of damage to hearing!

- Wear ear protectors.

Raw water pump – relief bore check

1. Check relief bore for oil and raw water discharge.
2. Stop engine (→ Page 73) and disable engine start, observe general safety instructions on maintenance and repair.
3. Clean the relief bore with a wire if it is dirty.
 - Permissible raw water discharge: up to 10 drops per hour;
 - Permissible oil discharge: up to 5 drops per hour.
4. If discharge exceeds the specified limits: Contact Service.



7.16 Battery-Charging Generator


7.16.1 Battery-charging generator drive - Coupling condition check

Preconditions

- Engine is stopped and starting disabled.

Battery-charging generator drive - Coupling condition check

1. Remove protective cover.
2. Check resilient coupling for cracks (arrow) and plastic deformation.
3. In case of severe deformation or cracking: (→ Contact Service).
4. Install protective cover.



7.17 Engine Mounting / Support

7.17.1 Engine mounting - Check

Engine mounting - Check

| Item | Findings | Action |
|--------------------------|---|----------------------------|
| Visually inspect mounts. | <ul style="list-style-type: none">• Damage• Brittleness• Deformation• Crack formation• Swelling visible | Replace (contact Service). |

7.18 Auxiliary PTO

7.18.1 Bilge pump - Relief bore check

DANGER



Rotating and moving engine parts.

Risk of crushing, danger of parts of the body being caught or pulled in!

- Only run the engine at low power. Keep away from the engine's danger zone.

WARNING




High level of engine noise when the engine is running.

Risk of damage to hearing!

- Wear ear protectors.

Bilge pump - Relief bore check

1. Check relief bores for oil and water discharge.
2. Stop engine (→ Page 82) and disable engine start.
3. Clean relief bores with a wire if dirty.
 - Permissible water discharge: up to 10 drops per hour;
 - Permissible oil discharge: up to 5 drops per hour
4. If discharge exceeds the specified limits: Contact Service.



7.19 Fuel Supply System

7.19.1 Water drain valve - Check

Water drain valve - Check

1. Open water drain valve.
2. Check water outlet for obstructions.
3. Close water drain valve.

7.19.2 Differential pressure gauge – Check

WARNING



Fuels are combustible.

Risk of fire and explosion!

- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

Checking differential pressure gauge

1. Switch on fuel treatment system (→ Page 81).
2. Set the alarm points at the differential pressure gauge to zero.

Result: Alarm is initiated with preset delay.

3. Reset the alarm points at the differential pressure gauge to the specified values.

7.19.3 Water level probe (3-in-1 rod electrode) - Check

Preconditions

- System is put out of operation and emptied.

WARNING



Fuels are combustible.

Risk of fire and explosion!

- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

Checking water level probe (3-in-1 rod electrode)

1. Disconnect connector from water level probe.
2. Unscrew water level probe.
3. Disconnect connector from water level probe.
4. Immerse water level probe into a tank filled with water until water level reaches the thread.
5. Switch system on.
Result: Water drain valve opens.
6. Leave water level probe in tank.
Result: Alarm must be triggered with the preset delay.
7. Switch off the system.
8. Disconnect connector from water level probe.
9. Remove water level probe from tank.
10. Screw in water level probe.
11. Connect connector for water level probe.
12. Fill and vent the system then put it into operation.

7.19.4 Pump capacity – Check

WARNING



Fuels are combustible.

Risk of fire and explosion!

- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

Pump capacity – Check

1. Install suitable pressure gauge at the neck of the intake side of the pump.
2. Check pump pressure.
 - a) Switch on fuel treatment system (→ Page 81).

Note: The pressure limiting valve at the pump might respond and open. Audible noise is caused by overflowing fuel and can be disregarded.

- b) Close ball valve at the outlet of the fuel treatment system.
 - c) Check pressure at the pressure gauge in the inlet to the fuel treatment system and note down.
3. Check pump pressure with reduced suction.
 - a) Reduce suction pressure of pump to -0.8 bar with the shutoff valve at the pump intake side.
 - b) Check pressure at the pressure gauge in the inlet to the fuel treatment system and note down.
 - c) Open ball valve at inlet and outlet of fuel treatment system.
 4. Calculate wear limit.

Example:

| | |
|------------------------------------|-------|
| Measured value (normal condition). | 3 bar |
|------------------------------------|-------|

| | |
|---|---------|
| Measured value (reduced suction condition). | 2.6 bar |
|---|---------|

If the measured value (reduced suction condition) is 10% lower than the measured value (normal condition), the wear limit is reached. Repair pump (contact Service).

7.19.5 Coalescer filter element – Replacement

Preconditions

- ☑ System is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|--------------------------|-------------------------|------|
| Torque wrench, 6-50 Nm | F30027336 | 1 |
| Ratchet | F30027339 | 1 |
| Diesel fuel | | |
| Engine oil | | |
| Coalescer filter element | (→ Spare Parts Catalog) | |
| Gasket | (→ Spare Parts Catalog) | |

WARNING



Fuels are combustible.

Risk of fire and explosion!

- Avoid open flames, electrical sparks and ignition sources.
- Do not smoke.

NOTICE



Contamination of components.

Damage to component!

- Observe manufacturer's instructions.
- Check components for special cleanliness.

NOTICE




Incorrect installation of components and lines.

Damage to component!

- Ensure that components/lines are installed so that they are never under tension or strain.
- Ensure correct installation position of components.

Coalescer filter element – Replacement

1. Close ball valve at the inlet and outlet of the fuel treatment system.
2. Open drain valve.
3. Drain fuel.
4. Close drain valve.
5. Remove nuts (9) and washers (2).
6. Remove screws (1).
7. Remove cover with gasket (10).
8. Remove nut (3), washer (8) and end plate (4).
9. Remove coalescer filter element (5).
10. Catch fuel as it runs out.
11. Clean housing with a non-linting cloth, rinse with fuel if required.
12. Check housing for corrosion.
13. Clean housing sealing surfaces.
14. Install coalescer filter element (5).
15. Install end plate (4), washer (8) and nut (3).



36400024b

16. Tighten nut (3) to specified tightening torque using a torque wrench.

| Name | Size | Type | Lubricant | Value/Standard |
|------|------|-------------------|--------------|----------------|
| Nut | M16 | Tightening torque | (Engine oil) | 30 Nm +3 Nm |

17. Fit gasket (10).

18. Install cover.

19. Install screws (1), washers (2) and nuts (9).

20. Tighten nuts (9).

21. Open ball valve at the inlet and outlet of the fuel treatment system.

Result: The fuel treatment system is ready for operation.

7.20 Wiring (General) for Engine/Gearbox/Unit

7.20.1 Engine wiring - Check

Preconditions

- Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|-----------|------|
| Isopropyl alcohol | X00058037 | 1 |

Checking engine wiring

1. Check securing screws of cable clamps on engine and tighten loose threaded connections.
2. Ensure that cables are fixed in their clamps and cannot swing freely.
3. Check that cable clamps are firm, tighten loose cable clamps.
4. Replace faulty cable clamps.
5. Visually inspect the following electrical line components for damage:
 - Connector housing
 - Contacts
 - Sockets
 - Cables and terminals
 - Plug-in contacts

Result: Contact Service if cable conductors are damaged.

Note: Close male connectors that are not plugged in with the protective cap supplied.

6. Clean dirty connector housings, sockets and contacts using isopropyl alcohol.
7. Ensure that all sensor connectors are securely engaged.

7.21 Accessories for (Electronic) Engine Governor / Control System

7.21.1 CDC parameters - Reset with DiaSys®

Preconditions

- Engine is stopped and starting disabled.

Resetting CDC parameters (DiaSys® is available)

Note: The CDC parameters must be reset, otherwise the emission certification of the engine is no longer applicable.

- ▶ Reset the CDC parameters with DiaSys® (→ Manufacturer's documentation).

Resetting CDC parameters (DiaSys® is not available)

Note: The CDC parameters must be reset, otherwise the emission certification of the engine is no longer applicable.

- ▶ Contact Service.

7.21.2 EMU and connectors – Cleaning

Preconditions

- Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|----------|------|
| Isopropyl alcohol | | |

EMU and connectors – Cleaning

1. Remove coarse dirt from housing surface using a cloth moistened with isopropyl alcohol.
2. Remove dirt from the connector and cable surfaces with isopropyl alcohol.
3. Check legibility of cable labels. Clean or replace illegible labels.

Cleaning severely contaminated connectors on EMU

1. Release the latch and pull off connector.
2. Clean connector housings, connector socket housings and all contacts with isopropyl alcohol.
3. When connectors, sockets and all contacts are dry: Fit connectors and latch.

7.21.3 Limit switch for start interlock - Check


Preconditions

- Engine is stopped and starting disabled.

Note: In the OFF position, the limit switch initiates a start interlock, i.e. the engine cannot be started.

Checking limit switch for start interlock

1. Check whether switches (3) and guard plate (1) with engine support (4) are installed on both sides of flywheel housing (2).
2. Check whether both switches (3) are actuated.
3. If switches (3) and/or guard plate (1) with engine support (4) is/are not installed:
 - Screw on guard plate (1) with engine support (4).
 - Then screw on switch (3), ensuring that the switch (3) is actuated by the guard plate (1).
4. If switch (3) and guard plate (1) are installed, but switch (3) is in the OFF position:
 - Make certain that the guard plate (1) at the side of the switch (3) is not distorted.
 - Release guard plate (1) and screw on such that the switch (3) is actuated.



7.21.4 Engine governor and connectors – Cleaning

Preconditions

- Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|-----------|------|
| Isopropyl alcohol | X00058037 | 1 |

Note: Always use test connectors to enter the connectors. Never use test leads for this purpose. Otherwise the contacts could be bent.

Engine governor and connectors – Cleaning

1. Remove coarse dirt from housing surface with isopropyl alcohol.
2. Remove dirt from connector and cable surfaces with isopropyl alcohol.
3. Check legibility of cable labels. Clean or replace illegible labels.

Cleaning severely contaminated connectors on the engine governor

Note: Seal unused connectors with the supplied protective cap.

1. Release the latch and pull off connectors.
2. Clean connector housings, connector socket housings and all contacts with isopropyl alcohol.
3. When connectors, sockets and all contacts are dry: Fit connectors and lock them.


7.21.5 Engine Control Unit ECU 7 - Checking plug connections

Preconditions

- Engine is stopped and starting disabled.

Check plug connections on ECU 7

1. Check all connectors on ECU for firm seating. Ensure that clips (3) are engaged.
2. Check screws (2) of cable clamps on ECU for firm seating. Ensure that cable clamps are not faulty.




7.21.6 Engine Monitoring Unit EMU 8 - Plug connections check

Preconditions

- ☑ Engine is stopped and starting disabled.

Checking EMU plug connections

1. Check both connectors on EMU (2) for firm seating. Make sure that clips (3) are engaged.
2. Check screws (1) of cable clamps on EMU (2) for firm seating. Make sure that cable clamps are not defective.




7.21.7 Interface module plug connections - Check

Preconditions

- Engine is stopped and starting disabled.

Checking EIM plug connections

1. Check both Tyco plugs (62-pole) (1) on EIM for firm seating. Make sure that the clips (2) are engaged.
2. Check screws (3) of cable clamps on EIM for firm seating. Ensure that cable clamps are not faulty.



7.21.8 ECU 7 engine governor - Removal and installation

Preconditions

- Engine is stopped and starting disabled.

NOTICE




Wrong engine governor installed.

Engine damage!

- When reassembling an engine, make sure that the governor with the data record for the given engine is installed.

Removing engine governor from engine

1. Note or mark assignment of cables and connectors.
2. Remove all screws (2).
3. Undo latches (3) of the connectors.
4. Disconnect all connectors.
5. Remove screws (1).
6. Take off engine governor.



Installing engine governor on engine

1. Install in reverse order. Ensure correct assignment of connectors and sockets in so doing.
 2. Check resilient mount before installing.
- Result: Replace resilient mount if porous or defective.

7.21.9 EMU 8 - Removal and installation

Preconditions

- Engine is stopped and starting disabled.

NOTICE




Wrong engine governor installed.

Engine damage!

- When reassembling an engine, make sure that the governor with the data record for the given engine is installed.

Remove ECU with EMU from engine

1. Note or mark assignment of cables and connectors.
2. Remove all screws (2).
3. Undo clips (3) on connectors.
4. Disconnect all connectors.
5. Remove screws (1).
6. Remove ECU (1) with EMU (4).



Removing EMU

1. Unscrew screws on base of EMU (4).
2. Remove EMU (4) from ECU (1).

Installing EMU

1. Place EMU (4) on ECU (1).
2. Screw in and tighten screws on base of EMU (4).

Installing ECU with EMU on engine

1. Install in reverse order. Ensure correct assignment of plugs and sockets.
2. Check resilient mount before installing.

Result: If resilient mount is porous or defective then replace it.


7.21.10 Engine Interface Module EIM - Removal and installation

Preconditions

- Engine is stopped and starting disabled.

Removing EIM from the engine

1. Note or mark assignment of cables and connectors.
2. Unscrew all screws (1).
3. Undo clips (2) on connectors.
4. Disconnect all connectors.
5. Unscrew power and starter cable.
6. Remove screws (3).
7. Take off EIM.



Installing EIM on the engine

1. Install in reverse order. When doing so, observe correct assignment between cables and plugs.
 2. Check seal before installing.
- Result: Replace seal if porous or defective.

Downloading software

1. The new EIM still does not have appropriate FSW and parameter/descriptor module (the diagnostic lamp (DILA) indicates flashing code 4 when the power supply is connected, (→ Page 204)).
2. The FSW and the parameter/descriptor module must first be downloaded from the central database (CDB) based on the relevant engine number using the DiaSys software tool, and then loaded in the EIM.

7.21.11 Diagnostic features of EIM

Diagnostic lamp (DILA)


A diagnostic lamp (LED, blue) is integrated in the housing of the Engine Interface Module (EIM).

It indicates the operating status of the EIM.

Functions of diagnostic lamp DILA

| | |
|--------------|---|
| DILA lights | Engine Interface Module (EIM) is OK |
| DILA dark | EIM supply voltage missing or diagnostic lamp activation is faulty. |
| DILA flashes | Hardware or software fault in the Engine Interface Module. |

The diagnostic lamp (DILA) signals the following states:



- | | | |
|-----------------------|-----------------------------|-----------------------|
| 1 Time in seconds | 4 Application loader active | 7 No firmware |
| 2 Timing: 1/8 s | 5 External RAM faulty | 8 Application crashed |
| 3 Ready for operation | 6 External FLASH faulty | |

Fuse lamp (SILA)

A second indicator is the fuse lamp.

This is also integrated in the housing of the Engine Interface Module. It indicates the status of the fuses.


An orange LED is provided to allow diagnosis of a “tripped fuse” fault directly at the unit as it is often difficult to pinpoint a fault in the field without cabling diagrams.

This LED is activated by the controller.

Functions of fuse lamp SILA

| | |
|---------------------|---------------------------------|
| SILA dark | Norma operating state. |
| SILA flashes orange | One or more fuses have tripped. |


The fuse lamp (SILA) signals the following states:



- | | | |
|---|---|---|
| 1 Preamble | 6 VSP current path failed (S5) | 11 ES pushbutton current path failed – 24V external (S10) |
| 2 ECU current path failed (S1) | 7 SLD current path failed (S6) | 12 Key switch current path failed (S11) |
| 3 MCS current path failed (S2) | 8 DDV current path failed (S7) | 13 SDAF 1+2 current path failed (S12) |
| 4 EMU current path failed (S3) | 9 Gear monitoring current path failed (S8) | 14 PIM current path failed (S13) |
| 5 Starter voltage: Terminal 30, 31 not connected and PR 10.0600.001 has value 1 or 2 (S4) | 10 Emergency stop current path failed – 24V internal (S9) | 15 Spare current path failed (S14) |

The failed current paths are signaled consecutively following the preamble (LED on for 4 seconds (1)). There is a pause lasting 4 seconds in between.

Sample flashing sequences



A Fuse S5 failure (1/2 second steps)

B Fuse S1 and fuse S4 failure (1/2 second steps)

Note:

These bit sequences are transmitted constantly.

Information about the status of the current paths of the EIM is also provided in the CAN message "Status internal power supply".

7.22 Emergency Instrumentation (Local Operating Panel)

7.22.1 LOP and connectors - Cleaning

Preconditions

- Engine is stopped and starting disabled.

Special tools, Material, Spare parts

| Designation / Use | Part No. | Qty. |
|-------------------|-----------|------|
| Isopropyl alcohol | X00058037 | 1 |

Cleaning LOP

1. Wipe LCD display with dry cloth, without applying excessive pressure.
2. Remove dirt from keys using isopropyl alcohol.
3. Remove heavy soiling from housing surface with isopropyl alcohol.

Cleaning connectors on LOP

1. Remove dirt from connector and socket surfaces using isopropyl alcohol.
2. Check legibility of cable labels. Clean or replace illegible labels.

8 Appendix A

8.1 Abbreviations

| Abbreviation | Meaning | Explanation |
|--------------|---|---|
| ADEC | Advanced Diesel Engine Control | Engine governor |
| AL | Alarm | Alarm (general) |
| ANSI | American National Standards Institute | Association of American standardization organizations |
| ATL | Abgasturbolader | Exhaust turbocharger |
| BR | Baureihe | Series |
| BV | Betriebsstoffvorschrift | MTU Publication No. A01061/.. |
| CAN | Controller Area Network | Data bus system, bus standard |
| CPP | Controllable Pitch Propeller | |
| DILA | Diagnostic lamp | on EIM |
| DIN | Deutsches Institut für Normung e. V. | At the same time identifier of German standards (DIN = "Deutsche Industrie-Norm") |
| DIS | Display unit | Display panel |
| DL | Default Lost | Alarm: Default CAN bus failure |
| ECS | Engine Control System | Engine management system |
| ECU | Engine Control Unit | Engine governor |
| EDM | Engine Data Module | Memory module for engine data |
| EIM | Engine Interface Module | Interface to engine monitoring system |
| EMU | Engine Monitoring Unit | Engine monitoring unit |
| ETK | Ersatzteilkatalog | Spare Parts Catalog |
| FPP | Fixed Pitch Propeller | Fixed pitch propeller |
| GCU | Gear Control Unit | Gear control unit |
| GMU | Gear Monitoring Unit | Gear monitoring unit |
| HAT | Harbour Acceptance Test | |
| HI | High | Alarm: Measured value exceeds 1st maximum limit |
| HIHI | High High | Alarm: Measured value exceeds 2nd maximum limit |
| HT | High Temperature | |
| ICFN | ISO - Continuous rating - Fuel stop power - Net | Engine power rating as per DIN-ISO 3046-7 |
| IDM | Interface Data Module | Memory module for interface data |
| IMO | International Maritime Organization | |
| ISO | International Organization for Standardization | International umbrella organization for all national standardization institutes |
| KGS | Kraftgegenseite | Engine free end in accordance with DIN ISO 1204 |
| KS | Kraftseite | Engine driving end in accordance with DIN ISO 1204 |
| LCD | Liquid Crystal Display, Liquid Crystal Device | Liquid crystal display |
| LCU | Local Control Unit | Local control unit (LOP subassembly) |

| Abbreviation | Meaning | Explanation |
|--------------|--|--|
| LED | Light Emitting Diode | Light emitting diode |
| LMU | Local Monitoring Unit | Local monitoring unit (LOP subassembly) |
| LO | Low | Alarm: Measured value lower than 1st minimum limit |
| LOLO | Low Low | Alarm: Measured value lower than 2nd minimum limit |
| LOP | Local Operating Panel | Control console, control panel |
| LOS | Local Operating Station | Local operating station |
| MCS | Monitoring and Control System | |
| MG | Message | |
| MPU | Microprocessor Unit, Microprocessing Unit | Microprocessor (unit) |
| OT | Oberer Totpunkt | Top Dead Center |
| P-xyz | Pressure-xyz | Pressure measuring point xyz |
| PAN | Panel | Control panel |
| PCU | Propeller Control Unit | |
| PIM | Peripheral Interface Module | |
| RCS | Remote Control System | |
| RL | Redundancy Lost | Alarm: Redundant CAN bus failure |
| SAE | Society of Automotive Engineers | U.S. standardization organization |
| SAT | Sea Acceptance Test | |
| SD | Sensor Defect | Alarm: Sensor failure |
| SDAF | Shut Down Air Flaps | Emergency-air shutoff flap(s) |
| SILA | Sicherungslampe | Fuse lamp on EIM |
| SOLAS | International Convention for the Safety of Life at Sea | |
| SS | Safety System | Safety system alarm |
| SSK | Schnellschlussklappe(n) | Emergency-air shutoff flap(s) |
| T-xyz | Temperature-xyz | Temperature measuring point xyz |
| TD | Transmitter Deviation | Alarm: Sensor comparison fault |
| UT | Unterer Totpunkt | Bottom Dead Center |
| VS | Voith Schneider | Voith Schneider drive |
| WJ | Water Jet | Water jet drive |
| WZK | Werkzeugkatalog | Tool Catalog |
| ZKP | Zugehörigkeit-Kategorie-Parameter | Assignment category parameter, number scheme for signals from the ADEC engine governor |

8.2 MTU contact persons/service partners

Our worldwide sales network with its subsidiaries, sales offices, representatives and customer service centers ensures fast and direct support on site and the high availability of our products.

Local support

Experienced and qualified specialists place their knowledge and expertise at your disposal.

For locally available support, go to the MTU Internet site: <http://www.mtu-online.com>

24h hotline

With our 24h hotline and the outstanding flexibility of our service staff, we are always ready to assist you – either during operation, for preventive maintenance, corrective work in case of malfunction or changed operating conditions, or for spare parts supply.

Your contact person in our Customer Assistance Center:

E-mail: info@mtu-online.com

Tel.: +49 7541 9077777

Fax: +49 7541 9077778

Asia/Pacific: +65 6100 2688

North and Latin America: +1 248 560 8000

Spare parts service

Fast, simple and correct identification of spare parts for your drive system or vehicle fleet. The right spare part at the right time at the right place.

With this aim in mind, we can call on a globally networked spares logistics system, a central warehouse at headquarters and on-site stores at our subsidiary companies, agencies and service workshops.

Your contact at Headquarters:

E-mail: spare.parts@mtu-online.com

Tel.: +49 7541 908555

Fax: +49 7541 908121

9 Appendix B

9.1 Index

A

- Abbreviations 208
- Actuators
 - Overview 26
- ADEC (ECU 7) fault codes for Series 4000 engines, marine application 100
- After stopping the engine 91
- Air filter
 - Installation 159
 - Removal 159
 - Replacement 158
- Automatic oil filter
 - Oil filter candles replacement 168

B

- Battery-charging generator drive
 - Coupling condition check 184
- Bilge pump
 - Relief bore check 186

C

- CDC parameters
 - Reset 194
- Centrifugal oil filter
 - Cleaning 173
- Checks
 - Prior to start-up 77
- Coalescer filter element
 - Replacement 191
- Compressor wheel
 - Cleaning 155
- Connectors
 - Cleaning 195, 197
- Contact persons 210
- Coolant
 - Change 177
- Coupling
 - From LOP 84
- Cylinder
 - Designation 25
- Cylinder head cover
 - Removal and installation 138
- Cylinder liner
 - Endoscopic examination 129
 - Instructions and comments on endoscopic and visual examination 131

D

- Designations
 - Engine sides and cylinders 25
- Differential pressure gauge
 - Check 188

- Disengaging
 - from LOP 85

E

- ECU 7
 - Installation 201
 - Removal 201
- ECU 7 engine governor
 - Installation 201
 - Removal 201
- Emergency stop
 - From LOP 89
- EMU
 - Cleaning 195
- EMU 8
 - Installation 202
 - Removal 202
- Engine
 - Barring with starting system 128
 - Emergency stop 90
 - Start 73
 - Stopping 82
 - At the BlueLine automation system (control stand) 88
 - From LOP 87
 - Wiring check 193
- Engine Control Unit ECU 7
 - Checking plug connections 198
- Engine coolant
 - Change 177
 - Filling 179
 - Level check 176
 - Sample analysis 182
 - Sample extraction 182
- Engine coolant draining 178
- Engine coolant pump
 - Relief bore check 181
- ENGINE DATA 12V 4000M93, heat exchanger installed, EPA stage 2 43
- ENGINE DATA 12V 4000M93, heat exchanger installed, IMO 46
- ENGINE DATA 12V 4000M93L, heat exchanger installed, EPA stage 2 49
- ENGINE DATA 12V 4000M93L, heat exchanger installed, IMO 52
- ENGINE DATA 16V 4000M93, heat exchanger installed, EPA stage 2 55
- ENGINE DATA 16V 4000M93, heat exchanger installed, IMO 58
- ENGINE DATA 16V 4000M93L, heat exchanger installed, EPA stage 2 61

ENGINE DATA 16V 4000M93L, heat exchanger installed, IMO 64

Engine emergency stop

- At BlueLine automation system (control stand) 83

Engine governor

- Cleaning 197

Engine Interface Module EIM

- Removal and installation 203

Engine layout 15

Engine Monitoring Unit EMU 8

- Plug connections check 199

Engine mounting

- Check 185

Engine oil

- Centrifugal oil filter
 - Cleaning 173
- Change 163
- Filter sleeve
 - Replacing 173
- Sample analysis 165
- Sample extraction 165

Engine oil level

- Check 162

Engine sides

- Designation 25

Engine wiring

- Check 193

Engine wiring harness

- Overview 36

Engine - Barring manually 127

Engine - Main dimensions 67

F

Filter

- Coalescer element
 - Replacement 191

Filter sleeve

- Replacing 173

Firing order 68

Fuel

- Prefilter
 - Flushing 151
- Treatment system
 - Switching on 81
 - Troubleshooting 96
- treatment system
 - Shutdown 92

Fuel filter - Replacement 147

Fuel prefilter

- Differential pressure gauge adjustment 149
- Differential pressure gauge check 149
- Draining 150
- Filter element
 - Replacement 153
- Flushing 151

Fuel treatment system

- Putting into operation 78
- Shutdown 92
- Switching on 81

Fuel treatment system control cabinet - Control elements 75

H

Hotline 210

HP pump

- Filling with engine oil 139
- Relief bore check 140

I

Injector

- Removal and installation 142
- Replacement 141

Intercooler

- Check water drain for coolant discharge and obstruction 157

Interface module EIM

- Check 200

L

Limit switch for start interlock

- Check 196

LOP

- Cleaning 207
- Connector cleaning 207

LOP - Controls 69

M

Maintenance schedule

- Maintenance schedule task reference table [QL1] 94

MTU contact persons 210

O

Oil indicator filter

- Check 171
- Cleaning 166, 171

Operational checks 74

P

Plant

- Cleaning 93

Plug connections

- Check 200

Product description 16

Pump capacity

- Check 190

Putting the engine into operation after extended out-of-service periods (>3 months) 71

Putting the engine into operation after scheduled out-of-service-period 72

R

Raw water pump

- Relief bore check 183

S

Safety notices, standards 13

- Safety regulations
 - Consumables 11
 - Environmental protection 11
 - Fire prevention 11
 - Fluids and lubricants 11
 - Important provisions 5
 - Maintenance work 8
 - Operation 7
 - Organizational requirements 6
 - Personnel requirements 6
 - Repair work 8
 - Safety notices, standards 13
 - Startup 7
- Sensors
 - Overview 26
- Service indicator
 - Signal ring position check 160
- Service partners 210
- Spare parts service 210
- Starter
 - Condition check 161

T

- Tasks
 - After extended out-of-service periods 76
- Tasks after extended out-of-service periods (>3 weeks) 76
- transport 14
- Troubleshooting 97
 - Fuel treatment system 96

V

- Valve clearance
 - Adjustment 134
 - Check 134
- Valve gear
 - Lubrication 133
- Venting points 175

W

- Water drain valve
 - Check 187
- Water level probe (3-in-1 rod electrode)
 - Check 189
- Waterjet
 - Flushing
 - From LOP (option) 86

9.2 Spare Parts

Air filter

Part No.:

| | |
|----------|---|
| Qty.: | |
| Used in: | 7.9.1 Air filter – Replacement (→ Page 158) |

Coalescer filter element

Part No.:

| | |
|----------|--|
| Qty.: | |
| Used in: | 7.19.5 Coalescer filter element – Replacement (→ Page 191) |

Easy-change filter

Part No.:

| | |
|----------|--|
| Qty.: | |
| Used in: | 7.6.1 Fuel filter – Replacement (→ Page 147) |

Filter element

Part No.:

| | |
|----------|--|
| Qty.: | |
| Used in: | 7.6.5 Fuel prefilter – Filter element replacement (→ Page 153) |

Filter sleeve

Part No.:

| | |
|----------|---|
| Qty.: | |
| Used in: | 7.13.4 Centrifugal oil filter – Cleaning and filter-sleeve replacement (→ Page 173) |

Gasket

Part No.:

| | |
|----------|---|
| Qty.: | |
| Used in: | 7.3.3 Cylinder head cover – Removal and installation (→ Page 138) |

| | |
|----------|--|
| Qty.: | |
| Used in: | 7.6.3 Fuel prefilter – Draining (→ Page 150) |

| | |
|----------|--|
| Qty.: | |
| Used in: | 7.6.5 Fuel prefilter – Filter element replacement (→ Page 153) |

| | |
|----------|--|
| Qty.: | |
| Used in: | 7.19.5 Coalescer filter element – Replacement (→ Page 191) |

Injector

Part No.:

| | |
|----------|---|
| Qty.: | |
| Used in: | 7.5.1 Injector – Replacement (→ Page 141) |

O-ring

Part No.:

| | |
|----------|--|
| Qty.: | |
| Used in: | 7.5.2 Injector – Removal and installation (→ Page 142) |

| | |
|----------|---|
| Qty.: | 1 |
| Used in: | 7.13.1 Oil indicator filter – Cleaning (→ Page 166) |

| | |
|----------|---|
| Qty.: | 1 |
| Used in: | 7.13.1 Oil indicator filter – Cleaning (→ Page 166) |

| | |
|----------|---|
| Qty.: | |
| Used in: | 7.13.2 Automatic oil filter – Oil filter candles replacement (→ Page 168) |

| | |
|----------|---|
| Qty.: | |
| Used in: | 7.13.3 Oil indicator filter – Cleaning and check (→ Page 171) |

Oil filter candles

Part No.:

| | |
|----------|---|
| Qty.: | |
| Used in: | 7.13.2 Automatic oil filter – Oil filter candles replacement (→ Page 168) |

Seal

Part No.:

| | |
|----------|--|
| Qty.: | |
| Used in: | 7.6.4 Fuel prefilter – Flushing (→ Page 151) |

Sealing ring

Part No.:

| | |
|----------|---|
| Qty.: | |
| Used in: | 7.12.2 Engine oil – Change (→ Page 163) |

| | |
|----------|---|
| Qty.: | |
| Used in: | 7.13.4 Centrifugal oil filter – Cleaning and filter-sleeve replacement (→ Page 173) |

Square-section ring

Part No.:

| | |
|----------|---|
| Qty.: | |
| Used in: | 7.13.3 Oil indicator filter – Cleaning and check (→ Page 171) |

Strainer

Part No.:

| | |
|----------|---|
| Qty.: | 1 |
| Used in: | 7.13.1 Oil indicator filter – Cleaning (→ Page 166) |

| | |
|----------|---|
| Qty.: | |
| Used in: | 7.13.3 Oil indicator filter – Cleaning and check (→ Page 171) |

Synthetic ring

Part No.:

| | |
|----------|--|
| Qty.: | |
| Used in: | 7.6.1 Fuel filter – Replacement (→ Page 147) |

9.3 Consumables

Assembly paste (Optimoly Paste White T)

Part No.: 40477

Qty.: 1

Used in: 7.5.2 Injector – Removal and installation (→ Page 142)

Cleaner (Hakupur 312)

Part No.: 30390

Qty.: 1

Used in: 4.22 Plant – Cleaning (→ Page 93)

Qty.: 1

Used in: 7.13.1 Oil indicator filter – Cleaning (→ Page 166)

Qty.: 1

Used in: 7.13.3 Oil indicator filter – Cleaning and check (→ Page 171)

Cleaner (Snow-White 11-0)

Part No.: X00054118

Qty.: 1

Used in: 7.13.1 Oil indicator filter – Cleaning (→ Page 166)

Cleaner (Snow-White 11-0)

Part No.: 40460

Qty.: 1

Used in: 7.13.3 Oil indicator filter – Cleaning and check (→ Page 171)

Cold cleaner

Part No.: X00056750

Qty.: 1

Used in: 7.7.1 Compressor wheel – Cleaning (→ Page 155)

Cold cleaner (Hakutex 60)

Part No.: X00056750

Qty.: 1

Used in: 7.13.4 Centrifugal oil filter – Cleaning and filter-sleeve replacement (→ Page 173)

Coolant

Part No.:

Qty.:

Used in: 7.14.3 Engine coolant – Change (→ Page 177)

Diesel fuel

Part No.:

Qty.:

Used in: 7.6.1 Fuel filter – Replacement (→ Page 147)

Qty.:

Used in: 7.6.3 Fuel prefilter – Draining (→ Page 150)

Qty.:

Used in: 7.6.5 Fuel prefilter – Filter element replacement (→ Page 153)

Qty.:

Used in: 7.19.5 Coalescer filter element – Replacement (→ Page 191)

Engine coolant

Part No.:

Qty.:

Used in: 7.14.5 Engine coolant – Filling (→ Page 179)

Engine oil

Part No.:

Qty.:

Used in: 7.3.1 Valve gear – Lubrication (→ Page 133)

Qty.:

Used in: 7.3.2 Valve clearance – Check and adjustment (→ Page 134)

Qty.:

Used in: 7.4.1 HP pump – Filling with engine oil (→ Page 139)

Qty.:

Used in: 7.5.2 Injector – Removal and installation (→ Page 142)

Qty.:

Used in: 7.12.2 Engine oil – Change (→ Page 163)

Qty.:

Used in: 7.13.1 Oil indicator filter – Cleaning (→ Page 166)

Qty.:

Used in: 7.13.2 Automatic oil filter – Oil filter candles replacement (→ Page 168)

Qty.:

Used in: 7.13.3 Oil indicator filter – Cleaning and check (→ Page 171)

Qty.:

Used in: 7.19.5 Coalescer filter element – Replacement (→ Page 191)

Fuel

Part No.:

Qty.:

Used in: 7.6.4 Fuel prefilter – Flushing (→ Page 151)

Grease (Klutho Hakuform 30-10/Emulgier)

Part No.: X00029933

Qty.: 1

Used in: 7.5.2 Injector – Removal and installation (→ Page 142)

Qty.: 1

Used in: 7.13.2 Automatic oil filter – Oil filter candles replacement (→ Page 168)

Isopropyl alcohol


| | |
|-----------|---|
| Part No.: | X00058037 |
| Qty.: | 1 |
| Used in: | 7.20.1 Engine wiring – Check (→ Page 193) |
| Qty.: | 1 |
| Used in: | 7.21.4 Engine governor and connectors – Cleaning (→ Page 197) |

Isopropyl alcohol

| | |
|-----------|---|
| Part No.: | X00058037 |
| Qty.: | 1 |
| Used in: | 7.22.1 LOP and connectors – Cleaning (→ Page 207) |


9.4 Special Tools

Barring device




| | |
|-----------|--|
| Part No.: | F6555766 |
| Qty.: | 1 |
| Used in: | 7.1.1 Engine – Barring manually (→ Page 127) |

Box wrench socket, 24 mm




| | |
|-----------|---|
| Part No.: | F30039526 |
| Qty.: | 1 |
| Used in: | 7.3.2 Valve clearance – Check and adjustment (→ Page 134) |

Feeler gauge




| | |
|-----------|---|
| Part No.: | Y20098771 |
| Qty.: | 1 |
| Used in: | 7.3.2 Valve clearance – Check and adjustment (→ Page 134) |

Installation/removal tool




| | |
|-----------|--|
| Part No.: | F6789889 |
| Qty.: | 1 |
| Used in: | 7.5.2 Injector – Removal and installation (→ Page 142) |

Milling cutter




| | |
|-----------|--|
| Part No.: | F30452739 |
| Qty.: | 1 |
| Used in: | 7.5.2 Injector – Removal and installation (→ Page 142) |

MTU test kit




| | |
|-----------|---|
| Part No.: | 5605892099/00 |
| Qty.: | 1 |
| Used in: | 7.12.3 Engine oil – Sample extraction and analysis (→ Page 165) |
| Qty.: | 1 |
| Used in: | 7.14.7 Engine coolant – Sample extraction and analysis (→ Page 182) |

Oil filter wrench




| | |
|-----------|--|
| Part No.: | F30379104 |
| Qty.: | 1 |
| Used in: | 7.6.1 Fuel filter – Replacement (→ Page 147) |

Ratchet



| | |
|-----------|--|
| Part No.: | F30027340 |
| Qty.: | 1 |
| Used in: | 7.5.2 Injector – Removal and installation (→ Page 142) |

Ratchet



Part No.: F30027341


Qty.: 1

Used in: 7.5.2 Injector - Removal and installation (→ Page 142)

Qty.: 1

Used in: 7.12.2 Engine oil - Change (→ Page 163)

Ratchet




Part No.: F30027339

Qty.: 1

Used in: 7.19.5 Coalescer filter element - Replacement (→ Page 191)

Ratchet head with extension




Part No.: F30006212

Qty.: 1

Used in: 7.1.1 Engine - Barring manually (→ Page 127)

Rigid endoscope



Part No.: Y20097353

Qty.: 1


Used in: 7.2.1 Cylinder liner - Endoscopic examination (→ Page 129)

Steam jet cleaner

| | |
|-----------|-----------------------------------|
| Part No.: | - |
| Qty.: | 1 |
| Used in: | 4.22 Plant – Cleaning (→ Page 93) |


Torque wrench

| | |
|-----------|---|
| Part No.: | F30027337 |
| Qty.: | 1 |
| Used in: | 7.12.2 Engine oil – Change (→ Page 163) |




Torque wrench, 0.5-5 Nm

| | |
|-----------|--|
| Part No.: | 0015384230 |
| Qty.: | 1 |
| Used in: | 7.5.2 Injector – Removal and installation (→ Page 142) |




Torque wrench, 10-60 Nm

| | |
|-----------|--|
| Part No.: | F30452769 |
| Qty.: | 1 |
| Used in: | 7.5.2 Injector – Removal and installation (→ Page 142) |




Torque wrench, 4-20 Nm




| | |
|-----------|--|
| Part No.: | F30044239 |
| Qty.: | 1 |
| Used in: | 7.9.2 Air filter – Removal and installation (→ Page 159) |

Torque wrench, 6-50 Nm



| | |
|-----------|---|
| Part No.: | F30027336 |
| Qty.: | 1 |
| Used in: | 7.13.4 Centrifugal oil filter – Cleaning and filter-sleeve replacement (→ Page 173) |
| Qty.: | 1 |
| Used in: | 7.19.5 Coalescer filter element – Replacement (→ Page 191) |

Torque wrench, 60-320 Nm



| | |
|-----------|---|
| Part No.: | F30452768 |
| Qty.: | 1 |
| Used in: | 7.3.2 Valve clearance – Check and adjustment (→ Page 134) |
| Qty.: | 1 |
| Used in: | 7.5.2 Injector – Removal and installation (→ Page 142) |